

Skilcraft

Wireless Optical Mouse

Model No.: CTW001V2

Mouse FCC ID: 2AHKSCTW001V2, Receiver FCC ID: 2AHKSREV

Quick Installation Guide

- Open the battery compartment located underneath the mouse and install 2 AAA batteries.
- Remove the USB receiver from the magnetic compartment in the bottom of the mouse.
- Slide the power switch on the bottom of the mouse to the ON position.
- Turn on your computer and insert the USB transmitter into an available USB port.
- Your computer will automatically configure to operate the mouse within a few minutes.
- Tracking speed can be adjusted with button below the scroll wheel (800/1200/1600 DPI).
- Buttons on the left side of the mouse can be used for forward and back web navigation.
- A low battery indicator LED is located on the left side of the mouse near the front.

Troubleshooting:

Mouse pointer (cursor) moves erratically.

- The batteries may be low. Replace the batteries.
- Some surfaces such as glass may cause issues with the optical sensor. Use a mouse pad to alleviate issues.

Mouse doesn't work properly.

- Unplug and replug the USB receiver.
- The batteries may be low. Replace the batteries.
- Test on another USB port or another computer.
- If the mouse still does not function, re-establish the wireless connection:
 1. Unplug the USB receiver.
 2. Install a fresh sets of batteries in mouse. Then press left, middle and right button simultaneously for 3-5 seconds. The LED indicator on the left side of the mouse flashes, indicating pairing mode.
 3. Plug the USB receiver in. The LED indicator flashes 1 second quickly, when pairing is successful. The mouse and USB receiver should be less than 1 meter apart when pairing.

Maintenance:

- Maintaining your mouse will ensure longer life and minimize the chance of damage to the mouse.
- Keep all beverages away from the mouse and avoid spills.
- Keep the bottom of the mouse clean and free of dust by wiping the bottom with a damp soft cloth.
- Use only alkaline batteries.

FCC DECLARATION OF CONFORMITY COMPLIANCE STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

MODIFICATIONS

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RADIATION EXPOSURE STATEMENT:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.