HeroBox

User Manual
取扱説明書
用户手册
Guide dell'utente
Guía del usuario
Руководство пользователя
Bedienungsanleitung
Guide d'utilisation

Made in China


CHUWI

English

Service Assurance

Thank you for purchasing this product. You can enjoy one-year free spare parts and manual service assurance provided by our company.
The following conditions lead to the need for our company to provide services,and the maintenance fees will be charged as appropriate:
-Failure to perform proper operations according to the user manual or instructions.
-Man-made damage, computer viruses, dampness, improper software installation or self-disassembly, etc.
-Fire, flood, wind, earthquake and other irresistible forces.
-Abrasive wear caused by accessories, consumables and natural use.
-If we need to re-install software or adjust computer settings on our behalf, we will charge fees as appropriate.
-Our company provides warranty for the damaged or dirty logo which may result in un-recognizability.
Before the product is repaired, please make a separate backup of your personal data and files, which may affect the integrity of the data during the process of maintenance. The company guarantees maintenance services so that you can buy and use it at ease.


Product Interface Description



1、Reset button 2、Power input 3、VGA interface
4、HD port 5、Network interface 6、USB2.0
7、Headphone 8、LED(Power Indicator) 9、Type-C
10-11、USB3.0 12、SD card(expansion slot)
13、Power Button 14、Bracket buckle

Instructions

1.Connect the device with the display device (such as TV, screen, projector, etc.) via HD line, and select the "video input source" of the display device to the connected HD input channel.
2.DC-IN power supply: Connect the DC-IN interface of the power cord of the accessories to the device and insert the other end directly into the plug.
3.Use the device by connecting it with a wired or wireless keyboard and mouse via USB port.
4.Press the power button to start the system.



Power Adapter (factory accessories)
It can be used with Bluetooth or wireless keyboard and mouse (self-provided)

HD installation

1 . Turn HeroBox upside down and remove the six fixing screws on the back as shown in the figure below. When removing the rear cover, the metal brackets on both sides of the HDD bin can be seen. Tear them down.
2. Install the metal bracket on both sides of the 2.5-inch HDD. Place the metal bracket and the HDD together into the HDD installation position of HeroBox. Install the fixing screws and pay attention to the direction of the HDD data interface.
3. Install the rear cover back into HeroBox and screw up the fixing screws.
Tip: The newly loaded HD must be initially operated before it can be identified by the system. The above operations require a certain knowledge of computer maintenance. It is recommended to install it at a professional after-sale maintenance site.



Intention of HDD Installation:
A、Rear cover of HeroBox B、HDD installation position of HeroBox C、2.5 inch HDD

Packing List:

1. Computer Box*1
2. User Manual(Warranty Card)l *1 Certificate *1
3. Power Adapter *1 VESA Display Bracket*1
4. Remote Controller * 1 (Optional)

Note

1.This low-power RF motor is a certified and qualified product. Companies, businesses or individuals may not change the frequency, enhance the power or change the characteristics and functions of the original design without permission.
2.Low-frequency RF motors should not affect flight safety and interfere with legitimate communication when they are used. When interference is found, they should be stopped using immediately and be improved to no interference before they can continue to be used. Legitimate communication refers to wireless communication in the work prescribed by law. Low-frequency RF motors must be able to tolerate the interference of legitimate communication or electromagnetic radiation motor equipment for industrial, scientific and medical purposes.
3.This product contains miniature batteries for mainboard CMOS, which cannot be replaced by consumers themselves. It may be dangerous if consumers replace incorrect types of batteries by themselves. Please properly handle the battery replacement.

Attention


1. This product is suitable for places below 3000 meters above sea level; this product is only suitable for non-tropical areas.
2. Be very careful when performing operations that may cause damage or loss of files.
3. After abnormal withdrawal or accidental power failure of the mini pc system, the hard disk scanning should be carried out as soon as possible to repair the errors in time.
4. When the mini pc boots, we should pay attention to the defense of the virus and try to use the virus firewall.
5. Turn on the display, printer, and other peripherals first, and finally turn on the device. Turn off the device first, then turn off the display.
6. If you do not use the device for a long time, turn off the main power switch.
7. The ideal working temperature of the device is 10-35 degrees, and the relative humidity is 30-80%.
8. The device should not be powered off for a long time (e.g. 1-3 months) before using it.
9. The device should not be turned on or off frequently; the time interval between two boots should be at least 10 seconds, preferably no less than 60 seconds.
10. You can't move the device or turn off the power while reading/writing to the hard disk. Wait for about 30 seconds after shutting down it.
11. Pay attention to dust control, keep the environment clean and hygienic, and wipe it with a dry soft cloth.
12. Avoid direct exposure of strong light to the device, and do not put it near the strong magnetic field.
13. Don't get water, food and other fluids onto the device, and don't pull the data and power lines with force.
14. Rationally organize the directory structure of the disk and always keep a copy of important things on the hard disk.

简体中文

服务保证说明

感谢您购买本产品，您可以享有本公司所提供的一年免费零件及人工保证服务。
下列状况导致需要本公司提供服务，将酌情收取维修费用：
· 未按产品使用手册或说明书进行不当操作。
· 人为损坏、电脑病毒、受潮、不当软体安装或自行拆装等。
· 火灾、水灾、风灾、地震等不可抗拒力。
· 配件、耗材、自然使用导致的磨损。
· 需要本公司代为重新安装软体或调整电脑设定，将酌情收取费用。
· 本公司保固识别标志损坏或髒污，导致无法辨识。
产品送修前，请将个人资料、档案另行备份，维修过程中可能会影响资料的完整性。
本公司保证维修服务，让您买的安心，用的放心。


产品接口说明



1、Reset按钮 2、电源接口 3、VGA显示接口
4、HD接口 5、网络接口 6、USB2.0
7、耳机 8、LED(电源指示灯) 9、Type-C
10-11、USB3.0 12、SD CARD (扩展槽)
13、开机按钮 14、支架卡扣

使用说明

1. 将本设备通过HD线与显示装置（如:电视、荧屏、投影仪等设备）连接，并将显示装置的的“视频输 入来源”选择至所连接的HD输入通道。
2. DC-IN供电：将配件的电源线DC-IN接口与本设备 连接，并将另一端直接插入插头。
3. 连接USB接口的有线或无线键盘鼠标使用。
4. 按电源键启动系统。



适配器（原厂附件）
可搭配蓝牙或无线键盘鼠标使用（自备）

FCC warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

CE FC RoHS

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.