

Hi10 XPro

User Manual

取扱説明書

用户手册

Guide dell'utente

Guia del usuario

Руководство пользователя

Bedienungsanleitung

Guide d'utilisation

Made in China

CHUWI

English

Introduction

Dear users, Thank you for choosing CHUWI. This is a product elaborately developed by CHUWI for freely surfing on the internet. Please read this user manual carefully before using the machine, so as to correctly use the function of the machine!

Disclaimer:
1. Please make sure to use the original power brick for charging. For problems or faults caused by any third-party adapter, the company does not undertake responsibility.

2. Users can use the music video, pictures and software which provide by third part but we don't take any responsibility for the copyright issue or software fault.
3. If the product fails, we will strictly comply with the warranty terms, but in the process of use may cause property losses or economic losses, we will not be responsible.

4. The device comes with factory - built software that can be used after actual testing.However, if you delete or do not delete anything while looking for compatibility or other issues, there will be no impact on the machine.Please note that it is not a product quality problem.

5. The company reserves the right to improve the product, product specifications and design are subject to change without prior notice! Please refer to the real product.

(1)The attention:

Computer are precision electronic instruments, please do not disassemble by yourself.

- Avoid throwing collision.
- Avoid using device in high temperature, low temperature, humidity, dust, strong magnetic field and long time exposure to sunlight.

- Wipe gently the device by wrung-out wet cotton dath, Avoid contact with other chemicals.

- This device can't survive drip and splash water, and can't place it beside such as full glass of liquid.

- Please use appropriate volume to avoid damaging your hearing.

- Please use original battery, charger and other accessories.The use of any other type of accessories will violate the warranty and may cause the equipment to malfunction.


- Do not disconnect the device during formatting or ongoing updates and downloads, or you may cause corruption errors.

- Dispose of waste machinery and accessories in accordance with local environmental regulations.

- If you have any questions during the use of the equipment, please contact your local distributor or contact our customer service directly.

- The company reserves the right to improve the product, product specifications and design are subject to change without prior notice! Please refer to the real product.

(2) Instruction



The way to turn on the tablet is to press the button, please press the power button to turn on it. Please click "power off" in the OS to turn off the tablet. Pressing the power button for several seconds by force to turn off the tablet can be used in special circumstances. What customers need to pay attention to is that frequent power-off by force may cause system files missing or crash of the tablet.

(3)The solution of common problem:
1.Tablet can't boot

a.Check if the battery is fully charged.
b.Check the power adapter before starting the machine again.
c.If it is still unable to boot after charging, please contact with our distributors.

2.WiFi can't work
a.Please confirm whether there is a WiFi hotspot.
b.Make sure that the tablet is connected to the WiFi (enter the settings to check).
c. Please confirm the WiFi signal strength and link permission.

(4)Technical specification

Brand: CHUWI
Model: Hi10 XPro
System: Android™ operating system
CPU Brand: Unisoc™ T606
Screen size: 10.1
Resolution: 1280*800
Network: WiFi (2.4G/5G 802.11b/g/n/ac), Dual Nano SIM Card
Connection: OTG, Bluetooth 5.0
Expansion slot: 128GB Micro SD card (TF)
Other interface: 3.5mm headphone jack, TF card interface.
Type-C (USB 2.0 data/charging)
Preposition: 500W, Postposition: 1300W
Battery capacity: 7000mAh
Charger: Input: AC100-240V, 50-60Hz Output: 5V*2A, 239.3mm*158mm*7.5mm
Size: MP3, AAC, AAC+, AMR-NB
Voice format: H.264, H.265, VP8, VP9
Video format: H.264, H.265, VP8, VP9

Android is a trademark of Google LLC.

Español

Introducción

Estimados usuarios, Gracias por elegir CHUWI. Este es un producto desarrollado por CHUWI para navegar libremente en Internet. Lea este manual de usuario detenidamente antes de utilizar la máquina para utilizar correctamente la función de la máquina!

Descargo de responsabilidad:
1. Asegúrese de utilizar el bloque de alimentación original para cargar. Para problemas o fallos causados por cualquier adaptador de terceros, la compañía no asume responsabilidad.

2. Los usuarios pueden usar video música, las imágenes y el software que proporcionan terceros, pero no nos hacemos responsables por problemas de derechos de autor o falta del software.

3. Si el producto falla, cumpliremos estrictamente con los términos de la garantía, pero en el proceso de uso puede causar pérdidas de propiedad o pérdidas económicas, no seremos responsables.

4. El dispositivo viene con un software de fábrica que puede usarse después de las pruebas reales. Sin embargo, si se elimina o no se elimina o si mismo mientras busca compatibilidad u otros problemas, no habrá impacto en la nuestra distribuidores.

5. La compañía se reserva el derecho de mejorar el producto! Las especificaciones y el diseño del producto están sujetos a cambios sin previo aviso. Por favor, consulte el producto real.

(1) Atención:
- Los ordenadores son instrumentos electrónicos de precisión, no los desmonte usted mismo.

- Evite tirar o dar golpes.
- Evite usar el dispositivo a alta temperatura, baja temperatura, humedad, polvo, campo magnético fuerte u exposición prolongada a la luz solar.

- Limpie suavemente el dispositivo con un paño de algodón húmedo u oscuro. Evite el contacto con otros productos químicos.

- Este dispositivo no puede sobrevivir al agua o salpicaduras de agua, y no puede colocarlo al lado como un vaso lleno de líquido.

- Utilice el volumen apropiado para evitar daños su audición.

- Utilice la batería original, el cargador y otros accesorios. El uso de cualquier otro tipo de accesorios violará la garantía y puede causar un mal funcionamiento del equipo.

- No desconecte el dispositivo durante el formato o las cargas y descargas continuas, o puede causar errores en la aplicación.

- Deshéchese los desperdicios de maquinaria u accesorios de acuerdo con las regulaciones ambientales locales.

- Si tiene alguna pregunta durante el uso del equipo, comuníquese con su distribuidor local o directamente con nuestro centro de servicio al cliente.

- La compañía se reserva el derecho de mejorar el producto, las especificaciones y el diseño del producto están sujetos a cambios sin previo aviso! Por favor, consulte el producto real.

(2) Instrucciones



The way to turn on the tablet is to press the button, please press the power button to turn on it. Please click "power off" in the OS to turn off the tablet. Pressing the power button for several seconds by force to turn off the tablet can be used in special circumstances. What customers need to pay attention to is that frequent power-off by force may cause system files missing or crash of the tablet.

(3)The solution of common problem:
1.Tablet can't boot

a.Check if the battery is fully charged.
b.Check the power adapter before starting the machine again.
c.If it is still unable to boot after charging, please contact with our distributors.

2.WiFi can't work
a.Please confirm whether there is a WiFi hotspot.
b.Make sure that the tablet is connected to the WiFi (enter the settings to check).
c. Please confirm the WiFi signal strength and link permission.

(4) Specifications

Marca: CHUWI
Modelo: Hi10 XPro
Sistema Operativo: Android™
CPU de la marca: Unisoc™ T606
Tamaño de pantalla: 10.1
Resolución: 1280*800
Tipo de conexión de red: OTG, Bluetooth 5.0
Conectividad: 128GB Micro SD Card (TF)
Ranura de expansión: 3.5mm headphone jack, TF card interface.
Tipo-C (Carga/datos USB 2.0)
Preposición: 500W, Postposición: 1300W
Capacidad de batería: 7000mAh
Cargador: Entrada: AC100-240V, 50-60Hz Salida: 5V*2A, 239.3mm*158mm*7.5mm
Formato de voz: MP3, AAC, AAC+, AMR-NB
Formato de video: H.264, H.265, VP8, VP9

Android es una marca de Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Español

Introducción

Estimados usuarios, Gracias por elegir CHUWI. Este es un producto desarrollado por CHUWI para navegar libremente en Internet. Lea este manual de usuario detenidamente antes de utilizar la máquina para utilizar correctamente la función de la máquina!

Descargo de responsabilidad:
1. Asegúrese de utilizar el bloque de alimentación original para cargar. Para problemas o fallos causados por cualquier adaptador de terceros, la compañía no asume responsabilidad.

2. Los usuarios pueden usar video música, las imágenes y el software que proporcionan terceros, pero no nos hacemos responsables por problemas de derechos de autor o falta del software.

3. Si el producto falla, cumpliremos estrictamente con los términos de la garantía, pero en el proceso de uso puede causar pérdidas de propiedad o pérdidas económicas, no seremos responsables.

4. El dispositivo viene con un software de fábrica que puede usarse después de las pruebas reales. Sin embargo, si se elimina o no se elimina o si mismo mientras busca compatibilidad u otros problemas, no habrá impacto en la nuestra distribuidores.

5. La compañía se reserva el derecho de mejorar el producto! Las especificaciones y el diseño del producto están sujetos a cambios sin previo aviso. Por favor, consulte el producto real.

(1) Atención:
- Los ordenadores son instrumentos electrónicos de precisión, no los desmonte usted mismo.

- Evite tirar o dar golpes.
- Evite usar el dispositivo a alta temperatura, baja temperatura, humedad, polvo, campo magnético fuerte u exposición prolongada a la luz solar.

- Limpie suavemente el dispositivo con un paño de algodón húmedo u oscuro. Evite el contacto con otros productos químicos.

- Este dispositivo no puede sobrevivir al agua o salpicaduras de agua, y no puede colocarlo al lado como un vaso lleno de líquido.

- Utilice el volumen apropiado para evitar daños su audición.

- Utilice la batería original, el cargador y otros accesorios. El uso de cualquier otro tipo de accesorios violará la garantía y puede causar un mal funcionamiento del equipo.

- No desconecte el dispositivo durante el formato o las cargas y descargas continuas, o puede causar errores en la aplicación.

- Deshéchese los desperdicios de maquinaria u accesorios de acuerdo con las regulaciones ambientales locales.

- Si tiene alguna pregunta durante el uso del equipo, comuníquese con su distribuidor local o directamente con nuestro centro de servicio al cliente.

- La compañía se reserva el derecho de mejorar el producto, las especificaciones y el diseño del producto están sujetos a cambios sin previo aviso! Por favor, consulte el producto real.

(2) Instrucciones

The way to turn on the tablet is to press the button, please press the power button to turn on it. Please click "power off" in the OS to turn off the tablet. Pressing the power button for several seconds by force to turn off the tablet can be used in special circumstances. What customers need to pay attention to is that frequent power-off by force may cause system files missing or crash of the tablet.

(3)The solution of common problem:
1.Tablet can't boot

a.Check if the battery is fully charged.
b.Check the power adapter before starting the machine again.
c.If it is still unable to boot after charging, please contact with our distributors.

2.WiFi can't work
a.Please confirm whether there is a WiFi hotspot.
b.Make sure that the tablet is connected to the WiFi (enter the settings to check).
c. Please confirm the WiFi signal strength and link permission.

(4) Specifications

Marca: CHUWI
Modelo: Hi10 XPro
Sistema Operativo: Android™
CPU de la marca: Unisoc™ T606
Tamaño de pantalla: 10.1
Resolución: 1280*800
Tipo de conexión de red: OTG, Bluetooth 5.0
Conectividad: 128GB Micro SD Card (TF)
Ranura de expansión: 3.5mm headphone jack, TF card interface.
Tipo-C (Carga/datos USB 2.0)
Preposición: 500W, Postposición: 1300W
Capacidad de batería: 7000mAh
Cargador: Entrada: AC100-240V, 50-60Hz Salida: 5V*2A, 239.3mm*158mm*7.5mm
Formato de voz: MP3, AAC, AAC+, AMR-NB
Formato de video: H.264, H.265, VP8, VP9

Android es una marca de Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

русский

Вступление

Дорогие пользователи! Благодарим вас за выбор марки CHUWI. Мы разработали это устройство для удобства работы в интернете. Просим внимательно прочитать данное руководство перед началом пользования, чтобы правильно использовать все функции устройства.

Ограничение ответственности:
1. Пожалуйста, используйте оригинальный адаптер питания для зарядки изделия. Наша компания не несет ответственность за проблемы и неисправности, вызванные использованием неоригинального адаптера питания.

2. Вы можете использовать сторонние программы для воспроизведения аудио, видео и графического контента. Однако, мы не несем никакой ответственности за нарушения авторских прав и иные последствия использования стороннего программного обеспечения.

3. Если продукт выйдет из строя, мы выполним ремонт в строгом соответствии с гарантийными обязательствами. Но мы не несем ответственности за материальный ущерб или экономические потери, возникшие во время пользования продуктом.

4. В устройстве предустановлен заводской ПО, которым Вы можете пользоваться или переустанавливать по собственному желанию. Возможны несовместимости, глюки и иные проблемы с этим ПО никак не отразятся на исправности самого изделия. Просим не вызывать такие случаи с помощью нашей продукции.

5. Компания оставляет за собой право вносить изменения в конструкцию, дизайн и комплектацию изделия без предварительного уведомления, в связи с чем, покупатель самостоятельно отслеживает эти изменения.

(1). Общие указания по эксплуатации
- Компьютер является высокоточным электронным изделием. Показуется не разбирайте его самостоятельно.

- Не допускайте падений устройства и избегайте ударов.
- Не используйте устройство в среде с высокой и низкой температурой, повышенной влажностью или запыленностью, а также избегайте воздействия сильных магнитных полей и прямых солнечных лучей.

- Для очистки устройства используйте слегка увлажненный и тщательно отожженную мягкую ткань из хлопка. Не используйте химические чистящие средства.

- Не допускайте попадания влаги на поверхность и внутрь устройства. Не размещайте его, например, рядом со стиральной и посудомоечной машинами.

- Не превышайте рекомендуемые уровни громкости звука, чтобы не повредить слух.

- Используйте только оригинальные батареи, адаптеры питания и другие аксессуары. Устройства не подлежат гарантийному обслуживанию, если выяфен вынан использованием несовместимых аксессуаров и деталей.

- Не отключайте устройство во время форматирования, загрузки и сканирования, чтобы не вызвать ошибки при работе.

- Следуйте местным инструкциям по надежной утилизации отслужившего устройства.

- По вопросам использования этого устройства просим обращаться к вашему продавцу или в службу поддержки клиентов Чжуви.

- Компания оставляет за собой право вносить изменения в конструкцию, дизайн и комплектацию изделия без предварительного уведомления, в связи с чем, покупатель самостоятельно отслеживает эти изменения.

- Для зарядки батареи устройства требуется источник питания с определенными параметрами тока и напряжения, в связи с чем, используйте оригинальный адаптер питания для зарядки устройства.

- Если вы не пользуетесь устройством длительное время, то рекомендуем вам производить полную зарядку батареи один раз в неделю чтобы поддерживать готовность к началу ТР работы.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.

Android is a trademark of Google LLC.