



PRINTER SLUG FOR MANUAL

BRAND: CASE LOGIC
CATEGORY: EARBUDS

DESCRIPTION: **Manual for CL-AU-BE-136-AC,**


PRESS WORK: TRIM TO SIZE, SCORE & FOLD WHERE SPECIFIED

SCALE: **100%**

COLOR(S): **BLACK, 1/1.**

SUBSTRATE TYPE: **C2S MATTE ART PAPER 128gsm**

PRESS SPEC COLOR REFERENCES



APPROVAL CHECKLIST:

PRIMARY DESIGNER: DAVID H

DATE: **06.26.2026**

PROOF READ:
DATE:

APPROVED BY:
DATE:

AUTHORIZATION
SIGNATURES:

DO NOT PRINT "PRINTER SLUG" LAYER!

INSIDE PAGES

Read all safety information below and operating instructions before using these Wireless Earbuds to avoid injury and damage to your device, and store them for possible future reference. We assume no responsibility for the damage due to improper operation of the Wireless Earbuds.

SAFETY INSTRUCTIONS

WARNING: Do not use this unit for anything other than its intended use. Do not puncture, throw, drop, bend, or modify this product.
Do not throw this product into fire or water.
Do not short-circuit the battery with any metal or metallic objects. Do not expose this product to corrosive liquids such as salt water. Do not operate the unit if it has been wet or moist to prevent against electric shock and/or injury to yourself and damage to the unit. Do not allow children to play with this product as it is not a toy, and may present a choking hazard. Avoid leaving your device in direct sunlight, such as on the dashboard, console, or seat of a vehicle. Do not leave your device, or use your device, in any area where the temperature is likely to drop below 32°F, or may exceed 140°F, such as inside a closed vehicle on a hot day. Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk. Protect your hearing by always listening at a safe level. Prolonged use at elevated volumes may affect your hearing capacity and could result in hearing loss. Use the earbuds with this charging case only. To avoid damage to the charging case, please only use a USB 5V/1A or higher charger.
In order to ensure the battery life, charge normally at least once a month.

FCC ID: 2AHN6-CLBE136

SPECIFICATIONS

Bluetooth® Version: 6.0
Working distance: 33 ft
Charge Connector: USB Type-C
Speaker Size: Ø10 mm
Frequency Response: 20Hz - 20kHz
Sensitivity: 100 dB ± 3 dB
Charging voltage: 5V/1A
Case Battery: 300 mAh
Case Charge time: Up to 1.5 hrs
Earbuds Battery: 2 x 30 mAh
Earbuds Charge time: ±1 Hr

PACKAGE CONTENTS

True Wireless Earbuds, Charging Travel Case, 2 Small Ear Cushions, USB Charging Cable, Instruction Manual.

GETTING STARTED

Before using this device, fully charge it.

CHARGING

1. Replace the earbuds in the case.
2. Connect the USB Type-C charging cable to the charging port on the bottom of the case.
3. Plug the cable into a standard USB 5V/1A or higher power output charger outlet. When you plug the case into a charging mechanism, the earbud indicator lights will glow red, and the case LCD screen will display the percentage of power it has. When the case and earbuds batteries are fully charged, the screen will read "100%" and the earbud indicator lights will shut off.
4. When fully charged, unplug the charging cable from the power source.

If you want to charge the earbuds from the charge case internal battery, simply replace them in the case. The LCD screen will display their current battery levels and you will see as the levels rise.

PAIRING

1. Take out the earbuds from inside of the case. Both LED indicator lights will flash white until one of the earbuds flashes white, while the other earbud flashes white, indicating that the right and left earbuds have synced to each other.
2. Go to Bluetooth® Settings on your mobile device.
3. Turn Bluetooth® ON, on your device.
4. On your Bluetooth® device, select "CL-BE-136" from the list of available devices.


The earbud indicator lights will turn off to indicate they are paired.

USING THE EARBUDS

- Short press the control surface of either earbud to play/pause, or answer/end a call.
- Double press the left earbud control surface to go back to the start of a track.
- Double press the right earbud control surface to go to the next track.
- Triple press the left earbud control surface to lower the track volume.
- Triple press the right earbud control surface to increase the track volume.
- Long press the Control Surface of either earbud for 2 seconds to activate Google Assistant or Siri®.
- Long press the Control Surface of either earbud for 5 seconds to power on/off.

PHONE CALLS

When there is an incoming call, the unit will pause the playback and ring to alert you of the call. Phone call functions work the same on either of the earbuds. To answer an incoming call single tap the control button of either earbud. To end a call double tap the control surface. To reject an incoming call tap and hold the control surface. Volume controls may not work during phone calls with some smartphone models.



Using Siri® and Google Assistant™
On either earbud, press the control surface for 2 seconds to activate your AI assistant. The AI assistant on your device must be setup prior to this operation.

TROUBLESHOOTING

Earbuds do not sync with each other:
1. Place the earbuds in the case, then take out the earbuds, ensuring both earbuds are turned On.
2. On each earbud press and hold the control surface for 5 seconds. The earbuds will turn off after the LED flashes red 3 times.
3. Replace the earbuds in the charging case.
4. Repeat the Getting Started process.
Earbuds do not pair to device:
1. Turn the Earbuds OFF by pressing the control surface on each earbud until the LED blinks red, and then turns Off.
2. Replace the earbuds in the case. Turn your device's Bluetooth® OFF and then back ON. Then repeat the pairing process.

WARRANTY

Bytech NY INC. warrants this product to be free from defects in materials and workmanship to the original purchaser for a period of 12 months from the original purchase date. Bytech responsibility with regard to this limited warranty shall be limited solely to repair or replacement at its option of any product which fails during normal consumer use. This warranty does not extend to damage or failure which results from misuse, neglect, accident, alteration, abuse, improper installation or maintenance.
At any time during the 12 months period following the purchase, if the product fails due to defects in material or workmanship, return the defective product (with freight prepaid) with proof of purchase.

FCC COMPLIANCE STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Bluetooth® is a registered trademark of SIG Inc. Google, and the Google Assistant are registered trademarks of Google Inc. registered in the U.S and other countries.
Apple® and Siri® are registered trademarks of Apple® Inc. registered in the U.S and other countries.

USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum, Inc.
Bytech and Thule Group have no affiliation to Apple Inc., Google LLC, or USB Implementers Forum, Inc.

*All Trademarks and copyrights are the property of their respective owners.
*Actual products may differ slightly, images are for illustrative purposes only.

Manufactured by Bytech NY INC., an authorized Licensee of Thule Group. This product is not designed, manufactured, sponsored, or endorsed by SIG Inc., Apple Inc., Google LLC, or USB Implementers Forum, Inc.

©2026 Thule Group

42 Silvermine Road, Seymour, CT 06483 USA.
Avenue Jean Monnet 4, 1348 Louvain-la-Neuve, Belgium.
Unit 806, 8/F, CTF Life Tower, 18 Sheung Yuet Road, Kowloon Bay, Hong Kong.

caseologic.com

Contact Info:
2585 West 13th Street, Brooklyn, NY 11223.
Manufactured by Bytech NY Inc., an authorized Licensee of Thule Group®.

©2026 BYTECH NY INC. BYTECH™ is a registered trademark of Bytech NY INC. www.bytechintl.com

WARRANTY: 12 MONTHS
Please visit our website: www.Bytechintl.com/warranty or call us at (718) 449-3700.
Made in China.



OUTSIDE PAGES



LIFE, SIMPLIFIED.



TRUE WIRELESS EARBUDS



CL-AU-BE-136-AC

SCORE AND FOLD AS SHOWN ON THIS PICTURE

