

BYTECH®
THE ART OF TECHNOLOGY

BY-KB-WS-116-AC



ergo WIRELESS KEYBOARD

INCLUDES:

- 1 (One) Wireless Ergo Keyboard 14.1in. x 8.27in. x 1.25in.(35.8 cm x 21 cm x 3.1 cm)
- 1 (One) USB Receiver .72in. x .57in. x .23in.(1.85cm x 1.46cm x .6cm)
- 1 (One) User Manual

FEATURES

- Wireless connection: automatic linking, plug & play via USB receiver.
- Responsive buttons for ultimate productivity and efficiency.
- Ergonomic split design helps to position wrists and forearms in a natural, relaxed position.
- Built-in cushioned wrist rest to reduce wrist fatigue.
- Customize your working angle with the flip-out stand.

OPERATING INSTRUCTIONS

1. Power ON/OFF:

The keyboard is powered by 2 (Two) AA 1.5V Alkaline Batteries. The ON/OFF switch is located on the top side panel of the keyboard.

USB RECEIVER

- The USB receiver can be found (and stored) in a slot on the bottom of the keyboard, under the battery compartment cover.
- Flip the keyboard over. Open the battery compartment door. You will see a small rectangular object embedded in a slot in the bottom of the keyboard, imprinted with the FCC ID number, this is the USB receiver unit, and it can be stored in this slot when not in use so that it doesn't get lost or damaged. The keypad will not work without the USB Receiver.
- Remove it carefully by hooking a fingernail into the groove along the metal side surface, and lift it up slowly to free it, being very careful not to damage or lose it.

HOW TO USE

- Place 2 (Two) X AA 1.5V Alkaline Battery (not Included) into the battery compartment on the bottom of the keyboard.
- Insert the USB receiver into one of your computer's USB ports.
- Turn the keyboard ON (the switch is located on the top side panel).
- Your computer should recognize the keyboard instantly. Be sure to check your computer's settings if it is not detected.
- Remove the USB receiver from your computer's USB port when the unit is not in use.


NOTE: If your computer lost connection to keyboard, unplug and reinsert the USB receiver, press and hold FN+Q for 3 seconds to pair.

INSTALL THE BATTERIES IN THE KEYBOARD:

- Step1: Remove the battery compartment cover on the bottom of the keyboard by squeezing the cover in from the tab to release it.

- Step2: Insert batteries in the battery compartment.

- Step3: Replace the cover.



Sleep:

After 10 minutes of no button action, keyboard will enter sleep mode; If a button is pressed while the keyboard is in sleep mode, it will automatically return to its original state.

CAUTION

- This is not a toy. Please keep away from small children.
- Please keep the unit away from water and heat.
- This unit is for indoor use only.

Interface compatibility: USB 2.0/3.0

Working range: up to 33 feet (10 meters)

Sleep mode: after 10 minute of inactivity, keyboard will go into sleep mode

Sleep wake-up: press any button to wake up

Operation Voltage: 3.0V

Operation Current: ≤6ma

Operating Temperature: -10~55°C

Storage Temp: -20~+60°C

Forced Pairing: Press and hold Esc+Q

Operating Humidity: 20~90%

Storage Humidity: ≤93% (40C°)

LED LIGHT INDICATORS



← Caps Lock (The Caps Lock indicator lights green when Caps Lock is on).

← Battery (The Power indicator lights green when batteries are installed).

MULTIMEDIA HOTKEYS FUNCTIONS:



Mute



Volume -



Volume +



Previous Track



Pause/Play



Next Track



Brightness-



Brightness+



Select All



Copy



Paste



Cut

*Please note the following limitations when using this keyboard with Mac OS®:

- Non-functional keys: **F9, F10, F11, F12**, and the **Windows** key.
- Incorrect key mapping: **Home** key functions as Page Up; **End** key functions as Page Down.
- **Menu** key: Limited functionality.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

For Ergo Wireless Keyboard-ASST

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

For Ergo Wireless Keyboard-dongle

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

FCC ID: 2AHN6-KBWS116 FCC ID 2AHN6-DE12

SPECIFICATIONS:

- 2.4GHz wireless keyboard
- 85 keys
- Working range: up to 33 feet
- Battery: 2 (Two) X AA 1.5V Alkaline Battery (Not Included)

COMPATIBILITY

Windows® 7/8/10/11 & Mac OS®

©2025 BYTECH NY INC.

BYTECH™ is a registered trademark of Bytech NY INC.

*All Trademarks and copyrights are the property of the respective companies.

*Mac OS® is a registered trademark of Apple Inc.

*Windows® is a registered trademark of Microsoft Corporation.

*Bytech NY Inc. has no affiliation to Apple Inc. or Microsoft Corporation, Inc.

*Photos are for illustration purposes only.

*Mac OS® user will have limited media keys functionality.

WARRANTY- 12 MONTH

Please visit our website Bytechintl.com/warranty

BYTECH

Contact Info:

2585 West 13th Street,

Brooklyn, NY 11223

BYTECHintl.com

© 2025 BYTECH NY INC.

CE FC

MADE IN CHINA

⚠ WARNING: TO AVOID BATTERY LEAKAGE

- 1) Be sure to insert the batteries correctly, and always follow the toy/game and battery manufacturers' instructions.
- 2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- 3) Always remove weak or dead batteries from the product.
- 4) Remove the battery if the product is left unused for a long period of time.