

BYTECH®
THE ART OF TECHNOLOGY



Windows® and Mac® Compatible



**ergonomic
wireless mouse**

BY-MS-WS-135-AC

INCLUDED ITEMS:

- 1 (One) Ergonomic Wireless Mouse 4.4in. x 3.14in. x 1.81in. (11.2cm x 8cm x 4.6cm)
- 1 (One) USB Receiver .72in. x .56in. x .23in. (1.85cm x 1.43cm x .6cm)
- 1 (One) User Manual

FEATURES

- Ergonomic design.
- Adjustable DPI: 800/1200/1600.
- 6 buttons with scroll wheel.
- No pairing required, Plug and Play via 2.4Ghz USB receiver.
- On/Off power switch.

Thank you for choosing our ergonomic 2.4G wireless mouse. This mouse supports 2.4GHz wireless connection, which can be seamlessly paired with a variety of devices to provide a flexible user experience. It can meet your needs whether you are working, gaming or entertaining.

POWER SWITCH

Controls the mouse power to turn ON and OFF. To turn on the power, slide the power switch at the bottom of the mouse to the ON position; to turn off the power, slide the power switch to the OFF position.

DPI SWITCH BUTTON

Adjusts the mouse sensitivity (DPI value).

FUNCTION DESCRIPTION

- Left Button:** Standard left-button function.
- Middle Button:** Standard middle-button function.
- Right Button:** Standard right-button function.
- Front Side Button:** Forward button (can be tested and used in the browser).
- Rear Side Button:** Backward button (can be tested and used in the browser).

USB RECEIVER

- The USB receiver can be found stored in a slot adjacent to the battery bay under the battery bay door.
- Flip the mouse over and remove the battery bay door. You will see a smooth black rectangular object.
- Remove it carefully by hooking a fingernail into the groove along the surface that faces the battery bay and lift it up slowly to free it.
- Store the receiver in this slot when the mouse is not in use so that it doesn't get lost.

HOW TO USE

- Insert the USB receiver into your computer's USB port.
- Place 1 (One) X AA 1.5V Alkaline Battery (not included) into the battery compartment of the mouse according to the positive and negative polarity.
- Turn on the mouse power switch (located at the bottom of the mouse).
- Your computer should recognize the mouse instantly. Be sure to check your computer's settings if it is not detected.
- Please remember to remove the USB receiver when you are not using the device.

MAINTENANCE

- Clean the mouse surface with a soft cloth.
- Prevent liquid from splashing into the mouse.
- Avoid exposing the mouse to extreme temperature or humid environments.
- Do not disassemble the mouse by yourself; if there is any problem, please contact professional maintenance personnel.
- If the mouse is not used for a long time, remove the battery, put the mouse into the packaging box, and store it in a dry place.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

For Ergo Wireless Mouse-ASST

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

For Ergo Wireless Mouse-dongle

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

FCC ID: 2AHN6-MSWS135 FCC ID: 2AHN6-DE14

TROUBLESHOOTING

- If device won't connect, try the following:
- Be sure the power switch (located at the bottom of the mouse) is turned ON.
- Be sure the USB receiver is connected to your computer.
- Be sure the USB receiver is not damaged.
- Check your computer's input settings.
- Try new battery in the mouse.
- Restart your computer.

SPECIFICATIONS:

- Ergonomic wireless optical mouse
- Adjustable DPI: 800/1200/1600
- 6 buttons with scroll wheel
- No pairing required, Plug and Play via USB receiver
- 2.4Ghz USB receiver
- On/Off power switch
- USB receiver stores conveniently in battery compartment
- Supports Windows® 7-11 and Mac OS®

WARRANTY- 12 MONTH

Please visit our website Bytechintl.com/warranty

©2025 BYTECH NY INC.

BYTECH™ is a registered trademark of Bytech NY INC.

*All Trademarks and copyrights are the property of the respective companies.

*Mac OS® is a registered trademark of Apple Inc.

*Windows® is a registered trademark of Microsoft Corporation.

*Bytech NY Inc. has no affiliation to Apple Inc. or Microsoft Corporation, Inc.

*Photos are for illustration purposes only.

*Requires 1 (One) X AA 1.5V Alkaline Battery (N Included).

BYTECH

Contact Info:
2585 West 13th Street,
Brooklyn, NY 11223
Bytechintl.com

© 2025 BYTECH NY INC.



Made in China

WARNING: TO AVOID BATTERY LEAKAGE
1) Be sure to insert the battery correctly, and always follow the toy/game and battery manufacturers' instructions.
2) Always remove a weak or dead battery from the product.
3) Remove the battery if the product is left unused for a long period of time.