



warranty does not extend to damage or failure which results from misuse, neglect, accident, alteration, abuse, improper installation or maintenance. At any time during the 12 months period following the purchase, the product fails due to defects in material or workmanship, return the defective product (with freight prepaid) with proof of purchase.

2585 West 13th Street
Brooklyn, NY 11223
Bytechintl.com
©2026 BYTECH NY INC
MADE IN CHINA



- How to connect your item to Apple Find My
1. Open your Apple Find My app
 2. At the bottom of the screen, press ITEMS
 3. Press the "+" Button
 4. Select "Other Item"
 5. It will search for your tag
 6. Once it finds your tag, it will show you and ask you to press "Connect"
 7. It will ask you to Name your Tag - Enter a Descriptive name like "Car Keys" app on the map.
 8. It will ask you to Choose an Emoji - Press the Happy face and search or select an emoji below. Then press "Continue"
 9. It will display a message that your tag has been linked to your account. Press "AGREE"
 10. Finally, press "FINISH" to complete the process



- How to connect your item to Google Find Hub
1. Press button on tag
 2. Your phone will display a pop up to connect the tag - press Connect
 3. Your phone will display useful instructions on use - press Continue
 4. Your tag will be added to your Find Hub - Press Done or Open app

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING

INGESTION HAZARD: DEATH or serious injury can occur if ingested. A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as 2 hours.

KEEP new and used batteries **OUT OF REACH OF CHILDREN**. **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.


For treatment information call: [phone number for the National Battery Ingestion Hotline, currently 1-(800) 498-8666].

BYTECH®

SMART TAG



USER MANUAL



- Device Operation Instructions**
1. Power On - Press and hold the device button for 5 seconds until a confirmation chime sounds. The device will then power on.
 2. Check Device Status - Double-press the device button. If the device beeps, it is powered on. If there is no sound, the device is powered off.
 3. Pairing Mode Timeout - If the device is powered on but not paired within 10 minutes, it will automatically exit pairing mode. To re-enter pairing mode: Press the device button once, wait for the beep. Open the Find My or Find Hub app and follow the instructions to pair the device.
 4. Check Serial Number - Quickly press the device button six (6) times in succession. The device will beep to confirm the action.
 5. Factory Reset - Quickly press the device button four (4) times. Then press and hold the device button. When the device beeps, continue holding the button. Release the button after the second tone/music is played.
 6. Power Off - Quickly press the device button five (5) times in succession. The device will beep to indicate that it has powered off.
 7. Rebinding the Device - If you unbind the device from your phone, perform a factory reset before pairing it with a new phone.

- FAQ**
1. How do I confirm if the device is powered on?

Double-press the device button. If the device emits a sound, it indicates that the device is powered on and functioning normally. If the device does not respond, it is likely powered off. To power on the device, press and hold the button for 5 seconds until you hear a confirmation sound.

2. How do I replace the device battery?

Use a screwdriver to loosen the device screws by turning them counterclockwise, then gently pry open the housing from the gap. Remove the old battery and insert a new button battery, ensuring that the positive (+) side faces upward. Replace the back cover of the device and tighten the screws securely. Press and hold the power button for 5 seconds to turn on the device.

Notes

If the device is powered on but cannot be detected by Google Find Hub App, restore the device to factory settings. If the device still cannot be found, restart your phone and try locating the device again. The device cannot be paired with both iOS and Android simultaneously. If you dismiss the Fast Pair pop-up twice or frequently pair and unpair the device, the system may trigger a temporary Fast Pair restriction to prevent unnecessary pop-up notifications. To resolve this issue, either: Wait approximately 5 minutes for Fast Pair to be re-enabled, or Restart your phone. Some features described above are only supported on Android 12.0 or later.

Apple Find My Compatibility Notice

The "Works with Apple" badge indicates that this product has been designed to work specifically with the technology identified in the badge and has been certified by the manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or for the product's compliance with safety and regulatory standards. To locate this item using the Apple Find My app, it is recommended that you use the latest version of iOS, iPadOS, or macOS. The Find Items app on Apple Watch requires the latest version of watchOS.

Trademark Notice

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS, and watchOS are trademarks of Apple Inc., registered in the United

States and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Google Find Hub Compatibility Notice

This product has been certified by Google to meet Find Hub network accessory specifications. Google is not responsible for the operation of this product, nor for ensuring that the product complies with any applicable safety standards or regulatory requirements. The Find Hub network requires Location Services and Bluetooth to be enabled. A cellular service or internet connection is also required. The product works on Android™ 9 or later on select devices (phones or tablets) and may only be available in certain countries for age-eligible users. Trademark Notice Google, Android, and Find Hub are trademarks of Google LLC.

WARNING: KEEP BATTERIES OUT OF REACH OF CHILDREN

Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus. If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poison Information Centre for fast expert advice.

Rated voltage 3V
Rated current -15mA

Immediately dispose of used batteries and keep away from children. Do NOT dispose of batteries in household trash. Even used batteries may cause severe injury or death. Call a local poison control center for treatment information.

KEEP BATTERIES OUT OF REACH OF CHILDREN

Keep in original package until ready to use
Call a local poison control center for treatment information. Australia: 13 11 26 Canada: 1-800-268-9017(Ontario), 1-800-567-8911(BC), 1-800-463-5060 (Quebec) US: 800-498-8666.Verify suitable. emergency call numbers for your country. Do not use if the compartment is not secure. Dispose of used button batteries promptly and safely. Flat batteries can still be dangerous. European Union-Disposal Information The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

- a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- b) Even used batteries may cause severe injury or death.
- c) Call a local poison control center for treatment information.

- d) Battery type : CR2032.
 - e) Nominal battery voltage: 3 V.
 - f) Non-rechargeable batteries are not to be recharged.
 - g) Do not force discharge, recharge, disassemble, heat above60 °C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
 - h) Ensure the batteries are installed correctly according to polarity (+ and -).
 - i) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
 - j) Always completely secure the battery compartment.
- If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.
- k) Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries. Risk of fire and burns. Do not recharge, disassemble, heat (-20°C +70°C) or incinerate.

Article 12

Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery.

Article 14

The application of low power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists. The foregoing legal communication refers to the wireless telecommunication operated according to the telecommunications laws and regulations. The low power frequency electric machinery should be able to tolerate the interference of the electric wave radiation electric machineries and equipment for legal communications or industrial and scientific applications.

WARRANTY:

Bytech NY INC. warrants this product to be materially free from defects and workmanship to the original purchaser for a period of 12 months from the original purchase date. Bytech responsibility with regard to this limited warranty shall be limited solely to repair or replacement as its option. This