



SPINNING STUNT VEHICLE
WITH LED LIGHTS



THE BLACK SERIES™
radio controlled 360° rally car
turbo tumbler®

360°
WHEELIES



BOX CONTAINS
THE FOLLOWING
FREQUENCY:
☐ 27 MHz
☐ 49 MHz



radio controlled 360° rally car
turbo tumbler®

THE BLACK SERIES™

antenna provides
wireless control

LED lights

knobby grip tires
for jumps and
stunts



radio controlled 360° rally car
turbo tumbler®

360°
WHEELIES

WIRELESS
REMOTE CONTROL FOR FULLY
FUNCTIONAL RACING ACTION

COMPETITIVE
AVAILABLE IN 2 FREQUENCIES
FOR TWO PERSON PLAY

VERSATILE
EASILY PERFORMS STUNTS
AND WHEELIES



radio controlled 360° rally car
turbo tumbler®

stunts, wheelies & LED lights!



WARNING!
Do not use this product near water.
Batteries should be removed if the
product is not used for 30 days.

BATTERY
OPERATED
PLAY VEHICLE
BATTERIES NOT INCLUDED
AGES 6 AND UP

radio controlled 360° rally car turbo tumbler®

OPERATING INSTRUCTIONS

Operation requires 4 "AA" 1.5V alkaline batteries (not included) for car and one 9V battery (not included) for remote control.

1. Carefully remove items from package.
2. Locate the battery compartment on the back of each item (see diagram on right).
3. Switched latches on bottom of car to release battery pack and insert batteries.
4. Switch both car and remote buttons to "ON" position.
5. For best result use the car on hard surfaces such as wood or tile.

GENERAL CONTROLS

Reverse
Press both control sticks backward.

Forward
Press both control sticks forward.

Spinning Action
Press and hold the control sticks in opposite directions to make the car spin.

Action Button
Press and hold the action button to have the car stand up on its back wheels and move forward.

SPINNING ON REAR WHEEL (ACTION BUTTON)

1) Spin the car by pressing and holding the control sticks in opposite directions.

2) Press and hold the action button while the car is spinning.

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating car.
- Do not submerge car or controller in water.
- Never operate your car on the street or highway.
- Never operate your car in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON".
- Do not leave car or transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not leave car or transmitter outside overnight. Dampness is harmful to plastic components.
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is recommended when operating this car.

BATTERY WARNING:

- Do not use old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Insert batteries using the correct polarity. Do not short-circuit the supply terminal.
- Remove batteries when not in use. Recycle or dispose of exhausted batteries according to local, state, and federal laws. Do not dispose of batteries in fire. They may catch or explode.
- Only use manufacturer specified batteries (rechargeable and/or alkaline, if applicable, specified by the manufacturer).
- Always use, replace, and recharge (if applicable) batteries under adult supervision.

©2016 MerckSource, LLC. The Black Series, Thunder Tumbler and all associated logos are trademarks of MerckSource, LLC. All Rights Reserved. Distributed by MerckSource, LLC, Irvine, CA 92618. China Patent No. ZL20123022680.1 For technical support, please visit www.mercksource.com or call 1-800-314-2744.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

REMOTE CONTROL ASSEMBLY

USES ONE 9V BATTERY (NOT INCLUDED)

ON/OFF SWITCH

BATTERY DIAGRAM

USE ALKALINE BATTERIES FOR BEST PERFORMANCE

BATTERY PACK (NOT INCLUDED)