



BLUETOOTH SPEAKER USER'S MANUAL


LANG | EN



Packing content



Connection Diagram



Introduction

Thanks for choosing our bluetooth speaker. The manual will help you operate the Bluetooth Speaker, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Bluetooth Speaker.

Safety Rules

- 1 Please follow the rules depicted in this manual closely to ensure your safety. Before using this Bluetooth speaker, we would strongly encourage you to read through this user manual.
- 2 Be more wary of any edges, uneven surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage.
- 3 Do not modify, repair or dismantle this bluetooth speaker. Doing so may result in fires, electric shocks, complete breakdown of this Bluetooth speaker, etc. All of which, are not covered under warranty.
- 4 Do not use any diluents or volatile liquid to clean the Bluetooth speaker.
- 5 Do not use the Bluetooth speaker in a hazardous location.

How to use

General Functions

Desired Result	Required Action
Turn on & Enter pairing mode	Press the button to the right
Pairing	You should use a Bluetooth function mobile phone or other Bluetooth device and to perform pairing action
Turn off	Press the button to the left
Charging	Plug the Micro USB cable to port of the device
USB flash memory	Insert the USB flash with Mp3 format files inside
TF card memory	Insert the TF card with Mp3 format files inside slot
FM radio	Long press the wheel control switch to FM channel

Pairing to Mobile phone or other device

To use your Bluetooth speaker, you must first pair your speaker with a phone or a computer. Once your Bluetooth speaker is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

Pairing to a phone and Entertainment:


- Turn on your phone and ensure its Bluetooth function is activated
- Turn on the speaker go to the pairing mode.
- Search your Bluetooth devices on your phone by following the phone's user manual for more information.
- After a few seconds the phone will list the "Bluetooth speaker" as a discoverable device. Select it and follow your phone instruction to select this pairing.
- Your phone will confirm the pairing, and then press Yes/OK.
- Finally, select to connect with round speaker from your phone
- You can play music: watch TV/movie and play game with your phone, then you can hear all the sound or music from the speaker. Also you can control the player by operating the speaker. Example, volume up and next music

Pairing to computer and entertainment

If there is no Bluetooth function supported by your computer, a Bluetooth adapter is necessary. Fix the adapter with your computer and ensure its Bluetooth function is activated. Turn on the speaker go to pairing mode. Open the Bluetooth software (such as BlueSoleil) installed on your computer, and select "Search your Bluetooth devices" function. Refer to user manual of the Bluetooth software for more information. After a few seconds the "Bluetooth Speaker" will list in Bluetooth software of your computer as a discoverable device. Select this icon and click right button of mouse to select "pairing" item, then select "connect with audio device" with same operation. Open your media player software to play music, watch TV/movie and play game, then all the sound will be playback on your speaker.

Charge your speaker

The speaker is convenient to connect to Mini USB charger with Mini USB port marked with . Make sure that your speaker is fully charged for at least 6 hours before initial use. Insert one terminal of your charger to USB port of PC and other terminal to Mini USB cable.



Warning:

You must select a qualified charger from a regular manufacturer.
You must charge the Bluetooth speaker if it has been not used for more than 1 month.

Product Specification

Parameter	Value
Driver Diameter	40mm
Impedance	4 Ohms
Bluetooth Version	2.1
Battery Capacity	800mAh
Bluetooth range	10m
Support	Bluetooth USB flash memory TF card memory Line-in Earphone output FM radio

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.