


MOCUTE GAMEPAD

Operation Manual

Model: MOCUTE-054



Many thanks for purchasing our product! This is a portable wireless gamepad, used for mobile phone, MID, TV box, smart TV, PC and so on. It is supported iOS, Android, Windows operate system and so on.

Important Note: Products are subject to change without any notice. And this product has applied for patents, counterfeiting!

Operating instructions:

- **Power** Press Power button until Work LED is on (about 2 seconds). Default is stand automatic mode.

Power on mode changing instruction
(please operate when power off)

Stand automatic mode: Press A button, then press POWER to power on, Work LED will be flash with blue. now is standard mode! when connected with Android equipment then it is stand Android mode; when connected with iOS equipment, then change to iOS iCade mode.

Android MTK mode: Press Y button, then press POWER to power on,

Work LED will be flash with blue. now is Android MTK mode!

iOS NEWGAME mode: Press X button, then press POWER to power on, Work LED will be flash with blue. now is iOS NEWGAME mode!

iOS iCade mode: Press B button, then press POWER to power on, Work LED will be flash with blue. now is iOS iCade mode!

Remark:

(1) After use the specified mode one time, then press POWER button to power on next time, gamepad will default specified mode before. If need shift to other mode, please refer to above power on mode.

(2) Under standard automatic mode, when connected with Android equipment, it is stand Android mode; when connected with iOS equipment, then change to iOS iCade mode automatically.



● Pair and connect

After power on, Work LED will flash, the device will enter into the wireless pair mode automatically to find the address and name of this device (MOCUTE-054-XXX), click then can connect. Pair and connect successfully, Work LED will turn off. Next power on, it can connect and match the last wireless device automatically. Under turn off state, long press START button more than 8 seconds, Work LED will flash, then go to pair mode again, and can't connect last paired device automatically.

● Power off

Long press POWER button, Work LED light will flash to off (about 5 seconds), gamepad will power off.

Note: If no connecting with wireless device after 5mins, gamepad will power off automatically; after connecting with wireless device, if no any operation, gamepad will power off after 30mins .

GAME instructions:

● Standard Android device (A mode)

In Menu, if left joystick can move cursor, A&X button is enter button, B&Y button is returning key; this means your mobile system can support international standard gamepad, just download game and play directly.(If can't operate, then refer to part of Android MTK mobile operation)

Game Download: scan QR code on the manual(or go website: <http://www.migamepad.com>)to enter into MIGAMEPAD download center, then you can download Newgame or Migamepad game application or third party's game application. e.g. Newgame platform: after entering the Newgame application need to check the menu -gamepad management. whether the connection is successful, you can direct play games in the Newgame center. the m key is i key functions in the Newgame. Note: Newgame application will automatically connect to the Newgame protocol, if change to the other platform operation, please press the HOME button of phone, exit the Newgame platform.MIGAMEPAD Game center have all gamepad games, and support NES/GB/GBC/SFC/SMD/GBA/N64/MAME/PS games. Users can also download simulator BIN files to Games file folder in mobile, then can use MIGAMEPAD software to open the game file, like many famous games: Super Mario, Metal Slug, Sangokushi and so on.

● Android MTK/PC device (Y mode)

Like Redmi 3G version, Huawei Honor3X, CoolPAD, Zhongxing etc, these old style mobiles use MTK CPU, due to MTK bad compatibility,they can't support international standard gamepad agreement. So if by standard Android connection method, unusual problems will happen. We preset MTK mode to support MIGAMEPAD games.In this mode, the output for the keyboard letters, can be used to set the game on the PC function.

● Android/iOS VR mode (A mode)

With this mode just for BaoFeng or other VR application ! A is enter button, B is return button, X is menu button, left joystick can move cursor in menu of the app, when playing video with left joystick, up is volume+, down is volume-, left is fast rewind, right is fast forward. (Note: in iOS BaoFeng VR App must be set gamepad is MOCUTE option.

● iOS iCade mode (B mode)

Enter into APP store or other Apple store, search "iCade", then you can find games of iCade which support gamepad, download and install then ok. like Akane Lite, Brotherhood, TTR Premium and so on.
Before play games, please set keyboard input mode to English input and can input English letters then ok (Some games maybe need set to use iCade when playing).

● iOS NEWGAME mode (X mode)

Scan QR code on the manual to download NEWGAME Application! then you can use the gamepad to play games in the APP! e.g CF or Herok etc.
Mode m key is i key function.

Additional function:

● Android device

after connected with wireless, pressing MODE KEY, is NEWGAME i key function. Press m key more than 3 second, Mode LED will be long on, additional function start!

Right joystick = mouse

L1/R3=left key of mouse

R1=right key of mouse

L2=volume- R2=volume+ A/L3=enter B=return Y=home

If open the music/video player

START=play/pause Arrow keys right=next Arrow keys left=prev

Arrow keys up = fast forward Arrow keys down = rewind

when connected with gamepad, the soft keyboard can't work, we can use QR code software to scan QR code on the manual to enter into MIGAMEPAD download center, then download XunFei Input and use this. now the soft keyboard can work! just for Android device!



● iOS device

after connected with wireless, pressing MODE KEY, is NEWGAME i key function. Press m key more than 3 seconds, Mode LED will be long on, additional function start!

now L2=volume- R2=volume+ B=home function

if open the music player or Videos APP

START=play/pause Arrow keys right=next Arrow keys left=prev

Arrow keys up=fast forward Arrow keys down=rewind

pressing MODE KEY again, Mode LED off, additional function stop.

when connected with gamepad, if soft keyboard can't work, hitting MODE KEY can set soft keyboard working! but just for iOS device!

Charge:

Our product is with inner rechargeable lithium battery, when power is low, Work LED will flash with red. Please insert 5V USB port to charge! Work LED will be long on with red. And when power is full, Red LED will be off.

Notes:

- ①When accident cause not boot or unable to shutdown, please use needle to press Reset button.
- ②If can't connect, please press B+Y+Power to boot and power off, then boot the device and connect again.

Product Specifications:

Items	Specifications
Machine model	MOCUTE-054
Product size	158*110*52mm
Wireless protocol	Wireless 3.0 compliant
Wireless distance	2-10M
Support system	Android、iOS、PC
Battery	Rechargeable Li-3.7V 400mA
Continuous game time	about 40 hours
Working current	0.5-8mA



Scan the QR code to get more details, helps and game resources!

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.