

LATEST AND GREATEST

Our team is constantly improving your product experience.
This model may have new features or controls which are not detailed in this guide.

For the latest version of the manual, scan the QR code below.



Distributed in U.K. by: JLab c/o Tiogo Limited
21 Headlands Business Park, Ringwood,
Hampshire BH24 3PB United Kingdom
EU Importer: JLab
5927 Landau Ct., Carlsbad, CA 92008
USA

WITH LOVE FROM THE LAB

We have lots of different ways to show we care.

GET STARTED + FREE GIFT

Product updates | How-to tips | FAQs & more
Go to jlab.com/register to unlock your
customer benefits including a free gift.

Gift for US only. No APO/FPO/DPO addresses.

Instructional videos at:
HELP.JLAB.COM
or INTL.JLAB.COM/MANUALS

WE GOT YOUR BACK

We're obsessed with creating the best possible experience
around owning our products. If you have any questions,
concerns, or feedback, we're here for you. Contact a real
human on our U.S.-based customer support team:

Website: jlab.com/contact
Email: support@jlab.com
Phone U.S.: +1 (405) 445-7219
(Check hours jlab.com/hours)
Phone U.K./EU: +44 (20) 8142 9361
(Check hours jlab.com/hours)

Visit jlab.com/warranty to initiate a return or exchange.

FCC ID: 2AHYV-FLOWKB
2AHYV-FLOWM
2AHYV-MKDGLC
IC: 21316-FLOWKB
21316-FLOWM
21316-MKDGLC



WELCOME TO THE LAB

The Lab is where you'll find real people, developing really great products,
in a real place called San Diego.

PERSONAL TECH DONE BETTER

Designed for You
We actually listen to what you want and
we're always looking for ways to make
everything easier and better for you.

#yourkindoftech
Tech all about you

Surprisingly Awesome Value
We always pack in the most
functionality and fun into every
product at a truly accessible price.

TROUBLESHOOTING

- If your device is not connecting to Bluetooth, forget the Flow Keys or Flow Mouse in your device settings.
Turn device off and on. Press and hold for bluetooth connection until blinking blue light indicates pairing
mode. Reenter your device settings to re-pair.
- If the USB dongle is not registering keyboard:
 1. Remove dongle
 2. Press Fn + 1 to enter 2.4G connection
 3. Press + hold CONNECT button until green light blinks quickly
 4. Plug dongle back in
- If the USB dongle is not registering mouse:
 1. Remove dongle
 2. Quick press Connect button until LED blinks green to indicate 2.4G mode
 3. Press and hold Connect button until green light blinks quickly
 4. Plug dongle back in



FLOWKEYBOARD
+ **FLOW**MOUSE


QUICK START GUIDE



CONNECT WITH DONGLE


1

Remove pull tabs, batteries
already installed in both devices




2

Switch both devices on



3


Install 2.4G USB dongle



CONNECT MOUSE WITH BLUETOOTH



1

SWITCH CONNECTION:
Quick press button
(Light switches to associated connection)



2


PAIRING
Press and hold button to enter pairing mode
Select "Flow Mouse" in device settings



CONNECT KEYBOARD WITH BLUETOOTH



1

SWITCH CONNECTION:
Quick press Fn + F1 or F2
(Light switches to associated connection color)



2

PAIRING
Press hold Fn + F1 or F2 to enter Pairing Mode (Blinking light)
Select "Flow Keys" in device settings



KEYS / CONTROLS

Fn + F1-F12:
Shortcut keys (see Shortcut Keys list)



Custom Keys
Set commands using desktop app



MEDIA DIAL
Vol +/- : Rotate
Play/Pause: Single press
Track Forward: Double press
Track Back: Press and hold

Fn + Right Shift:
Lock / Unlock Fn key
(See Shortcut Keys)



SHORTCUT KEYS

Fn +	MAC	PC	Android
Esc	N/A	Homepage	Homepage
F1	Brightness -	Brightness -	Brightness -
F2	Brightness +	Brightness +	Brightness +
F3	Task Control	Task Control	N/A
F4	Show Applications	Notification Center	N/A
F5	Search	Search	Search
F6	Desktop	Desktop	N/A
F7	Track Back	Track Back	Track Back
F8	Play/Pause	Play/Pause	Play/Pause
F9	Track Forward	Track Forward	Track Forward
F10	Mute	Mute	Mute
F11	Screenshot	Screenshot	Screenshot
F12	Dashboard	Calculator	N/A
Delete	Screen lock	Screen lock	Screen lock