


TEST SETUP PHOTO(S) - 110 VAC/60Hz POWER SUPPLY



TEST SETUP PHOTO(S) – EUT POSITION FOR FREQ< 1GHZ




TEST SETUP PHOTO(S) – EUT POSITION FOR FREQ > 1GHZ



TEST SETUP PHOTO(S)



TEST SETUP PHOTO(S) – FREQ < 200MHZ



TEST SETUP PHOTO(S) – 200MHZ < FREQ < 1GHZ



TEST SETUP PHOTO(S) – 1GHz < FREQ < 18GHz



TEST SETUP PHOTO(S) – 18GHz < FREQ

