

cromā



Bluetooth Speaker

model name:CRER2090,BT-022

Brand name:CROMA,SOUNDREVO

USER MANUAL

BEFORE OPERATING THIS PRODUCT, PLEASE READ AND FOLLOW INSTRUCTIONS.

Please retain Copy of your purchase receipt to authenticate product warranty.

* Picture depicted is only for illustration purpose actual product may differ.

Manufacture:Shenzhen SIGMA TRANSCEND., LIMITED

INDEX

1. Important safety instructions
2. E-waste Management (Disposal Policy)
3. Copyright Statement
4. Product Features
5. Package
6. Know your product
7. How to use your product
8. Warranty card
9. Warranty terms and conditions

SAFETY INSTRUCTIONS



WARNING:

- Please read the instruction manual carefully before using the product. Keep the user manual safely for future reference.
- Do not expose the product to fire, moisture and direct sunlight.
- Do not attempt to disassemble the product on your own.
- If you observe any deformity in the product, such as dents or puncture, immediately get in touch with Croma customer care at 7207-666-000.
- Do not attempt to power on the product other than the one as mentioned in this manual.
- Do not overcharge the battery as this may shorten its life.
- If you observe any foul smell coming out of the unit, please contact Croma customer care at 7207-666-000.
- Don't attempt to service the product on your own, as this may expose you to potential electric shocks and hazards and void your warranty claim.
- It is advisable to unplug it from the electric power point if not used for a prolonged time.
- Ensure that ventilation holes provided on the unit are free from any obstruction as it may result in overheating of the product and damage the circuits.
- In case of any product servicing required, please contact a Croma certified service personnel or a Croma Authorized Service Centre.
- Please ensure the product is fixed on a stable and even surface or wall mounted for safety of the product.
- Don't use any accessory which is not compatible with the product, as this may result in malfunctioning of the product and void your warranty.
- Periodically replace battery for proper operation of the remote and ensure correct polarity while inserting the batteries.

E-WASTE MANAGEMENT (DISPOSAL POLICY)



■ This Symbol on the products and/or accompanying documents means that used electrical and electronics products should not be mixed with general household waste. For proper treatment, recoveries, recycling, please take these products to designated collection points, where they will be accepted on a free of charge basis.

Alternatively, you may be able to return your products to CROMA CARE CENTRE upon purchase of an equivalent new product. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.

Please contact Croma Care centre at 7207-666-000 for further details on your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with the Indian legislation.

COPYRIGHT STATEMENT

- The product name mentioned in this manual only serves for identification of its features and functions of the product, and they may be registered trademarks or copyrights of other company's products / brands. Hence the following statement:
 - CROMA logo is a registered trademark.
 - The rest of the companies, products, or service names involved in this manual may all be the trademarks or service logos of the relevant holders.

PRODUCT FEATURES

PRUCT FEATURES

1. 5W x 2 Watts RMS Audio output
2. Built-in 3.7V 1000mAh rechargeable Li- Ion battery
3. USB interface and TF Card for music playback
4. Line - in input for connecting external audio device


PACKAGE

Note: You will find the following Three components when opening the package as illustrated below. In case if you find any of the below mentioned components missing, immediately contact Croma Customer Care.

Package

- Bluetooth Speaker x 1
- Micro USB cable x 1 (For charging the Speaker only)
- Instruction Manual and warranty card x 1

KNOW YOUR PRODUCTS



HOW TO USE YOUR PRODUCTS

Charge your product:

- Before using the product for the first time, please charge the product fully.
- Battery charging mode: Red LED remains steady, once fully charged LED turns off.
- Use the supplied micro- USB cable to charge the product.
- You can charge the speaker from a 5V DC USB adapter not supplied along with the product.

Bluetooth mode :

1. Switch the Power On/Off button to On mode, the unit will turn ON. You will hear voice "Power On, Bluetooth mode". The Speaker is now in Bluetooth pairing mode.
2. Turn on the Bluetooth function and search for CRER2090 speaker on your mobile phone, tablet Select CRER2090 and tap to pair your device to the speaker. After successful pairing, you will hear the voice" pairing successfully" and the LED indicator will become steady. You can start playback now.
3. In case a password is required, type "0000" on your mobile/device.
4. The speaker will automatically detect and reconnect to the last paired device.

Aux-in/TF card/ USB mode:

1. Switch the Power On/Off button to On mode, connect the 3.5mm cable with your device/ plug in USB disk/ plug in TF card . You will hear the voice "Aux mode" / "USB mode" / "TF card mode", then you can playback the music.
2. Press and hold the mode button ~ 2 sec to switch between Bluetooth / AUX / TF card and USB mode. The device will auto recognize the input source and playback.

LED Indicator at different modes:

1. The Blue LED flashing - the speaker is under pairing mode
2. The Blue LED On - the speaker already paired / Aux mode / USB mode / TF card mode
3. Battery charging mode: Red LED remains steady. Once fully charged, LED turns off.

Microphone Function:

This product has a built-in microphone for receiving phone calls, while your mobile phone is paired with the speaker system.

If you wish to receive phone calls on the Bluetooth speaker, press the Play button once. If you don't wish to receive calls on the speaker system, you can reject them on the phone and the music will turn in to pause mode.

Caution:

1. Always Turn Off power before removing TF card or USB Stick
2. Avoid using the speaker while it is in charging mode
3. When you hear voice "low battery" please recharge the speaker.

WARRANTY

cromā

WARRANTY CARD

Type of Product: Bluetooth Speaker

Model No.: CRER2090 Purchase Date: _____

Product Purchased from: _____

Receipt Invoice Number: _____ Serial No: _____

Your Name: _____ Tel #: (_____) _____

Address: _____

If you are experiencing difficulty operating this product or require service assistance please contact:

Customer Care Manager

Infiniti Retail Limited

Unit No 701 & 702, 7th Floor, Kaledonia, Sahar Road, Andheri (East) Mumbai - 400 069, India

Customer Care Number: 7207-666-000SMS: "CROMA" to 56677 Email: customersupport@croma.com

Please retain this form along with your receipt to avail the warranty/services

WARRANTY INSTRUCTION

1. Infiniti Retail Limited, ("IRL") guarantees the product purchased by you to be free from defects resulting from the use of faulty parts or poor workmanship during its manufacture subject to terms of the limited warranty ("Warranty") given below .
2. Warranty Period
 - a. This warranty is applicable for a period of Twelve (12) months from the date of invoice/purchase of the product.
 - b. In case of commercial usage of the product, warranty period would be limited to 90 days only.
3. Claim
 - c. The claim will have to be made within the warranty period
 - d. IRL will repair or replace any defective parts/ product and correct any problems resulting from inferior workmanship free of charge.
 - e. Service to the product shall be carried out on a carry in basis wherein the customer has to carry the product to the stores from where the product was purchased at the purchaser's risk, responsibility and cost.
 - f. While the Company will make every effort to carry out necessary repairs at the earliest, the Company is under no obligation to do so within a stipulated time period.
 - g. Claims, if any, to this warranty shall in no case exceed the purchase price of the product.
 - h. In case of repairs or replacement of any part(s) of the product, this warranty will thereafter continue and remain in force only for the remaining period of the warranty. Replacement of parts would be purely at the discretion of the Company alone. In case the replacement of the entire product is being made (subject to the sole discretion of the Company), the same model will be replaced and in the event such model has been discontinued, it shall be replaced with the model of price equivalent at the time of purchase.
 - i. Replacement criteria from warranty terms do not stand if "No problem found" type diagnosis is found and perceived intermittent errors that cannot be reproduced are noticed.
 - j. The concerned authorized technician will advise whether to affect repairs at the site or at the Croma customer care.
 - k. This warranty will be terminated automatically after the period of 12 months from the date of purchase even if the product was not in use for any time during the warranty period for any reason.

4. This warranty shall be rendered null and void if:

- a. The product is physically damaged.
- b. The product is modified, maintained or repaired by a party not authorized by IRL.
- c. The product is installed, maintained and operated in ways other than as recommended by IRL.
- d. The product is faulty or damaged due to electrical faults external to the product.
- e. Malfunctions or damages resulting from natural calamities, fire, civil unrest and/ or accidents.
- f. The model number, serial number or warranty stickers have been removed or tampered with.
- g. A non-IRL certified product is added on to the IRL product.

5. Warranty limitations

- a. The warranty is not transferable from one user/customer to another.
- b. IRL's warranty does not entail a warranty of functionality or any obligation to repair or replace a defective product, if that defect is a result of physical breakage, improper installation or connections, electrical faults external to the product, abuse or unauthorized modification of the product.
- c. Any service, repair or replacement not within the scope of IRL's coverage shall be subject to the rates and terms of Croma customer care.
- d. All third party peripherals, whether purchased as part of a system or bundled with it, normally come with the prevailing supplier's warranty and IRL does not provide warranty for such products.
- e. This warranty is only applicable if the product is purchased from IRL (Croma) or any of its authorized resellers.

6. This warranty is not applicable in following cases:

- a. The warranty card is not completed fully at the time of purchase of the product.
- b. The warranty card is not presented to the authorized technician at the time of the service of the product.
- c. The serial number of the product is deleted, defected or altered.
- d. Accessories.
- e. Plastic parts.
- f. Parts requiring replacement due to normal wear and tear, corrosion, rust, stain, etc.,
- g. Defects or damage caused due to
 - i. accidents, mishandling, negligence; or
 - ii. transportation or shifting; or
 - iii. improper or reckless use, which will be determined by the authorized technician of the Company; or

- iv. not used in the manner specified in the manual; or
- v. tampering, breakage; or
- vi. lightening, fire or natural calamities or Force Majeure; or
- vii. abnormal voltage or faulty electric or power connections or poor/faulty electric or power wirings; or
- viii. lack of supervision or lack of proper care or everyday maintenance; or
- ix. Improper storage and poor environment conditions.

7. Disclaimer:

Except for the warranties set forth herein, IRL disclaims all other warranties, express or implied or statutory, including, but not limited to the implied warranties of merchantability or fitness for a particular purpose. Any implied warranties that may be imposed by applicable law are limited to the duration of this limited warranty. In no event shall IRL be liable for any incidental, special or consequential damages, consequential human injury or loss, including, but not limited to loss of business, profits, or use whether in an action in contract or tort or based on a warranty arising out of or in connection with the use or performance of the product.

- 8. The customer agrees that repair or replacement, as applicable; under the warranty services described herein are the sole and exclusive remedies with respect to any breach of the IRL limited warranty set forth herein.
- 9. If any provisions on this limited warranty are judged to be unenforceable or illegal, the continuation of the other provisions will not be affected. This warranty will also not affect the customer's statutory right under applicable Indian laws.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.