

2. Please choose the charger that is certified by the regular manufacturer.
3. The battery performance may decrease as repeating charging and using the speaker. It's a normal phenomenon for all rechargeable batteries.
4. The power LED lights up red when charging and goes off when charging is complete.

Bluetooth speaker parameters:
Output power: 4.5dBm
Battery: 3.7V/2000mAh
Play time: 6H(Medium volume)
Charging time: 4H
Support: BT,TF
Wireless working range:10M(without obstacles)
Input voltage: DC5V/1A
Charging method: Type-C
Net weight: 483g
Product size: 100*100*138MM
Material: ABS+Fabric

5

Bluetooth speaker x1

Type-C Charging Cable x1

Wireless microphone*1

User manual x 1


Certificate of quality x1

Microphone Sensitivity: -42db
Microphone battery: 3.7V/500mAh
Wireless connection mode: 2.4G
Charging method: Type-C
Microphone size: 150*33.3MM
Input voltage: DC5V/500mA
Material: ABS+PC

Turn on the Bluetooth speaker and microphone will automatically match, match the successful microphone indicator blue light stable

6

- 1.Previous/Volume -
- 2.Next/Volume +
- 3.Play/Pause and Mode switching
- 4.Power button/ Light mode switch
- 5.TF card port
- 6.Charging port



2



1. Please follow the instruction to operate.
2. Please charge the product with input power below 5V/1A, in order to protect the battery;
3. Please do not use this product in the near water. Do not immerse this product in any liquid

7

1. Long press the power button for three seconds to turn on;
2. Long press the power switch for three seconds to turn off.

1. Turn on the Bluetooth speaker, the breathing light flashes slowly.
2. Then active the Bluetooth of your phone and search for "HAVIT SK894BT". Click manually to connect.
3. Since the speaker can automatically reconnect to the last paired device, When the Bluetooth of your device turns on, (Just turn on the speaker), it will automatically reconnect.

Long press play/pause button to select mode.
(Bluetooth /TF card)

Short press the power button to switch the light

3

2. Long press the "-" for PREV;
3. Long press the "+" for NEXT;
4. Short press the "-" for VOL -;
5. Short press the "+" for VOL +.

4

Any changes expressly or modifications not approved by the party responsible for compliance could void the user's authority to use the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device must not cause harmful interference,
- and (2) this device must accept any interference received, including interference that may cause undesired operation.

Use of this equipment near other equipment may result in interference with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to residential reception.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off or on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and operated in conjunction with any other antenna or transmitter.

For Bluetooth speaker

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



www.havit.hk

8