

Label Location Information

3.3V Label



5V Label



EUT (Affix to shielding case)

