



SAR Test Setup Photographs

EUT Side Definition		
Mode	Side	
1	Side 1	
2	Side 2	
3	Side 3	
4	Side 4	
5	Side 5	
6	Side 6	
		



Phantom Position : Flat_SIM1	EUT side : 1
Spacing to phantom : 10 mm	Accessory : N/A




Phantom Position : Flat_SIM1	EUT side : 2
Spacing to phantom : 10 mm	Accessory : N/A




Phantom Position : Flat_SIM1	EUT side : 3
Spacing to phantom : 10 mm	Accessory : N/A




Phantom Position : Flat_SIM1	EUT side : 5
Spacing to phantom : 10 mm	Accessory : N/A




Phantom Position : Flat_SIM1	EUT side : 6
Spacing to phantom : 10 mm	Accessory : N/A




Phantom Position : Flat_SIM2	EUT side : 1
Spacing to phantom : 10 mm	Accessory : N/A




Phantom Position : Flat_SIM2	EUT side : 2
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat_SIM2	EUT side : 4
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat_SIM2	EUT side : 5
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat_SIM2	EUT side : 6
Spacing to phantom : 10 mm	Accessory : N/A

