


USER INSTRUCTIONS


- Open the package



- Knowing your device




- Installation Steps




- Download APP from Google play or iTunes

Operating temperature: 0°C to 50°C



iPhone



Android

FCC Statements :

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy .However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

MODIFICATION : Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the device .

Disposal of the Batteries

You, as the end user, are legally obliged to return all batteries to the collection points in your community or anywhere where batteries are sold.

Caution

1. Replace only with the same or equivalent type of battery, please refer to the engraved battery mark inside the battery compartment for the correct battery polarity (+) and (-).
2. Danger of explosion is possible if battery is incorrectly replaced.
3. This is non-rechargeable battery, do not recharge it!

CAUTION:

PLEASE KEEP THE BATTERY AND STICKY PADS OUT OF REACH OF CHILDREN.

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS