



WIRELESS SPEAKER



Model: BT220

INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY & RETAIN FOR FUTURE USE

IMPORTANT SAFETY INFORMATION

1. Read all instructions before using this product.
2. Do not leave this product unattended while connected to the power supply.
3. Do not immerse in water or any other liquids.
4. Do not use if unit has been dropped or damaged in any way.
5. Improper repairs may place user at serious risk.
6. Repairs to electrical equipment should only be performed by qualified personnel.
Place unit on sound, even surface, free of vibrations and away from sources of heat.
7. Do not put objects into openings.
8. Do not use this unit for anything other than its intended use.
9. Keep this product out of reach of children.
10. This product is not a toy.
Do not play music at excessive levels especially near children, as damage to hearing may occur.

Getting Started

Remove the unit from the box. Remove any packaging from the product.

Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

Portable Wireless Speaker --1PC
Type-C charging cable --1PC
Instruction manual --1PC

Features

1. Wireless Bluetooth connectivity to iPad, iPod Touch, Android, Windows Phone, Blackberry, smartphones, tablets, computers and more.
2. Play music through Bluetooth
3. FM Radio
4. Rechargeable built-in battery

Bluetooth Connection:

POWER SWITCH to turn on the speaker until there is notice voice.

Then it's ready to pair. Turn on the Bluetooth on your devices to add, search or scan for devices, select "**BT220**". Enter passcode "0000" if it asks. Voice notice appear when connected successfully.

Charging:

Plug the USB cable into the speaker's charging port and connect to the power source. The RED LED indicator will be on when the unit is charging and will be off when full charge.

How to use True wireless stereo function:

If have 2 units for BT220 speaker. Turn on both units, and double press "  " button ,you will hear "BEEP" sound and units will connect with each other automatically .

double press "  " button again to cancel TWS connecting.




Note: True wireless stereo function only .

Specifications

Bluetooth version	Bluetooth 5.3
Drive size	32mm
Wireless rang	32.8 ft
Built-In Battery	500mAh
Charging time	2-3 hours
Playback time	1-2 hours
Frequency response	100Hz-18KHz
Sensitivity	>80dB

(Note: Battery life & charging time may vary based on usage & types of devices used.)

Description of Parts:



Item	Function	Operation
1		Long press : POWER ON/OFF Short press : Change mode to FM/BT
2		Short press: Previous Song in BT mode / Previous channel in FM mode Long Press: Volume decrease
3		Short press: Play/Pause Double press: TWS function Long press: Searching channel Automatically in FM mode
4		Short press: Next Song in BT mode / Next channel in FM mode Long Press: Volume increase
5	 DC-5V	Charging port

FCC Warning

15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Warning Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment can be used in portable exposure conditions.