


2
PLAYER
ACTION!

VERSATILE
BUILT-IN SPEAKER WITH
INTERACTIVE SOUND EFFECTS

WIRELESS
OPERATE YOUR SUMO WARRIOR
VIA WIRELESS REMOTE CONTROL
FOR FULL-FUNCTION WRESTLING

COMPETITIVE
PUSH AND SHOVE YOUR WAY TO
VICTORY BY KNOCKING YOUR
OPPONENT OVER



Twin nested wheels
propel sumo wrestlers
in all directions

move your player to
shove and knock
over your opponent

includes dual remote
controls for wireless
wrestling matches



THE BLACK SERIES

THE BLACK SERIES™



sumo king wrestling
wireless head-2-head RC fighters



BATTERY
OPERATED
PLAY WRESTLERS
AGES 6 AND UP

WARNING!
CHOKING HAZARD - Small parts.
Not suitable for children under 3 years.

2
PLAYER
ACTION!

THE BLACK SERIES™

sumo king
wrestling
wireless
head-2-head
RC fighters



sumo king wrestling
wireless head-2-head RC fighters



THE BLACK SERIES™

sumo king
wrestling
wireless head-2-head
RC fighters



BATTERY WARNING:
• Do not mix old and new batteries.
• Do not mix alkaline, nickel-cadmium, or rechargeable batteries.
• Insert batteries using the correct polarity. Do not short circuit the supply terminal.
• Remove batteries when not in use. Remove or disconnect all batteries according to safety rules and local laws. Do not dispose of batteries in fire. They may catch on fire.
• Only use manufacturer specified batteries. Unapproved and/or damaged batteries are prohibited.
• Always use, replace, and recharge (if applicable) batteries under adult supervision.
KEEP THIS INSTRUCTION SHEET FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.



1003656 (2300963)
6 94262 928018
Made in China

OPERATING INSTRUCTIONS

Each wrestler requires 3 "AAA" 1.5V batteries (not included). Each remote control requires one 9V battery (not included). When charging batteries, adult supervision is required. Use alkaline batteries for best performance.

1. Carefully remove items from the package.
2. Locate the battery compartment on the inside of each wrestler, as well as each remote.
3. To remove wrestler battery chamber, twist base counter-clockwise until loose.
4. On wrestler, loosen the screws and remove battery door. Slide doors open on rc units.
5. Insert "AAA" batteries inside wrestlers, while observing the correct polarity in each compartment (see diagram). Insert one 9V battery into each remote control.
6. Replace the battery doors and tighten screws.
7. Switch wrestler and remote control power switches to the "ON" position. The power switch is located on the bottom of the wrestler.

NOTE: For best results, operate wrestlers on hard surface.



TURN LEFT/TURN RIGHT
FORWARD / BACKWARD
POWER ON / OFF

HOW TO PLAY

The object of the game is to knock the opposing wrestler out of the ring for circles by making contact with the player's body, thus thrusting the wrestler forward by sheer force.