2302312

Black
Cyan
Magenta
Yellow

RALLY STOMPER

RC CONTROLLER STICKER

TRUCK DOOR STICKER (LEFT & RIGHT)

35cm x 20,3cm x 20cm

VERSATILE
OFF-ROAD RACING PLUS LED LIGHTS FOR DRIVING IN THE DARK

COMPETITIVE
AVAILABLE IN 2 FREQUENCIES FOR TWO PERSON PLAY

WIRELESS
REMOTE CONTROL FOR FULLY FUNCTIONAL RACING ACTION

8 LED LIGHTS

SEE BOTTOM PANEL FOR COMPLETE OPERATING INSTRUCTIONS

KEEP THIS PACKAGING FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Requires five AA (1.5V) batteries (not included) and one 9V battery (included). Colors and styles may vary.

4 spring-loaded shocks

knobby grip tires for all-terrain racing

flashing LED lights

multi-directional operation

THE BLACK SERIES™

radio controlled all-terrain vehicle

rally stomper™

THE BLACK SERIES™

SPRING-LOADED SHOCKS FOR OFF-ROAD ACTION!

AVAILABLE IN 2 FREQUENCIES!

BOX CONTAINS THE FOLLOWING FREQUENCY:

☐ 27 MHz
☐ 49 MHz

DX2016B
Toy RC Truck

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP

⚠ **WARNING!**
CHOKING HAZARD- Small parts. Not suitable for children under 3 years.

TWO FREQUENCIES FOR COMPETITIVE RACING

SPRING-LOADED SHOCKS FOR OFF-ROAD ACTION!

radio controlled all-terrain vehicle

rally stomper™

four spring-loaded shocks for off-road action

THE BLACK SERIES™

radio controlled all-terrain vehicle

rally stomper™

8 LED LIGHTS

radio controlled all-terrain vehicle

rally stomper™



BATTERY INSTALLATION

The truck requires 5 "AA" 1.5V batteries (not included). The controller requires 1 9V battery (included). When changing batteries, adult supervision is required. Use alkaline batteries for the best performance.

- Carefully remove items from the package.
- Locate the battery door on the bottom of the truck. Using a Phillips screwdriver, loosen the screw.
- Pull the latch on the door to the left and lift up to access the battery compartment. Insert 5 "AA" batteries while observing the correct polarity (Fig.1).
- Replace the battery compartment door.
- Locate the battery cover on the back of the controller. Slide down to open.
- Insert 1 9V battery while observing the correct polarity (Fig.2).
- Replace the battery compartment door.
- Switch both the truck and controller power switches to the "ON" position.
- Adult supervision is recommended when operating this truck.
- Never operate your truck in a confined or crowded area, and do not use indoors (between front wheels) if the truck does not run straight when moving forward.

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Do not operate your truck on roadways with your truck.
- Do not submerge truck or controller in water.
- Never operate your truck on the street or highway.
- Remove all batteries when not in use to avoid accidental operation.
- Never operate your truck in a confined or crowded area, and do not use indoors (between front wheels).
- Do not run your truck into furniture, objects or hard surfaces, as this will cause damage to both the objects and the truck.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the truck is switched to "ON".
- Never operate your truck near sources of heat or under direct sunlight for long periods of time.
- Do not leave truck or controller outside overnight. Dampness is harmful to interior components.

NOTE: For best operation, use the truck on a hard surface.



Fig.1



Fig.2

OPERATING CONTROLS

BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Insert batteries using the correct polarity. Do not short-circuit the supply terminals.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are to be charged under adult supervision.
- Only batteries recommended by the manufacturer are to be used.
- Do not dispose of batteries in fire. They may rack or explode.
- Do not dispose of batteries in household waste (trash). Dangerous substances may be released. Dispose of batteries according to the manufacturer.
- Always use batteries of the same brand.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

©2019 MannDorune, LLC. The Black Series, The Black Series, Rally Stomper, and all associated logos are trademarks of MannDorune, LLC. All rights reserved.

Distributed by MannDorune, LLC, Irvine, CA 92618

Customer Service: 1-800-555-1234

For technical support, please visit www.mannedorune.com or call: 1-800-374-2744.

The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permissible to place, remove or reproduce any trademarks or copyright notices from this package.

1847565 (2302312)

6 94202 05979 8 | 8

Made in China