

PRODUCT MANUAL

LENRUE A25 SPEAKER

PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE
PRODUCT AND KEEP IT IN A SAFE PLACE.

Contact Email: betindirect@gmail.com

Dear Customer

Thank you for purchasing LENRUE speaker. In order for you to get familiar with the operation machine as soon as possible, we provided the detailed user manual, from which you can read about the product introduction, usage, system settings and cautions. Before using this product, please read this manual, as it may help you better understand this product.


We were very careful in the preparation of this manual, and we believe that all the information provided in this manual is correct and reliable. If there are any omissions, please kindly forgive and correct. If you find any problems during use of the product, please contact us in time.

(Contact Email: betindirect@gmail.com)

Caution



Contains a built-in irreplaceable lithium battery. Do not throw it into the fire. Do not disassemble, modify or repair by yourself.

Product Layout



Function Introduction

1. Function switch: short press change to one of the mode wireless ,TF card , LINE IN
2. Last/Vol- : long press to choose last song/ short press decrease volume.
3. Play/pause/call : short press play or pause music, answer the phone by short press and refuse by long press when calling.Wireless status Quickly double-click call back to the phone recently.
4. Next/Vol+ :long press to choose next song/ short press increase volume.
5. Wireless power light: the light is flashing when device turned on, light keep on after the wireless connected.
6. MIC: can communicate by MIC after connected with mobile phone at wireless state.
7. Switch: Toggle switch.
8. AUX in/3.5 Jack to jack: Use 3.5 jack to jack cable to play music.
9. USB port: plug in U disk and play music.
10. TF card: can insert TF card play audio files on the surface of the card.
11. Connect the power supply and USB interface: insert the USB interface to the machine recharged.
12. Charging indicator: Insert the power cord and the red light is on. When it is full of electricity, the light will gone.



2

Packing List

Wireless Speaker*1 User Manual*1 USB Charging Cable(Adapter is not Included)*1
3.5mm Audio Cable*1

Specifications

Size	15.74×2.65×2.36 in	Charging Time	3H
BT Version	V5.0	TF Card Estention	32GB MAX
BT Feature	A2DP,AVRCP,HFP,HSP	Input	DC 5V
Effective Distance	10M	Frequency Range	120Hz-20KHz
Dialog Time	12-15H	Priring Name	A25

Trouble Shooting

No Sound when Connecting to the Computer

1.AUX Mode

1)Make sure that the speaker is turned on (the power on button is on the back of the body).
When the speaker is turned on successfully, there will be a blue light indicator and a boot prompt tone.

2)Make sure that Wireless speaker volume and speaker volume is up.

3)Make sure that Wireless speaker is fully charged.

4)Make sure put the aux cable into the green jack of desktop computer.

2.Wireless Mode

1)Make sure the speaker is in Wireless mode, otherwise press the 'm' key to switch to Wireless mode.

2)Make sure Wireless is turned on.

3.Windows 10

Make sure you set the output to speakers on the sound settings:

1) Click the 'speaker' icon in the taskbar.

2) Select the ' Realtek HD Audio 2nd output ' / ' Realtek (R) Audio ' as your computer playback device

4. "▶" button

Confirm whether pause is enabled or not. Short press to switch play / pause.

Low Voice

Press the volume button to adjust the volume, if it doesn't work, adjust the volume of your devices.

Charging Time

Around 3 hours. (The red indicator will fade out when fully charged)

Discontinuous of the Voice

Low battery level or the speaker is out of range of a wireless signal, the wireless signal is about 33ft.

FCC Information

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

MADE IN CHINA
FABRIQUE EN CHINE
صنع في الصين
HECHO EN CHINA

