

pureboom®




Summit

On-Ear Wireless Earbuds User Manual

Auriculares inalámbricos - Manual del usuario

English

How to wear your PureBoom Summit Earbuds:




1

To charge your PureBoom Summit Earbuds:

1. Please remove all protective stickers before charging.
2. Ensure the earbuds are placed correctly in the charging case.
3. Using the enclosed cable, plug the USB-C connector into the USB-C port on the charging case and the USB-A connector into a wall charger (not included).

Charging Indicators:



- Fully Charged. / The charging case is charging the headphones.
- ... Battery level on the charging case is below 20%.

Connecting / Bluetooth Pairing

1. Make sure the PureBoom Summit On-Ear Wireless Earbuds are within 2-3 ft (0.6-0.9m) of the device you will be connecting to.
2. Remove both earbuds from the charging case and place them into your ears.
3. Turn on your device's Bluetooth. Most devices will automatically detect your earbuds. Locate and select "PureBoom Summit". It will indicate that your earbuds are now connected or paired.

Notes: If your device does not automatically detect your earbuds, make sure Bluetooth is turned on, search for "PureBoom Summit" and then press connect.

Operating PureBoom Summit

Powering on:

Simply open the earbud charging case.


Powering off:

Place inside the charging case and close.

***Note:** If the earbuds are on and not connected to a device, they will shut off after 5 minutes.

2

Multi Function Button



Features and Specifications

- Frequency response: 20-20KHz
- Transmission Range: 15m; 49 ft.
- Speaker driver: 16.2mm; 2 Hi-Fi
- Earphone battery: 40mAh; charges in approximately 2 hours
- Charging case battery: 400mAh; charges in approximately 2 hours
- Charge port: DC5V Type C input

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference,
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

3

FCC Statement (cont.)

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RFE exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID : 2AIIF-11384PG




pureboom®

www.PureBoomAudio.com

© 2024 | F00240PG


Cómo usar sus auriculares PureBoom Summit:



Para cargar sus auriculares PureBoom Summit:

1. Retire todas las pegatinas protectoras antes de cargar.
2. Asegúrese de que los auriculares estén colocados correctamente en el estuche de carga.
3. Usando el cable incluido, conecte el conector USB-C al puerto USB-C en el estuche de carga y el conector USB-A a un cargador de pared (no incluido).

Indicadores de carga:



- Cargados completamente. / El estuche de carga está cargando los auriculares.
- El nivel de la batería en el estuche de carga está por debajo del 20%.

Conexión/emparejamiento Bluetooth

1. Asegúrese de que los auriculares de botón supraaurales inalámbricos PureBoom Summit estén a una distancia de entre 2 y 3 pies (0,6 y 0,9 m) del dispositivo al que se conectarán.
2. Retire ambos auriculares del estuche de carga y colóquelos en sus oídos.
3. Encienda el Bluetooth del dispositivo. La mayoría de los dispositivos detectarán automáticamente sus auriculares. Localice y seleccione "PureBoom Summit". Se indicará que los auriculares están ahora conectados o emparejados.

Nota: Si su dispositivo no detecta automáticamente sus auriculares, asegúrese de que Bluetooth esté activado, **busque** "PureBoom Summit" y luego presione conectar.

Cómo usar los auriculares PureBoom Summit:

Para encenderlos:


Simply open the earbud charging case.

Para apagarlos:

Place inside the charging case and close.

***Nota:** Si los auriculares están encendidos y no están conectados a un dispositivo, se apagará después de 5 minutos.

Botón multifunción



Características y especificaciones

- Respuesta de frecuencia: 20 - 20 kHz
- Rango de transmisión: 15 m; 49 pies
- Controlador de los altavoces: 16,2 mm; 2 de alta fidelidad
- Batería del auricular: 40 mAh; se carga en aproximadamente 2 horas
- Batería del estuche de carga: 400 mAh; se carga en aproximadamente 2 horas
- Entrada de carga: Entrada tipo C DC5V

Cumplimiento con la FCC

Este dispositivo cumple con la Parte 15 de las reglas de la FCC. La operación está sujeta a las siguientes dos condiciones:

- (1) este dispositivo no puede causar interferencia dañina
- (2) este dispositivo deberá aceptar cualquier interferencia recibida, incluyendo interferencia que pudiera causar una operación indeseable.

Advertencia: Los cambios o modificaciones a esta unidad que no estén expresamente aprobados por la parte responsable del cumplimiento podrían anular la autoridad del usuario para operar el equipo.

NOTA: Este equipo ha sido probado y se encontró que cumple con los límites establecidos para un dispositivo digital Clase B, de conformidad con la sección 15 de las reglas de la FCC. Estos límites están diseñados para ofrecer protección razonable contra interferencias perjudiciales cuando el equipo se opere en una instalación residencial. Este equipo genera, usa y puede emitir energía de radio frecuencia, y si no se instala y usa de conformidad con las instrucciones podría provocar interferencia perjudicial en las comunicaciones de radio. Sin embargo, no se garantiza que dicha interferencia no ocurrirá en una instalación específica.

Si este equipo genera interferencia perjudicial en la recepción de radio o televisión, lo cual se puede determinar apagando y encendiendo el equipo, se sugiere que el usuario intente corregir la interferencia mediante una o más de las siguientes medidas:

Mover o reorientar la antena receptora.

Aumentar la separación entre el equipo y el receptor.

Conectar el equipo a una salida o circuito distinto al que está conectado el receptor.

Consultar al proveedor o a un técnico de radio o televisión con experiencia para que le ayuden.

El dispositivo ha sido evaluado para que cumpla con los requisitos generales de exposición a RF. El dispositivo se puede usar en condiciones de exposición portátil sin restricciones.