

pureboom



SoundMagnet

Wireless Speaker User Manual

Altavoz inalámbrico - Manual del usuario

English

To charge your PureBoom SoundMagnet Wireless Speaker

Using the enclosed cable, plug the USB-C connector into the USB-C port on the speaker and the USB-A connector into a wall charger (not included).

The charging indicator light will turn off when the speaker is fully charged.

Connecting / Bluetooth Pairing

1. Make sure the PureBoom SoundMagnet is within 2-3 feet (0.6-0.9 meters) of the device that you will be connecting to.
2. Turn on the speaker press the **Power button**  for 3 seconds.
3. Locate "PureBoom SoundMagnet" under Bluetooth and tap to connect.

Operating your PureBoom SoundMagnet Wireless Speaker

When playing music:

- **On/Off:** Long press the **Power button**  for 3 seconds.
- **Play/Pause:** short press the **Power button** .
- **Next song:** long press the **(+) button** once.
- **Previous song:** long press the **(-) button** once.
- **Increase volume:** short press the **(+) button** to your desired volume.
- **Decrease volume:** short press the **(-) button**.

When on a call:

- **Answer or hang up a call:** short press the **Power button** .
- **Reject calls:** long press the **Power button** .

Pairing 2 Speakers:

1. Make sure your device is not connected to any speakers.
2. Turn on both SoundMagnet Speakers by pressing the **power button**  for 3 seconds.
3. The speakers will enter pairing mode, double press  on **one** speaker.
4. Once paired to each other you will hear a tone when they are connected to each other.
5. Locate "PureBoom SoundMagnet" under Bluetooth and tap to connect.

Light Show:

To activate Light Show mode, short press .

Features and Specifications

- Frequency Response: 40Hz – 18KHz
- Charging input: DC 5V
- Li-ion battery size: 1200mAh/3.7V
- Drivers: 5W 52mm
- Impedance: 3Ω

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference,
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Statement (cont.)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2AIIIF-11541PG



Para cargar su altavoz inalámbrico PureBoom SoundMagnet

Usando el cable incluido, conecte el conector USB-C al puerto USB-C del altavoz y el conector USB-A a un cargador de pared (no incluido).

La luz indicadora de carga se apagará cuando el altavoz esté completamente cargado.

Conexión/emparejamiento Bluetooth

1. Asegúrese de que el altavoz inalámbrico PureBoom SoundMagnet esté a una distancia de entre 2 y 3 pies (0.6 y 0.9 m) del dispositivo al que se conectará.
2. Encienda el altavoz manteniendo presionado el **botón de encender**  durante 3 segundos.
3. Localice **PureBoom SoundMagnet** bajo Bluetooth y toque para conectar.

Operación del altavoz inalámbrico PureBoom SoundMagnet

Cuando se esté reproduciendo música:

- **Encender/apagar:** Mantenga presionado el **botón de encender**  durante 3 segundos.
- **Reproducir/pausa:** Oprima brevemente .
- **Siguiente canción:** mantenga oprimido el **botón (+)**.
- **Canción anterior:** mantenga oprimido el **botón (-)**.
- **Aumentar el volumen:** oprima brevemente el **Botón (+)** hasta llegar al volumen deseado.
- **Bajar el volumen:** oprima brevemente el **Botón (-)**.

Cuando se está en una llamada:

- **Contestar o colgar llamadas:** Oprima brevemente el **botón** .
- **Rechazar llamadas:** mantenga oprimido .

Emparejamiento de 2 altavoces

1. Asegúrese de que su dispositivo no esté conectado a ningún otro altavoz.
2. Encienda ambos altavoces SoundMagnet presionando el **botón de encendido**  durante 3 segundos.
3. Los altavoces entrarán en modo de emparejamiento, presione dos veces  en uno de los altavoces.
4. Una vez emparejados entre sí, escuchará un bip y la luz indicadora de un altavoz parpadeará rápidamente, la luz indicadora del otro altavoz parpadeará lentamente.
5. Localice el **"PureBoom SoundMagnet Speaker"** en el Bluetooth de su dispositivo y toque para conectarlo, altavoces a su teléfono.

Espectáculo de luces

Para activar el espectáculo de luces, oprima brevemente .

Características y especificaciones

- Respuesta de frecuencia: 40 Hz – 18 kHz
- Entrada de carga: DC 5V
- Batería de iones de litio: 1200mAh/3.7V
- Controladores: 5W 52mm
- Impedancia: 3Ω

Cumplimiento con la FCC

Este dispositivo cumple con la Parte 15 de las reglas de la FCC. La operación está sujeta a las siguientes dos condiciones:

- (1) este dispositivo no puede causar interferencia dañina
(2) este dispositivo deberá aceptar cualquier interferencia recibida, incluyendo interferencia que pudiera causar una operación indeseable.

Advertencia: Los cambios o modificaciones a esta unidad que no estén expresamente aprobados por la parte responsable del cumplimiento podrían anular la autoridad del usuario para operar el equipo.

NOTA: Este equipo ha sido probado y se encontró que cumple con los límites establecidos para un dispositivo digital Clase B, de conformidad con la sección 15 de las reglas de la FCC. Estos límites están diseñados para ofrecer protección razonable contra interferencias perjudiciales cuando el equipo se opere en una instalación residencial. Este equipo genera, usa y puede emitir energía de radio frecuencia, y si no se instala y usa de conformidad con las instrucciones podría provocar interferencia perjudicial en las comunicaciones de radio. Sin embargo, no se garantiza que dicha interferencia no ocurrirá en una instalación específica.

Si este equipo genera interferencia perjudicial en la recepción de radio o televisión, lo cual se puede determinar apagando y encendiendo el equipo, se sugiere que el usuario intente corregir la interferencia mediante una o más de las siguientes medidas:

- Mover o reorientar la antena receptora.
- Aumentar la separación entre el equipo y el receptor.
- Conectar el equipo a una salida o circuito distinto al que está conectado el receptor.
- Consultar al proveedor o a un técnico de radio o televisión con experiencia para que le ayuden.

El dispositivo ha sido evaluado para que cumpla con los requisitos generales de exposición a RF. El dispositivo se puede usar en condiciones de exposición portátil sin restricciones.

FCC ID: 2AIIIF-11541PG

