

尺寸：420*200mm

黑白双面印刷

RIPTUNES

Bluetooth Speaker Model: A5500BT User Manual



Congratulations on your new RIPTUNES Bluetooth Speaker. Please read user manual carefully and keep it for your records

RIPTUNES

Bluetooth Speaker Modelo: A5500BT Manual de Usuario



Felicidades por tu Nuevo Altavoz Bluetooth portátil. Por favor leer el manual con atención y guárdelo en sus archivos.

RIPTUNES

Bluetooth Speaker Modèle : A5500BT Manuel de l'utilisateur





Félicitations pour votre nouveau haut-parleur Bluetooth portable. Veuillez lire attentivement le manuel d'utilisation et le conserver pour vos dossiers

Specification:
Bluetooth Speaker with crisp treble and deep acoustics
TWS; ability to pair speakers simultaneously
Bluetooth version: 5.0 up to 33' (10meters)
Bluetooth distance: 100 ft (30 meters)
Speaker power: 5W RMS
4 ways to play music: USB/BT/Micro-SD/AUX
Built-in MIC for Hands-free calling
6 colors LED ambient lights
Rechargeable battery: 1200mAh
Material: ABS
Measures; 4.65"x4.65"x3.35"H (118x118x136mm)

Includes:
A5500BT Bluetooth speaker, USB charging cable, User Manual

Identifying the buttons/controls and ports:




Getting started:


- Before the first-time use, please fully recharge the battery. Do not play music while charging battery.
- Please use only a DC-5V certified power adapter and cable to charge your speaker.
- If experiencing intermittent sound while playing music, it may be caused by lack of power, please fully recharge the speaker.
- To play music via Bluetooth, activate the Bluetooth feature on your source device (phone/laptop/tablet/MP3 player, and set the device to search for wireless device.

Know the functions of each button:

ON/OFF Button:
1. Power ON/OFF: Press and hold for 3 seconds to turn on/off the speaker.



Guía de Inicio:
1. Antes del primer uso, por favor recarga completamente la batería. No reproduzca música mientras se está cargando.
2. Utilice únicamente un cable y un adaptador de corriente con certificación DC-5V para cargar el altavoz.
3. Si experimenta un sonido intermitente mientras reproduce música, puede deberse a una falta de energía, por favor recargue completamente el altavoz.
4. Para reproducir música a través de Bluetooth, active la función Bluetooth en el teléfono/computadora portátil/tableta/reproductor de MP3 de su dispositivo fuente y configure el dispositivo para buscar un dispositivo inalámbrico.



Commencer :
1. Avant la première utilisation, veuillez recharger complètement la batterie. Ne jouez pas de musique pendant le chargement de la batterie.
2. Vous êtes prié d'utiliser uniquement un adaptateur secteur et un câble certifiés DC-5V pour charger votre haut-parleur.
3. Si vous rencontrez un son intermittent lors de la lecture de musique, cela peut être dû à un manque de puissance, veuillez recharger entièrement le haut-parleur.
4. Pour écouter de la musique via Bluetooth, activez la fonction Bluetooth sur votre appareil source, téléphone/ordinateur portable/tablette/lecteur MP3 et configurez l'appareil pour qu'il recherche un appareil sans fil.

2. Bluetooth Pairing: When powering on the speaker, a sound will indicate "Bluetooth mode". Activate the Bluetooth feature on your source device (phone/laptop/tablet/MP3 player), and set it to search. Wait for your new speaker "A5500BT" to appear, then press connect to pair and connect.
3. LED light control: Short press to change the light color/mode, total of 6 colors lighting/modes. Short press in sequence until the lights will turn off.

M Button:

- Mode: Short press to switch between BT/USB/micro-SD/Aux-in mode.
- TWS: Press and hold for several seconds to connect /disconnect TWS.

TWS Function (2-speakers required)

Prepare 2 speakers and turn them ON. Press & Hold the M button of either of the 2 speakers to connect TWS. When tone will prompt indicating that the TWS connection is successful. At this time, your phone will only show one Bluetooth name, select to pair and connect, now you can enjoy two speakers playing music at the same time. Press & Hold the M button again to disconnect the TWS.

Play/Pause Button:

- Click to pause or play music
- For incoming calls, click to answer the call, click again to hang up the call
- Double click in short time to redial the last number.
- Hold the button for 2 seconds to reject the phone call.

Conoce las funciones de cada botón

Botón de encendido y apagado.

- Encendido/Apagado: Presione y espere 3 segundos para que se encienda o apague el altavoz.
- Emparejar con Bluetooth: Al encender el altavoz, un sonido indicará "modo Bluetooth". Active la función Bluetooth en el teléfono/computadora portátil/tableta/reproductor de MP3 de su dispositivo fuente y configurelo para buscar. Espere a que aparezca su nuevo altavoz "A5500BT", luego presione conectar para emparejar y conectar.
- Control de la luz LED: Presione brevemente para cambiar el color/modo de la luz, total de 6 colores de iluminación /modos. Presione brevemente en secuencia hasta que las luces se apaguen.

Botón M:

- Modo: Presione brevemente para cambiar entre los modos BT/USB/micro-SD/Aux-in.
- Función TWS: Mantenga presionado durante varios segundos para conectar/desconectar la función TWS.

Función TWS (2 altavoces requeridos)

Prepare 2 altavoces y enciéndalos, mantenga presionado el botón M de cualquiera de los 2 altavoces para conectar TWS. Cuando suena un tono esto indicará que la conexión TWS se ha realizado correctamente. En este momento, en su teléfono solo aparecerá un nombre de Bluetooth, seleccione para emparejar y conectar, ahora puede disfrutar de dos altavoces reproduciendo música al mismo tiempo. Mantenga presionado el botón M nuevamente para desconectar el TWS.

Connaitre les fonctions de chaque bouton :

Bouton MARCHE/ARRÊT :

- Marche/Arrêt : Appuyez et maintenez pendant 3 secondes pour allumer/éteindre le haut-parleur.
- Appariement Bluetooth: Lors de la mise sous-tension de l'enceinte, un son indiquera "mode Bluetooth". Activez la fonction Bluetooth sur votre appareil source, téléphone /ordinateur portable/tablette/lecteur MP3 et réglez-le pour rechercher. Attendez que votre nouveau haut-parleur "A5500BT" apparaisse, puis appuyez sur connecter pour coupler et connecter.
- Contrôle de la lumière LED : Appuyez brièvement pour changer la couleur/le mode de la lumière, total de 6 couleurs /éclairage/modes. Appuyez brièvement en séquence jusqu'à ce que les lumières s'éteignent.

Bouton M:

- Mode : Appuyez brièvement pour basculer entre les modes BT/USB/micro-SD/Aux-in.
- TWS : Appuyez et maintenez pendant plusieurs secondes pour connecter/déconnecter TWS.

Fonction TWS (2 haut-parleurs requis)

Préparez 2 haut-parleurs et allumez-les, appuyez et maintenez le bouton M de l'un des 2 haut-parleurs pour connecter TWS. Lorsque vous entendrez un ton, cela indiquera que la connexion TWS est réussie. À ce moment, votre téléphone n'affichera qu'un seul nom Bluetooth, sélectionnez pour coupler et connecter, vous pouvez maintenant profiter de deux haut-parleurs jouant de la musique en même temps. Appuyez à nouveau sur le bouton M et maintenez-le enfoncé pour déconnecter le TWS.

Volume ↑/Next Button:

Press & Hold to increase the volume
Short press to change to next music file

Volume ↓/Previous Button:

Press & Hold to decrease the volume
Short press to change to previous music file

USB/micro-SD Card Reading:

Insert the USB drive/micro-SD card into their slot to play MP3 files automatically. Adjust volume or switch to previous/next music files by following instructions above

Aux-In Mode:

Insert a 3.5mm audio cable (not included) into the AUX port and connect the other end of the 3.5mm cable into your music source device such as phone/laptop/tablet/MP3/audio player. A sound will prompt indicating the AUX connection is successful.

Charging:

Connect the small end of the Micro USB charging cable (included) to the Micro USB port located on the speaker. Connect the larger end of the cable to an AC adapter (not included) or to a USB port on your computer. The LED indicator will turn red while charging. Once fully charged, the red LED will turn off.

Safety Instructions:

Do not disassemble, damage, or dispose this Product. Consult your local waste collection agency for proper disposal or recycling methods.
This product is not a toy. Use extra caution while children are using this product.
Keep the Speaker away from direct sunlight, fire, and from high voltage equipment. Do not store the Speaker inside a car during hot weather. Remember, a closed car acts as a

Botón de Reproducir y Apagar:

- Haga clic para pausar o reproducir música
- Para llamadas entrantes, haga clic para contestar la llamada, haga clic nuevamente para colgar la llamada
- Haga doble clic en poco tiempo para volver a marcar el último número.
- Mantenga presionado el botón durante 2 segundos para rechazar la llamada telefónica.

Subir Volumen ↑/Botón de Siguiente:

Mantenga presionado para aumentar el volumen
Presione brevemente para cambiar al siguiente archivo de música

Bajar Volumen ↓/Botón de Anterior:

Mantenga presionado para disminuir el volumen
Presione brevemente para cambiar al archivo anterior

Lector de Memoria USB/micro-SD:

Inserte la unidad USB/Tarjeta Micro-SD en su ranura para reproducir archivos MP3 automáticamente. Ajuste el volumen o cambie a los archivos de música anteriores/siguientes siguiendo las instrucciones anteriores

Modo de Entrada Auxiliar:

Inserte un cable de audio de 3.5 mm (no incluido) en el puerto AUX y conecte el otro extremo del cable de 3.5 mm a su dispositivo fuente de música, como un adaptador de corriente, una computadora portátil, una tableta, un MP3 o un reproductor de audio. Un sonido indicará que la conexión AUX se ha realizado correctamente.

Cargador:

Conecte el extremo pequeño del cable de carga Micro USB (incluido) al puerto Micro USB ubicado en el altavoz. Conecte el extremo más grande del cable a un adaptador de AC (no

Bouton lecture/pause :

- Cliquez pour mettre en pause ou lire de la musique
- Pour les appels entrants, cliquez pour répondre à l'appel, cliquez à nouveau pour raccrocher l'appel
- Double-cliquez en peu de temps pour recomposer le dernier numéro.
- Maintenez le bouton enfoncé pendant 2 secondes pour rejeter l'appel téléphonique.

Bouton Volume ↑/SUIVANT :

Appuyez et maintenez pour augmenter le volume
Appuyez brièvement pour passer au fichier musical suivant

Bouton Volume ↓/Précédent :

Appuyez et maintenez pour baisser le volume
Appuyez brièvement pour passer au fichier musical précédent

Lecture de carte USB/micro-SD :

Insérez la clé USB/ la carte micro-SD dans leur fente pour lire automatiquement les fichiers MP3. Ajustez le volume ou passez aux fichiers musicaux précédents/suivants en suivant les instructions ci-dessus

Mode Aux-in :

Insérez un câble audio de 3,5 mm (non inclus) dans le port AUX et connectez l'autre extrémité du câble de 3,5 mm à votre appareil source de musique telle qu'un téléphone/ordinateur portable/tablette/MP3/lecteur audio. Un son indiquera que la connexion AUX a été réussie.

Mise en charge :

Connectez la petite extrémité du câble de charge Micro USB (inclus) au port Micro USB situé sur le haut-parleur. Connectez la plus grande extrémité du câble à un adaptateur secteur

greenhouse allowing the inside temperature to possibly reach over 200 degrees. Device may become warm while charging. Be assured Power is completely turned off when unplugging and unplugging into a power outlet.
Damage, shock, and/or injury can occur if this warning is not heeded properly.

Technical Support

Visit our website below to find answers to frequently asked questions, updated versions of this user's manual and/or contact information.

www.rip-tunes.com

Bluetooth is a registered trademark of Bluetooth SIG, INC. Important: Be sure to register your product within 14 days of purchase at www.rip-tunes.com/register for warranty purposes

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.