

PBT3028

User Guide



Bluetooth speaker

PBT3028 User Manual



Setting Up the Speaker


Charging the Speaker

To charge the speaker, attach the pin of the **supplied** charging adapter to the DC 5V charging port on the back of the speaker. Plug the adapter into a working wall outlet.

If using for the first time, please allow **3 - 5 hours** for the speaker to fully charge before using.


Installing/Replacing the Remote Control Batteries

To replace or install the remote control battery, push and slide the battery door out from the remote control. Replace the battery with a new **CR2025** battery with the positive (+) polarity facing up.



NOTE: There is a protective plastic tab inserted into the battery door of the remote control. When using for the first time, gently pull the protection tab extending out of the remote control's battery door.

In the Box



Tower Speaker



Remote Control



Charging Adapter

Pairing the Speaker


1. Turn the speaker ON by moving the [POWER] switch to the ON position. A tone will be heard indicating the speaker has power and the LED indicator will quickly flash **BLUE**.

2. Set your mobile device to search for Bluetooth devices. When your mobile device finds the speaker, select **PBT3028** from the list of found devices.

3. Once successfully paired, a tone will be heard and the LED indicator will slowly flash **BLUE**.

For iOS or Android


- Go to **SETTINGS > BLUETOOTH** (Make sure Bluetooth is turned ON)



The screenshots above are typical of many Bluetooth-enabled devices in the market today and are used to assist in the explanation of the pairing process. Your Bluetooth-enabled device's interface and operation with the speaker may differ slightly from the illustrations above.

Location of Controls

(Top panel of Speaker)



Location of Controls (cont'd)

1. Laser Aperture
2. [] Button:
 - Long Press - Decrease volume
 - Quick Press - Skip to previous track (Bluetooth mode)
 - Quick Press - Skip to previous FM station (FM Radio mode)
3. [] Button:
 - Long Press - Change between Bluetooth and FM Radio mode
 - Quick Press - Play/pause (Bluetooth mode)
 - Quick Press - Search/save FM stations (FM Radio mode)
4. [] Button:
 - Long Press - Increase volume
 - Quick Press - Skip to next track (Bluetooth mode)
 - Quick Press - Skip to next FM station (FM Radio mode)
5. [] Button:
 - (NOTE: Please review ALL warnings in this manual before using the laser function)
 - Quick Press - Toggle laser ON/OFF
6. LED Indicator
7. Auxiliary Input Jack (Side)
8. [POWER] Switch (Back)
9. DC 5V Power Jack (Back, Bottom)

Using the Speaker

Playing Music

To enjoy music wirelessly on your speaker, make sure you are paired to a Bluetooth-enabled device. Once paired, you can control the media playback and volume adjustment with the controls on your paired device.

Playing/Pausing Music

- To pause media playback, quick press the [] button on the speaker or remote control.
- To resume media playback, quick press the [] button on the speaker or remote control.

Skipping Tracks

- To skip to the **previous track**, quick press the [] button on the speaker or the [] button on the remote control.
- To skip to the **next track**, quick press the [] button on the speaker or the [] button on the remote control.

Powering ON/OFF

- Move the [POWER] switch to the ON position to turn the speaker ON.
- Move the [POWER] switch to the OFF position to turn the speaker OFF.
- Press the [] button on the remote control to enter/leave standby mode.

Volume Adjustment

- To increase volume, long press the [] button on the speaker or the [VOL+] on the remote control. To decrease volume, press the [] button on the speaker or the [VOL-] button on the remote control.
- Press the [] button on the remote control to mute/unmute the speaker.

Using the Laser

WARNING: When using the laser, do NOT aim or direct toward the eyes or face of anyone nearby as it may cause irreparable damage to one's eyesight. **The laser can instantly dazzle viewers**, do NOT aim or direct at anyone operating any kind of vehicle, near or far away.

- Quick press the [] button on the speaker or remote control to enable/disable the laser.

