



Product manual





Key Description

Seven buttons: "Back", "camera button", "Up", "Down", "Left", "Right", "OK"

One toggle switch: Switch "A" and "B"

Function specification

A:

1. Camera button, open the camera then press the button
2. Back button, different systems have different operations:
Android: Short press for backing to last operation, long press for switching Music Mode and Key Mode
IOS: Short press for operating "HOME", Long press for starting siri voice control
3. "OK": Direction Key: "UP", "Down", "Left", "Right"

Music Mode

"UP": Short press=Volume louder, long press=Volume louder continuously
"Down": Short press=Volume lower, long press=Volume lower continuously
"Left": Short press=Move Previous, long press=fast backward
"Right": Short press=Move Next, Long press=fast forward
"OK": short press=Play or hold, Long press=ON or OFF (Note: fast backward and fast forward just support with Samsung built-in video player)

B:

Key Mode

"UP": Short press=move up
"Down": Short press=move down
"Left": Short press=move left
"Right": Short press=move right
"OK": Short Press=ENTER, Long Press=ON or OFF
Android mobile phone only

一、Install application software

1. To download the application of the VR and install
- 2 :VR applications can be found in the application platform

二、Install devices

Place your phone in the middle of the VR

Align the center line of mobile phone screen to product midpoint mark

三、Test before use

By adjusting the space of pupil and focusing your eyes on the center of the glass to get the best performance

Bluetooth connection with phone Key

Note: mobile phones with IOS system, can not back up to the last menu by key after entering the menu with the bluetooth connection

Other note matters

Watching for a long time may cause slight dizziness. It is recommended to have a rest watching for 30 minutes.

This product is suitable for the mobile phones whose screen resolution is more than 1020 and with 4 to 5.5 inches size

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.