



Date: 2023.6.30			
产品型号	PA-443/437	部件名称	英文说明书
设计		材料	70G书写纸 正反面
品号			
工艺	单黑 正反印	成品尺寸	59*85mm
注：无			

Smoke Alarm		This WiFi strobe smoke detector is the device which can detect smoke occurred at the beginning of a fire disaster and generates live strobe & sound alarm, at the same time, push alarm information to mobile app by WiFi.																								
User manual		1、Technical Parameter Power supply : DC9V alkaline battery (6LR61) Static current : <10uA Alarm current: <100mA Working temperature : 0 C ~ +50 C Humidity : ≯ 95%RH , no freezing Alarm sound : >80dB Low battery alert : ≯ 6.5V±0.5V 2、Working status <table border="1"> <thead> <tr> <th>Status</th><th>Led light</th><th>Alarm sound</th></tr> </thead> <tbody> <tr> <td>Normal state</td><td>Led light flashes once every 60s</td><td>none</td></tr> <tr> <td>Test state</td><td>Led light flashes continuously and quickly (on: 100mA, off:100mA)</td><td>Quick "beep" sound</td></tr> <tr> <td>Smoke alarm state</td><td>Led light flashes continuously and quickly (on: 100mA, off:100mA)</td><td>Quick "beep" sound</td></tr> <tr> <td>Mute alarm state</td><td>Led light flashes continuously and quickly (on: 100mA, off:100mA)</td><td>none</td></tr> <tr> <td>Low battery</td><td>Led light flashes once every 60s</td><td>60s "beep" sound</td></tr> <tr> <td>WiFi connection succeed</td><td>Led light keeps on for 10s</td><td>none</td></tr> <tr> <td>WiFi configuring</td><td>Led light flashes continuously and quickly(twice every second)</td><td>Short "beep" sound</td></tr> </tbody> </table>	Status	Led light	Alarm sound	Normal state	Led light flashes once every 60s	none	Test state	Led light flashes continuously and quickly (on: 100mA, off:100mA)	Quick "beep" sound	Smoke alarm state	Led light flashes continuously and quickly (on: 100mA, off:100mA)	Quick "beep" sound	Mute alarm state	Led light flashes continuously and quickly (on: 100mA, off:100mA)	none	Low battery	Led light flashes once every 60s	60s "beep" sound	WiFi connection succeed	Led light keeps on for 10s	none	WiFi configuring	Led light flashes continuously and quickly(twice every second)	Short "beep" sound
Status	Led light	Alarm sound																								
Normal state	Led light flashes once every 60s	none																								
Test state	Led light flashes continuously and quickly (on: 100mA, off:100mA)	Quick "beep" sound																								
Smoke alarm state	Led light flashes continuously and quickly (on: 100mA, off:100mA)	Quick "beep" sound																								
Mute alarm state	Led light flashes continuously and quickly (on: 100mA, off:100mA)	none																								
Low battery	Led light flashes once every 60s	60s "beep" sound																								
WiFi connection succeed	Led light keeps on for 10s	none																								
WiFi configuring	Led light flashes continuously and quickly(twice every second)	Short "beep" sound																								
WiFi Networking Status: when LED indicator is on for 10s after battery is loaded, it means the detector is successfully connected to WiFi. 		3、Mute & Testing • Mute: in alarm status, press the 'TEST' button to mute the buzzer, only LED indicator flashes. • Testing: in normal status, long press 'TEST' button for 2s to trigger the sound & light alarm, alarm message is pushed to the mobile APP. 4、WiFi Configuration & Networking WiFi configuration: 1. Search 'Smart Life' app at iOS appstore or Google Android market. Register an account with the app before use. You can also scan the QR code below to download it. 2. Make sure your smartphone is connected to the WiFi. a) Launch the APP, click 'Add device'---'Security Sensor'---'Sensor (WiFi)'. b) Long press the 'TEST' button for 5s until LED flashes with a short beep of 'Di'. c) Click 'OK' in the APP---input password for the WiFi an click 'OK', the detector enters configuration mode which lasts for 60s maximum. 3. A long beep of 'Di' with LED indicator on for 10s means the WiFi configuration is completed. When WiFi configuration fails, the detector exits configuration mode with short beep of 'Di Di Di'. 4. WiFi configuration is done based on the 3 steps above.																								
5、Installation 		Installing method a. Make a hole on the ceiling by using the percussion drill b. Install the expansion tube on the ceiling c. Fix the installation board by using the screw d. Aiming the alarming device with the installing board and connect them, rotating clockwise till heard the "kaca" sound, means installing correctly. 																								
		Installing attention a. Indoor stalling only b. Keep 50cm between the device with the illumination lamp c. Keep away from the bathroom and watery place d. Keep away from the place non fire smoke and steam. e. Keep away the place below 0 C or above 50 C f. While the cupboard near the ceiling, keep the device 60cm away from the cupboard. g. Keep the device 150cm away from the ventilator, air conditioner and air vent. h. If battery missed, the device cannot connect with installing board 6、Maintain • Trouble happened while testing, please check immediately or send back to manufacture. • Battery life can be used for 1 year in the normal environment, age will be reduces in the high temperature and high humid environment. • Please ensure all the function be normal before installing, please keep in the safety place and avoid the dust, humid and corrosion.																								

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

FCC ID: 2AIT9-PA-437