

100mm

90mm

Get Started:


Pulse is a wireless charger that can magnetically snap to the back of your phone as it wirelessly charges.

Compatibility:

• Designed for MagSafe-enabled devices but compatible with most modern cell phones.

iPhone 12 and newer are MagSafe-enabled. You can use the magnetic wireless charging feature. Do not use the included metal ring. See section "Wireless Charging Magsafe-enabled".

For all other wireless charging phones (Android & iPhone 8 -11): You can use PowerMag as a wireless charger, as a cabled charger or add the included metal ring to your phone to enable magnetic capabilities. See section "Wireless Charging without Magsafe".



90mm

The Lights:

• **Startup:** The lights will initially blink continuously & simultaneously as Pulse searches for a stable charging connection

• **Stable connection:** After startup, Pulse will find a stable connection and the lights will turn solid, with the available lights on the battery gauge illuminated.

• **Recharging:** As you recharge Pulse, the last light will blink. As the battery level increases, more lights will illuminate until all available lights are solid.

• **Keeps Blinking:** If, after a few seconds of startup, the lights continue to blink simultaneously when charging should have started, there may be an error or interference with the wireless charging area. See section "Troubleshooting".

Need help?

See "Troubleshooting" section
Contact support@powerstick.com

90mm

Instruction Manual

PULSE

Portable Wireless Charger
MagSafe compatible | 2,000 mAh | USB-C Input/Output

100mm

Recharge Pulse:

Recharge Pulse when battery gauge shows 1 light. Plug one end of the included cable into the USB-C port at the bottom of Pulse and the other into a suitable power source. Pulse is fully charged when all 4 lights are illuminated and solid. See section "The Lights" for more details.

Charge Phone with a Cable:

Plug one end of your phone's cable into USB C port at the bottom of Pulse and the other into your phone. See section "The Lights" for more details. Pulse can charge wirelessly and with a cable simultaneously.

Wireless Charging MagSafe-enabled Phones:

If your phone or phone case is Magsafe-enabled, your phone will magnetically snap to the back of Pulse. This is the optimal charging position. Press the power button to begin charging. See section "The Lights" for more details.

Wireless Charging without MagSafe capabilities:

If your phone or case is not MagSafe-enabled, you may choose to use the included metal ring to add magnetic functionality to your phone. See section "Metal Ring".

Metal Ring:

For Android and older iPhone 8-11 this step will add magnetic capabilities:

- Use on phones without Magsafe for wireless charging
- Use the included guide to find your phone's center.
- Remove the backing from the metal ring and stick it to the back of your phone as per the guide.
- Pulse should now magnetically snap to the metal ring on the back of your phone.
- Press the power button on Pulse.
- See section "The Lights" for more details.

****** If your phone model or case is already Magsafe-enabled disregard the metal ring.



Designed and Made by PowerStick.com Inc. in Canada
FCC ID: 2A1TN-PULSE

Power Off: If Pulse does not auto shut-off, hold down the button for 10 secs.

Troubleshooting:

- Metal ring should not be attached to back of Pulse
- Trouble with wireless charging: reposition the phone slightly to achieve optimal alignment with Pulse
- Trouble with wireless charging: be sure there are no foreign objects interfering between your phone and Pulse's wireless charging area.
- **RESET:** If Pulse is not performing as expected, reset the device by holding down the power button for 10 seconds.
- Refer to section "The Lights" for more info.

Technical Specs:

Lithium-Ion Capacity: 7.4Wh Wireless Max Output: 5W
USB-C Max output: 5Vdc/1A Total Max Output: 1,242 mAh (5Vdc/1A)
Operating Temperature Range: -15°C (5°F) - 50°C (122°F)
Charging Temperature Range: 0°C (32°F) - 45°C (113°F)

90mm

90mm

90mm

Instructions Pertaining to Risk of Fire or Injury to Persons

Warning: Important Safety Information

- WARNING – When using this product, basic precautions should always be followed, including the following:
1. Read all the instructions before using the product.
 2. The power bank main unit contains an internal lithium-ion battery. Upon initial use or after a prolonged storage period, fully charge it once. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
 3. Power banks are not allowed in checked luggage on commercial airline flights. Carry-on only. Handle with care and dispose of in accordance with local regulations.
 4. To reduce the risk of injury, close supervision is necessary when the product is used near children.
 5. Do not expose the power bank to rain or moisture.
 6. Use of a power supply or charger not recommended or sold by the manufacturer may result in a risk of fire or injury.
 7. Do not use the power bank if it is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion, or risk of injury.
 8. Do not disassemble the power bank. Seek professional help if the power bank seems damaged. Incorrect reassembly of the product could have hazardous results.
 9. Do not expose the power bank to fire or excessive temperature.
 10. Never store or use this product in temperatures below 0°C (32°F) or above 40°C (100°F).
 11. If having a repair performed by a qualified repair person, use only identical replacement parts. This will ensure that the safety of the product is maintained.
 12. Do not put fingers or hands into the product.
 13. Do not use the power bank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.
 14. Do not expose a power bank to fire or excessive temperature. Exposure to fire or temperature above 50 °C (122 °F) may cause explosion.
 15. Switch off the power bank when not in use.

SAVE THESE INSTRUCTIONS.

CAUTION: Risk of Fire and Burns. Do Not Open, Crush, Heat Above 50°C (122°F) or Incinerate. Follow Manufacturer's Instructions.

Storage Instructions

Store the power bank in a cool, dry, well-ventilated area, away from direct sunlight and heat sources.
Recommended storage temperature: ≤30 °C (86 °F) unless otherwise specified.
Do not store near flammable materials or inside enclosed spaces with poor ventilation.
Keep away from metal objects (keys, coins, tools) to prevent short circuits.
Store in original packaging or ensure terminals are protected (e.g., covered or isolated).
Do not store if the unit is damaged, swollen, leaking, or emitting odor.

Disposal Instructions

This product contains a lithium-ion battery.
Do NOT dispose of in household garbage or recycling bins.
Improper disposal may result in fire, explosion, or environmental harm.
Dispose of the power bank at an authorized battery recycling or household hazardous waste facility.

Avertissement de Sécurité

AVERTISSEMENT – Lors de l'utilisation de ce produit, des précautions de base doivent toujours être respectées, notamment les suivantes :

1. Lisez toutes les instructions avant d'utiliser le produit.
2. L'unité principale de la batterie externe contient une batterie lithium-ion interne. Lors de la première utilisation ou après une période de stockage prolongée, chargez-la complètement une fois. Les performances complètes de l'appareil ne sont atteintes qu'après 2 ou 3 cycles complets de charge et de décharge.
3. Les batteries externes ne sont pas autorisées dans les bagages enregistrés lors des vols commerciaux. Transport en cabine uniquement. Manipulez avec précaution et éliminez conformément aux réglementations locales.
4. Afin de réduire le risque de blessure, une surveillance étroite est nécessaire lorsque le produit est utilisé à proximité d'enfants.
5. N'exposez pas la batterie externe à la pluie ou à l'humidité.
6. L'utilisation d'une alimentation ou d'un chargeur non recommandé ou non vendu par le fabricant peut entraîner un risque d'incendie ou de blessure.
7. N'utilisez pas la batterie externe si elle est endommagée ou modifiée. Les batteries endommagées ou modifiées peuvent présenter un comportement imprévisible, entraînant un risque d'incendie, d'explosion ou de blessure.
8. Ne démontez pas la batterie externe. Demandez l'aide d'un professionnel si la batterie externe semble endommagée. Un remontage incorrect du produit peut entraîner des résultats dangereux.
9. N'exposez pas la batterie externe au feu ou à une température excessive.
10. N'utilisez ni ne stockez ce produit à des températures inférieures à 0 °C (32 °F) ou supérieures à 40 °C (100 °F).
11. Si une réparation est effectuée par un technicien qualifié, utilisez uniquement des pièces de rechange identiques. Cela permettra de garantir que la sécurité du produit est maintenue. vvv
11. Si une réparation est effectuée par un technicien qualifié, utilisez uniquement des pièces de rechange identiques. Cela permettra de garantir que la sécurité du produit est maintenue.
12. Ne mettez pas les doigts ou les mains à l'intérieur du produit.
13. N'utilisez pas la batterie externe au-delà de sa puissance de sortie nominale. Une surcharge au-delà de la capacité nominale peut entraîner un risque d'incendie ou de blessures.
14. N'exposez pas la batterie externe au feu ni à une température excessive. Une exposition au feu ou à une température supérieure à 50 °C (122 °F) peut provoquer une explosion.
15. Éteignez la batterie externe lorsqu'elle n'est pas utilisée.

CONSERVEZ CES INSTRUCTIONS.

ATTENTION : Risque d'incendie et de brûlures. Ne pas ouvrir, écraser, chauffer au-dessus 50 °C (122 °F) ou incinérer. Suivre les instructions du fabricant.

Instructions de stockage

Conservez la batterie externe dans un endroit frais, sec et bien ventilé, à l'abri de la lumière directe du soleil et des sources de chaleur.
Température de stockage recommandée : ≤30 °C (86 °F), sauf indication contraire.
Ne pas stocker à proximité de matériaux inflammables ni dans des espaces clos mal ventilés.
Tenir à l'écart des objets métalliques (clés, pièces de monnaie, outils) afin d'éviter les courts-circuits.
Conserver dans l'emballage d'origine ou s'assurer que les bornes sont protégées (p. ex. couvertes ou isolées).
Ne pas stocker si l'appareil est endommagé, gonflé, fuit ou dégage une odeur.

Instructions de mise au rebut

Ce produit contient une batterie lithium-ion.
Ne PAS jeter avec les ordures ménagères ni dans les bacs de recyclage.
Une mise au rebut inadéquate peut entraîner un incendie, une explosion ou des dommages environnementaux.

90mm

Pour commencer:

Pulse est un chargeur sans fil qui peut se fixer magnétiquement à l'arrière de votre téléphone pendant la charge.

Compatibilité:

• Conçu pour les appareils compatibles MagSafe, mais fonctionne avec la plupart des téléphones modernes.

Les iPhone 12 et modèles plus récents sont compatibles MagSafe. Vous pouvez utiliser la fonction de charge sans fil magnétique. *N'utilisez pas l'anneau métallique inclus.* Consultez la section « Recharge sans fil compatible MagSafe ».

Pour tous les autres téléphones compatibles avec la recharge sans fil (Android et iPhone 8 à 11): vous pouvez utiliser Pulse comme chargeur sans fil, comme chargeur filaire, ou ajouter l'anneau métallique inclus à votre téléphone pour activer les capacités magnétiques. Consultez la section « Recharge sans fil sans MagSafe ».



Indicateur de batterie :
1 voyant = Batterie faible
4 voyants = Batterie pleine

État de charge :
Voir la section
« Les voyants »

90mm

Les voyants:

• **Démarrage:** Les voyants clignotent d'abord en continu et simultanément pendant que Pulse recherche une connexion de charge stable.

• **Connexion stable:** Après le démarrage, Pulse établit une connexion stable et les voyants deviennent fixes, avec le nombre de voyants correspondant au niveau de batterie allumés.

• **Recharge:** Lors de la recharge de Pulse, le dernier voyant clignote. À mesure que le niveau de batterie augmente, d'autres voyants s'allument jusqu'à ce que tous les voyants soient fixes.

• **Clignotement continu:** Si, après quelques secondes suivant le démarrage, les voyants continuent de clignoter simultanément alors que la charge devrait avoir commencé, il peut y avoir une erreur ou une interférence au niveau de la zone de charge sans fil. Consultez la section « Dépannage ».

Besoin d'aide?

Consultez la section « Dépannage »
Contactez support@powerstick.com

90mm

Manuel d'instructions

Chargeur Portable Magnétique
compatibles MagSafe | 2,000 mAh | USB-C Entrée/Sortie

100mm

Recharger Pulse:

Rechargez Pulse lorsque l'indicateur de batterie affiche 1 voyant. Branchez une extrémité du câble fourni dans le port USB-C situé au bas de Pulse et l'autre dans une source d'alimentation appropriée. Pulse est complètement chargé lorsque les 4 voyants sont allumés et fixes. Consultez la section « Les voyants » pour plus de détails.

Charger le téléphone avec un câble:

Branchez une extrémité du câble de votre téléphone dans le port USB-C au bas de Pulse et l'autre dans votre téléphone. Consultez la section « Les voyants » pour plus de détails. Pulse peut charger sans fil et par câble simultanément.

Recharge sans fil – appareils compatibles MagSafe:

Si votre téléphone ou son étui est compatible MagSafe, il se fixera magnétiquement à l'arrière de Pulse. Il s'agit de la position de charge optimale. Appuyez sur le bouton d'alimentation pour commencer la charge. Consultez la section « Les voyants » pour plus de détails.

Recharge sans fil – sans MagSafe:

Si votre téléphone ou son étui n'est pas compatible MagSafe, vous pouvez utiliser l'anneau métallique inclus pour ajouter une fonctionnalité magnétique à votre téléphone. Consultez la section « Anneau métallique ».

Anneau métallique:

Pour les appareils Android et les anciens iPhone 8 à 11, cette étape ajoute des capacités magnétiques :

- À utiliser sur les téléphones sans MagSafe pour la recharge sans fil
- Utilisez le guide inclus pour trouver le centre de votre téléphone
- Retirez le film protecteur de l'anneau métallique et collez-le à l'arrière de votre téléphone selon le guide
- Pulse devrait maintenant se fixer magnétiquement à l'anneau au dos de votre téléphone
- Appuyez sur le bouton d'alimentation de Pulse
- Consultez la section « Les voyants » pour plus de détails

**** Remarque :** Si votre téléphone ou son étui est déjà compatible MagSafe, n'utilisez pas l'anneau métallique.

Conçu et fabriqué par PowerStick.com au Canada
FCC ID : 2A1TN-PULSE

**Arrêt:**

Si Pulse ne s'éteint pas automatiquement, maintenez le bouton enfoncé pendant 10 secs.

Dépannage:

- L'anneau métallique ne doit pas être fixé à l'arrière de Pulse
- Problème de charge sans fil : repositionnez légèrement le téléphone pour un alignement optimal avec Pulse
- Problème de charge sans fil : assurez-vous qu'aucun objet étranger n'interfère entre votre téléphone et la zone de charge sans fil de Pulse
- **REINITIALISATION:** Si Pulse ne fonctionne pas correctement, maintenez le bouton d'alimentation enfoncé pendant 10 secondes
- Consultez la section « Les voyants » pour plus d'informations

Spécifications techniques :
Capacité de la batterie lithium-ion : 7.4 Wh Puissance max. sans fil : 5 W
Sortie USB-C max. : 5Vdc/1A Puissance totale max. : 1,242 mAh (5Vdc/1A)
Plage de températures de fonctionnement : -15°C (5°F) – 50°C (122°F)
Plage de températures de charge : 0 °C (32 °F) à 45 °C (113 °F)

100mm

90mm

90mm

90mm

FCC Warning statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.