


BRIO® EASY SET UP



Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.
Android, Google Play and the Google Play logo are trademarks of Google Inc.
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Brio AB is under license.

This product requires a device with Bluetooth LE.
iOS: Apple iPhone 4s, iPad 3, iPad Mini, iPod touch (5th gen). Requires iOS 8.3 or higher.

This device complies with Industry Canada licence-exempt RSS standard(s).
Operation is subject to the following two conditions:
 (1) this device may not cause interference, and
 (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Getting started with BRIO App-Enabled Engine:
 1. Insert 2 x 1.5 V AA batteries (not included) in your engine. 2. Download the free BRIO APP-ENABLED ENGINE from App Store or Google Play. 3. Start the app. 4. Turn on the Bluetooth function on your device and pair with the engine. 5. Switch the buttons on the bottom of engine to ON. 6. When the app is in contact with the engine, the green indicator on the app is lit.

Installing (and changing) batteries:
The Engine requires 2 x 1.5 V AA batteries. Loosen the screw on the battery cover on the back of the engine. Insert the batteries according to the illustration (4/4). Close battery cover, and tighten the screw.

Control panel on the Apri:

- 1 The green indicator lights up when connected to the engine.
- 2 Speed gauge.
- 3 Turns ON/OFF front lights.
- 4 Activate signal sound.
- 5 Stop.
- 6 Drive control.
- 7 Forward, front lights on.
- 8 Fast forward, horn lights on.

A detailed diagram of the Apri control panel. It features a central speed gauge with a needle and a scale from 0 to 100. To the left of the gauge is a green indicator light. Below the gauge are two circular buttons: one with a forward arrow and one with a horn icon. To the right of the gauge is a vertical column of four triangular buttons (up, down, left, right) and a horizontal cylindrical control knob. Numbered callouts 1 through 8 point to these specific components.

10 Fast reverse, sound and flashing red reversing light.

Battery operated features on the engine:

- 1 Flashing red warning light
- 2 Reverse
- 3 Stop
- 4 Crank/Forward
- 5 Front light



Note:

- Make sure that your smartphone or tablet supports the app.
- Range of coverage depends on the distance between engine and device. Connection will hold for as long as the geolocalization light on the app is on.
- After approximately 5 minutes of inactivity, the engine and the app disconnects. To start up the play again, press one of the buttons on the top of the engine.
- You can turn the engine without the app and smartphone or tablet by using the buttons on the top of the engine.
- It is recommended to turn off other Bluetooth devices while using the engine.
- The BPO APP ENABLED Engine is free and can be downloaded unlimited times.

Trouble shooting:

- 1 Turn off the engine by using the button on the bottom of the engine.
- 2 Close the app and restart your device.
- 3 Turn on the engine and start the app on your device and establish contact.
- 4 If the engine is not responding to the app, check the batteries.

Important!

- All adults should install and charge batteries.
- Never try to recharge batteries which are not rechargeable.
- Remove rechargeable batteries from the product before recharging.
- Rechargeable batteries should be charged under adult supervision.
- Never mix battery types. **Never mix new batteries with old.**
- Use only recommended batteries of the same or corresponding type.
- Install the batteries with correct polarity.
- When the batteries are flat, remove them from the product.
- Do not short-circuit the poles.
- Always remove the batteries if the product is not to be used for an extended period.
- Discharged batteries and old electrical and electronic products must be disposed of at an approved collection centre.
- Do not dispose of batteries in the household waste.
- Do not expose batteries to damp or water.

BRIO AB, Box 305, SE-201 23 Malmö, Sweden. Tel: +46 479 19 000



Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.
Android, Google Play and the Google Play logo are trademarks of Google Inc.
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by BRIO AB is under license.


この製品の使用にはBluetooth®規格のデバイスが必要です
iOS: Apple iPhone 4s, iPad 3, iPod Mini, iPod touch (第5世代) iOS 4.3以上が必要。
Android: Android 4.3以上が必要。

BRIOアプリ Enabled Engineの使用にあたって:

1. 1.5V 3形電池 (別売) を入れてください 2. 無料のBRIO APP (ENABLED ENGINE) を App Store または Google Play からダウンロードしてください 3 アプリを起動してください 4 お手持ちのデバイス上のBluetooth機能をオンにし、エンジンと組み合わせてください 5 エンジン底部のボタンをオンにしてください 6 アプリ上のエンジンと接続します 7 コントローラの電源ボタンを押し、

電池の入れ方(と交換):

エンジンには1.5V単3形電池が2本必要です。
エンジン背面の電池カバーのねしを緩めてください。
給(+)の指示にしたがって電池を入れてください。
電池カバーを閉じ、ねしを締めてください。



アップリ上のコントロールがわかる:

- エンジンと接続される、極度の寒さ防止の暖房システム
- スピードメーター
- ヘッドライトのオン/オフ
- 暖房装置の有無
- ストップ
- 遠征コントロール
- 暖房、ヘッドライト・オン
- 暖房で前進、ヘッドライト・オン
- 暖房、暖房とヘッドライトの点滅
- 前進で暖房、暖房とヘッドライトの点滅

エンジン・電圧で作動する特性:

- 1 赤いバックライトの点滅
- 2 燃速
- 3 ストップ
- 4 スタート/前進
- 5 ヘッドライト

注意:

- お手持ちのスマートフォンはタブレットがプロに付属していることを確認してください。
- 受取前にもエンジンとバッテリーの充電を必ず行います。
- 燃料が満タンである状態での使用が望めます。
- 体より高い位置に、エンジンバッテリーの接続が完了します。
- エンジンが再燃している、エンジンオイルのレベルの低下を伴って、必ず停止してください。
- エンジンが過熱の警告を発する場合は、エンジンとバッテリーの接続を必ず停止させなければなりません。
- エンジンが過熱している場合は、エンジンオイルの電圧を必ず確認することを推奨します。

BRIQ APP ENABLED ENGINEはいつでも、いつでもタブレットにできます。

トラブルシューティング:

- 1 エンジン底部のボタンを使用してエンジンを切ってください。
- 2 アプリを閉じ、デバイスを再起動してください。
- 3 エンジンをかけ、デバイス上でアプリを起動して接続を確認してください。

4 エンジンがアブリアに反応しない場合は、電池を確認してください。

注意！

- 後述のものでも壊すてはいけません。
- 電池の交換は必ず大人が行ってください。
- ボタン電池は絶対に水素ガスがたまるのをやめさせてください。万が一燃えた場合は窓口に直接に投げてください。
- 3ボルトタイプや4ボルトタイプなど、電圧を間違えて使用しないでください。
- 使用したあとには必ず電源の電圧を確認してください。
- 電池は1週間以上充電しないでください。
- 電池と本体の接触部分にシートを貼ってはいけません。
- 本装置に付属していない部品は使用しないでください。
- 使用開始の直前には必ず本体の充電を確認し、充電が満量まで完了していることを確認してください。

注意！

- 本装置は水に大気をはき出してはいけません。

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.