

Congratulations

Welcome to a world of sensational pleasure. Zentoy, a premium, high quality pleasure device lies at your fingertips. We made it from the finest materials and gave it a unique, proprietary design that departs from anything you have ever experienced. Plus it is really simple to use, featuring a single multifunctional button, so you can concentrate on what’s really important: pleasure. Enhance your experiences by using Zentoy mobile applications, available at Apple Store and Google Play.

Before you embark on your first pleasure trip, we advise you to quickly go through this manual.

For the full manuals and FAQ please visit: zentoy.com

The Zentoy Team

Quick Notes

- Clean your Zentoy before use.
- Hold the button for 3 seconds to turn it ON or OFF. Each button press rotates to the next mode.
- **Do NOT bend** over 30 Degrees.
- Already charged, but you can fully charge for optimum results. Charging time varies from 50 to 100 minutes. Delivers up to 2 hours of pleasure.
- The noise created when shaking the Zentoy is because of a **Zenball** included at the tip for optimum sensations and balanced vibes.

- 4 pre-insralled vibration modes plus an Idle mode. First mode is the Idle mode. 5 additional fully customizable vibration modes are accessible through the **Zentoy Play** Mobile Application.
- If Zentoy remains in Idle mode for more than 3 minutes, it automatically turns off to save battery.
- Use only silicone-free lubricant when needed.
- 100% waterproof. Safe to submerge in bathtab and wash.
- 100% body safe silicone.
- Download the complementary Zentoy Mobile Apps for remote control and customisation of the vibration modes.

Before Use

- To charge your Zentoy, attach the DC pin to the DC socket. You should feel a subtle click. Connect the other end to a USB charging plug.
- While charging, the LED light will turn blue. When the battery is full, the LED light will turn off.
- Charging time varies from 50 to 100 minutes. Do not charge for more than 24 hours at a time.
- Only use original Zentoy chargers.
- Charge and use your Zentoy at temperatures between 5 and 35 °C (41 - 95 °F).

Clean & Care

- Clean before and after each use. It is advised to use the Zentoy Clean Foam for maximum results. Alternatively you can use mild soap and warm water.
- Store in provided case to keep clean and safe.
- **Do NOT use any of the following products with Zentoy as this could make the device permanently tacky and/or cause skin irritation:** silicone-based lubricants, massage oil, hand cream, cleansers containing alcohol or petrol or acetone.

Control Button

- A long **press for 3 seconds will turn it ON or OFF**. A short vibration buzz will indicate that the action is registered and that the button can now be released.
 - When the device is ON, short button presses (less than 3 seconds) will advance forward through operation modes in a cyclic order.
 - The first mode is the Idle mode. Press a second time for the vibrations to start.
- If Zentoy remains in Idle mode for more than 3 minutes, it automatically turns off.

Your Zentoy features 9 vibration modes, called Zenvibes, plus the Idle mode. On a new Zentoy, modes 5 to 9 are left empty. You can record your Zenvibes and upload them to your Zentoy using the Zentoy Play Mobile Application.

Zentoy “talks” to you via a light indicator.

Blue light	Zentoy charging
White light	Zentoy ON
White light slow flashing	Zentoy in idle mode
White light constant	Zentoy in any active mode
White light fast flashing	Low battery, recharge



© 2016 Lavme Inc - All rights reserved.
Designed and Developed by Lavme Inc in USA.
Manufactured in PRC.

Play Safe

- Keep out of reach of children.
- Intended for people aged 16 or older.
- Do NOT use in areas that are irritated, swollen, inflamed or have skin lacerations.
- Consult your physician if you are pregnant or if you are shortly after birth.
- Stop using your Zentoy if you experience discomfort.
- Do not use your Zentoy if any of the components are damaged.

- In the unlikely case unusual sounds occur, turn your Zentoy off and contact us at support@zentoy.com
- NEVER leave your Zentoy in direct sunlight or UV light.
- Your Zentoy is 100% waterproof. Can be used in bathtub.
- Keep your Zentoy charged over 50% for optimum battery life time.
- Your Zentoy utilizes an integrated Lithium Polymer accumulator and must NOT be burned, dismantled or exposed to temperatures above 60 °C (140 °F). Risk of battery explosion.
- **Do NOT Drop your Zentoy.**
- **Do NOT Microwave or Boil your Zentoy.**
- **Do NOT Overheat your Zentoy.**

Zentoy Play

Zentoy Play Application will enable you to fully control your Zentoy directly through your Bluetooth enabled Smartphone. You can play live and/or create, save and transfer custom vibration patterns. The complementary Zentoy Play and all Zentoy Mobile Applications are available for iOS and Android devices. Visit www.zentoy.com to find out more.

Support

In the rare case you face problems with this device, contact our support team at support@zentoy.com.

Never attempt to open or repair this device by yourself, as this will void your warranty.

My Zentoy does not turn on	Charge
I hear a noise when I shake my Zentoy	A Zenball exists in the tip.
My Zentoy makes strange sounds	Turn OFF. Contact us
My Zentoy heats up while charging	Unplug immediately. Contact us
I charge but it does not turn on	Contact us
The app cannot connect to my Zentoy	Refer to the online manual

Specifications

Materials: Medical grade silicone and ABS body safe plastic
Dimensions: 22cm x 5.1cm x 3.3cm (8.7in x 2.0in x 1.3in)
Silicone Length: 11cm (4.3in)
Battery: Li-Po 400mAh, 3.7V
Charging: 1hr at 5.0V, 400mA
Runtime: Up to 2hrs
100% Waterproof

Warranty

Zentoy comes with 2 year Limited Warranty
Please visit www.zentoy.com/warranty for more details.

Disposal

Electronic equipment. Not to be treated as household waste. Dispose of properly.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Disclaimer

Use this product at your own risk. Neither Lavme Inc. nor its retailers assume any responsibility or liability for the use of this pleasure object. Lavme Inc reserves all rights to implement technical changes that serve the improvement of the device as well as changes to the design. The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

FCC ID: 2AIVH-GC730692

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

