

Specifications


Bluetooth version: v5.3
Transmission Distance: 10 m
Battery Capacity: 150 mAh
Charging Time: Approximately 2 Hours
Playtime: Approximately 10 Hours **
Charging Input: USB-C

**Applicable at 50% of maximum volume.
Results will be lower when volume is higher.


The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International is under license. Other trademarks and trade names are those of their respective owners.

A Quick Look

- 1.Next Track/Volume +
- 2.Power On/Off/Play/Pause/Accept/End Call
- 3.Previous Track/Volume -
- 4.Mic
- 5.Auxiliary Port
- 6.LED Indicator
- 7.Charging Port
- 8.MicroSD Card Reader




Charging



1. Insert the included charging cable's USB-C end into the charging port.



2. Insert the charging cable's standard USB end into the USB port of a suitable wall adapter (not included).



3. The LED Indicator light will emit a steady red light while charging and will turn blue when fully charged.

Bluetooth Pairing




1. Press the power button for 3-4 seconds to enter into pairing mode. In pairing mode the LED indicator will flash blue and red.



2. On your phone, go in the Bluetooth page in the Settings app. Make sure Bluetooth is on before connecting to the available device "Kid Safe 2-in-1"

Controls



-Press and hold the power button for 3-4 seconds to power ON. Press and hold for 3-4 seconds to power OFF.
-Press to Play/Pause music.
-Press twice to activate voice assistant mode from compatible devices.

+
-Press the volume up button to increase the volume.
-Press and hold go to the next song.

-
-Press the volume down button to decrease the volume.
-Press and hold to go to the previous song.

MicroSD Card Mode

-When inserting a MicroSD card into the MicroSD slot the headphones will automatically enter card reader mode. In card reader mode, your headphones can play .mp3 music files stored on your memory card. Remove the MicroSD card to switch back to Bluetooth mode.

Wired Listening Mode

-When inserting an Aux cable into the Auxiliary port, the headphones will enter wired listening mode. In wired listening mode, while the headphones are connected to another audio device through an Aux cable, the headphones will play audio from the connected device.

Important Safety Precautions

1. READ ALL INSTRUCTIONS BEFORE USING YOUR PRODUCT.
2. Do not use your product near water. Do not place your product on any wet surfaces.
3. Do not allow children to use the product without proper adult supervision.
4. Do not expose your product to excessive heat or fire.
5. Do not use in extremely dry environments, as this can lead to static discharge during use.
6. Do not expose your product to temperatures above 100°F. Keep out of direct sunlight.
7. Do not attempt to repair the product yourself. Contact a qualified service center if your product is in need of service.
8. Do not drop, puncture or expose your product to excessive physical force.
9. Your product is not intended for commercial use.
10. Do not place the product near objects that generate a strong magnetic field.
11. Use only the supplied charging cable. Unplug this device when not in use for long periods of time and during lightning storms.
12. Use a soft cloth to clean your product. Never use any abrasive chemicals.
13. Please recycle or dispose of your product properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your product for further information.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable. This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.


What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:
Call 1-800-592-9541 in the U.S. or visit our website at www.vivitar.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaid.

Using Your Headphones: Call Controls



When connected to a Bluetooth smartphone that is receiving a call:
-Press the power button to answer/end a call.
-Press and hold the power button to reject a call.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

©2025 Sakar International
195 Carter Drive
Edison, NJ 08817
Support: 800 592 9541
www.vivitar.com