

User Manual

Bluetooth Earbuds With Charging Case (model:DRIPZ)

Specification:

1. Bluetooth Version: BT5.0+EDR
2. Earbud Playback time: 6 hours
3. Earbud charging time: 1.5 hours
4. Charging case Charging time: 2.5 hours
5. Earbud Battery: 3.7V/50mAh
6. Charging Case Battery: 3.7V/800mAh

1. Please full charge the charging case and the earbuds (Keep earbuds stay in Charging case) before use

2. How to Pair

a) Pair with devices with TWS mode

After full charge, take the earbuds out from charge case, the LED on one earbud will flash white (another earbud is solid white), switch on the Bluetooth on your devices and select "Dripz" to pair with. After paired, LED on both earbuds will be solid white

Note: If earbuds are off, to turn on them, please press and hold the MFB buttons for 2 seconds until you see the flash white LED

b) Pair with devices with mono mode

Just take one from the charging case and keep another stay in, Following the same processes as above "b"

c) Earbuds TWS pairing (Manual)

Press and hold MFB buttons on both earbuds for 3 seconds and then they will pair each other, after successfully paired, LED on one earbud will flash white and other will be solid white

Noted: USE TWS model for pairing when the earbuds are paired with a new device for the first time

3. How to reset:

In case the earbuds crashed, Press and hold the MFB buttons for 8 seconds until turn on..

4. How to operate

Turn ON	Take earbuds from charging case, The earbuds will turn on automatically Or Press and hold MFB buttons on both earbuds for 3 seconds to turn on them manually
Turn OFF	Put earbuds back the charging case, the earbuds will turn off automatically Or Or Press and hold MFB buttons on both earbuds for 3 seconds to turn off them manually
Pause/Play	Single click the MFB button
Previous/Next	Hold the L/R MFB button for 1.5 seconds
Volume+/-	Double click L/R MFB button (Step by step)
Answer/hang up	Click the MFB button during phone call

the phone call	
Reject the call	Press and hold the MFB button for 2 seconds during phone call
Activate Voice assistant	Triple click L/R

Note:

- ❖ If the charge case is out of power, the earbuds could not power on automatically they are taken out from Charge case, please charge the case for a while; Or you can power on the earbuds manually
- ❖ Earbuds will turn off after 10mins if no devices connected with.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.