
WIFI Storage

UD-4267



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- o Reorient or relocate the receiving antenna.
- o Increase the separation between the equipment and receiver.
- o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- o Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ENGLISH

Package Contents

- Wifi storage*1pc
- Data transfer & charge Micro USB cable *1pc
- Lid gift box* 1pc

Product Features



- A) Power button
B) WIFI indicator
C) Power indicator
D) Input

APP name

DM AirDisk PRO (Please search on your mobile device software store like APPstore, Google play etc.)

WIFI name

PocketCloud_***

Battery capacity

3.7V/800mAh li-polymer

Compatible for

Both for Android and IOS system mobile device

Micro USB data transfer& charge cable

Connect adapter to charge device , charging current: 400-500mA

Insert PC, act as card reader , also charge device with current 350-500mA

Power button

Power on when press button 3s

When power on, keep pressing 15s untill indicator start flickering, reset device

Power/Wifi indicator

Power indicator flash slowly in red under charging and light up when fully charged.

when battery power less than 10%, power indicator start flickering and will power off automatically Wifi indicator will flicker under data transferring between device and your phone.

Memory storage

16GB in class6

WIFI protocol

IEEE 802.11b/g/n

Frequency

support 2.4GHZ,

MICRO USB

support USB2.0 protocol

MICRO USB speed

read:12MB/S-20MB/S, write:6MB/S-13MB/S

WIFI 2.4G speed

read:1.7MB/S-3.1MB/S, write:0.8MB/S-2.2MB/S

Connecting users number

3people in max in same time

Functions

- Wireless extend your mobile phone/tablet storage
- Share photos/album/ videos/music and documents between the Pocket Cloud and your mobile device
- Up to 6 people can share data at the same time
- Act as USB drive when inserted in your PC with the included cable

Operation

1. Download the APP

A: For IOS system, please scan the QR code or please search for “DM AirDisk PRO” in the APP Store




B: For Android, please scan the QR code below and download or directly search for “DM AirDisk PRO” on Google Play




C: Power on the device by pressing the power button, the power indicator will light up in blue

2. Mobile device setting


A: Enter your mobile device settings, connect the device Wi-Fi named “PocketCloud_***”, the default wifi has no password



B: Open your downloaded APP “DM AirDisk PRO”




C: After searching, APP shows the workable device, connect it and login.




D: Device setting


- WIFI name can be changed
- You can add a wifi password




E: Upload files from your mobile device to the wifi storage





F: Download files from the Wi-Fi storage to your mobile device, you can also encrypt or delete files in the APP




H:Where are my downloads?



I:Backup mobile device albums and contacts



J: Encrypted space: APP setting -> Encrypted space Setting



WARNING!

- Do not expose to liquids or a humid environment
- Do not disassemble
- Avoid dropping
- Avoid temperatures above 70 degrees Celsius
- This is not a toy, not suitable for children under the age of 7