

Please read the instruction manual carefully before using the product

Welcome to ROOME

The Roome Mini Plus allows you to use the Roome APP to control the lamp remotely, schedule alarms, program night light sensitivity, etc. Additionally, the lamp will use its Smart Lamp Technology to intelligently learn your preferences for brightness, sensitivity to motion, and many other useful features.

* To get the best user experience and access to the latest features, please connect the lamp to the ROOME APP via Bluetooth.

- 1 -

Product Overview

Front

Leather sling
Lamp
Infrared Sensor
Lock
Charging base

[Mini Plus]

Back

Power Indicator
Photosensitive sensor
Power Button
Power Supply Interface

[Mini Plus]

- 2 -

Start Using

Power On / Off

Start: Press the "Power" button for 2-seconds; or press it 3-times.
Shutdown: Press the "Power" button 3-times.

Power On: Press & Hold for 2-sec Power On / Off: Press 3-times

Correct Placement

To optimize intelligent-control capabilities, the lamp should be placed facing the active area and have no obstructions to the front sensors.

* Infrared sensing range 180°

- 3 -

Manual Control

On/ Off: Press the "Power" button on the back.
To adjust the brightness: Press and hold the "Power" button. The brightness will cycle. When released, the current brightness is selected.

Press: On / Off Press and Hold: Adjusts the brightness

Reset

Press the "Power" button 5-times to initiate a reset. The indicator will flash to indicate reset is commencing, and will light continuously for 3-seconds when the reset is complete.

Press Power 5-times to restore factory settings

- 4 -

Roome APP Control

Scan the QRC code below, or search for "Roome Home" in the App Store.

Scan to download the APP

* The APP supports iOS 8.0 and Android 4.3 and above

When using for the first time, follow prompts within the APP to establish a Bluetooth connection. This will permit remote control from your mobile phone. You will be able to set schedules and timing-related control features, motion detection sensitivity, and many other intelligent-learning functions.

- 5 -

Basic Functions

Presence Detection

Elegant Design

App Control

Soft LED Lighting

Automated Control

Integrated with different sensors and ROOME patented algorithms, Roome Light Mini will intelligently study your use of it as well as its own ambient environment so that it knows when to switch itself on or off for you.

Elegant Design

Roome Mini Plus is made from high-quality anodized aluminum and the LED is set behind a durable semi-transparent PMMA lampshade. A leather belt is attached to the lamp so you can use it as a lantern.

App Control

Roome Mini Plus is Bluetooth enabled and works with our custom iOS and Android app. With the app, you can dim the light, enable presence detection, and set the light to turn off at a set time.

Wireless Charging

You can put it on magnetic charging base for continuous lighting or use it as a lantern for both indoor and outdoor use. With one charge, the battery can last up to 10 hours.

* Automated light control is enabled as default; if this function is unnecessary you can turn it off in the settings menu within the App.

- 6 -

Instructions

Automated Control Instruction

- The light will turn off after 3-5 minutes after Roome Mini Plus detects no presence in the room.
- The light will turn off if there is sufficient lighting in the room.
- Roome Mini Plus will enter a soft-light mode and illuminate with dimmed light when it detects movements in the middle of the night.
- When automated control is unnecessary, you can turn this mode off in the settings menu within the App.

Charging Instruction

Please put Roome Mini Plus correctly on the charging base, making sure the charging contacts on the bottom of Roome aiming at the charging contacts on the charging base.

Blue light flashes rapidly: Low Battery Blue light flashes slowly: Charging Blue light constant on: Charging Completed

- 7 -

Specifications

Model	HBP1-0-1701CN
Color	Metal
Dimensions	Height(mm/inch) 150/6 Diameter (mm/inch): 80/3.2
N.W:	(g/oz) 250/8.8
Material	Aluminum alloy, leather, plastic
Surface	CNC diamond cutting, anodized aluminum matte finish, transparent lamp shades
Sensor	Light sensor, Infrared sensor
Communication	Bluetooth 4.0
Operating mode	Manual Control, App control, Timer, Delay timer, Light control
Operating system	Compatible with iOS 8.0 & Android 4.3 and above
Light source	Flicker-free LED
Power	LED 0.8 W
Brightness	100-140 Lumen
Color temperature	3000 K
Battery	1200 mAh lithium battery
Charging	Aluminum charging base

- 8 -

Warranty Repair Limitations

Warranty for repairs of the Roome Light

The warranty period for the Roome Mini Plus is one year (from the date of purchase).

- During this period the lamp is covered for any repairs that are required due to faulty construction or workmanship provided that the light was used consistently in a normal fashion and in the manner for which it was intended.
- Any modifications or additions to the Roome Mini Plus will void this warranty.
- If the warranty card below and the original invoice are altered in any way, the warranty will be voided.
- The below warranty card and the original invoice are both normally required for the warranty to be honored. Please save them so that we can assist you with any problems that you may have.

The warranty will be voided under the following circumstances:

- Breakage that has occurred due to inability to follow the instructions in this manual or in the App.
- Breakage due to the inappropriate storage or use of the device.
- Breakage due to force majeure ("Acts of God"), such as fires, floods, etc.
- Breakage due to repairs or maintenance attempted by an unauthorized repair technician.

Caution

- Please use a standard adapter to avoid unnecessary damage to the product.
- Please do not try to dis-assemble the product.
- Keep product away from water.
- Keep product away from high temperatures and flames.
- Please do not cover the lamp with heavy clothing and bedding.

Warning Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- 9 -

Warranty Repair Card

Customer Name, _____

Address, _____ Email Address, _____

Phone Number, _____ Serial Number, _____

Product Model Number, _____

Where was the device purchased, _____

Purchase Invoice or Order Number, _____ stamp here!

Customer Signature, _____

- 10 -

USER GUIDE

ROOME LIGHT MINI PLUS

智能光瓶