



Bluetooth Speaker 5B332BT



INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY
AND RETAIN FOR FUTURE USE

1

Getting started

- Remove the unit from the box.
- Remove all packaging from the product.
- Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

In the Box

- Bluetooth Indoor/Outdoor Speaker
- USB Charging Cable
- Auxiliary Cable
- Instruction Manual

Features




- Stream music wirelessly from any Bluetooth enabled device – works with iPad, iPhone, iPod Touch, Android devices and more
- Built-in controls support play, pause, forward/backward track and volume
- Vibrant sound with powerful bass & crisp highs
- Included 3.5mm input & stereo auxiliary cable connects to even more devices

IMPORTANT SAFETY INFORMATION

- Read all instructions before using this product.
- Do not leave this product unattended while connected to the power supply.
- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use the unit with wet hands.
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This product is not a toy.
- Do not play music at excessive levels especially near children, as damage to hearing may occur.

2

Description of Parts



3

1	Multi-colored LED Flashing Lights (Speaker inside)	6	Previous Track / Volume -
2	Play / Pause / Phone Button	7	Multi-colored LED Flashing Lights On / Off Button: Short press to change other flashing pattern, long press to turn on/off the light
3	LED indicator	8	AUX-IN Port
4	Built-in Mic	9	USB Charging Port (DC 5V)
5	Next Track / Volume +	10	ON / OFF Switch

INSTRUCTIONS FOR USE

Charging Instructions

The speaker comes with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully.

Connect the USB cable to a computer USB port and the USB plug to the charging port of the speaker. The Red LED illuminates while the speaker is being charged. It takes 2 - 4 hours for the unit to fully charge. When the battery is fully charged the red LED will turn off.

Turning on/off the speaker

There is an ON/OFF switch at the back of the speaker. You can turn on/off the speaker with this switch. In order to save power, put the switch to off position when the speaker is not in use.

Pairing the speaker with Bluetooth devices (phone or music device)

- Switch on the speaker and you would hear the indication tone.
- Multi-colored LED Flashing Lights turn on, your speaker is now ON and is entering "pairing" mode
- Place the speaker and Bluetooth device (phone or music device) so that they are no further than 3 Feet apart.
- Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your device.
- Once you have activated Bluetooth on your device, select the speaker "SL RUGGED SPKR" from the list of available Bluetooth devices.
- If required, enter the password '0000' to confirm & finalize pairing.
- Once paired successfully, you would hear another indication tone.
- You can now start to use the speaker.
- If pairing is unsuccessful, turn off the speaker first and then re-pair following the above steps.
- Once you have paired the speaker with a device, the speaker will remember this device and will pair automatically when the device's Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.
- The speaker will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device please follow the steps outlined above.
- Once the speaker is paired with your device the music will transmit directly to the speaker. Please refer to your device's user manual for further information.

4

Listening to Music

Once the speaker is paired with your device you can stream music wirelessly using your mobile device. Select the track you wish to listen to and it will be streamed to your Bluetooth speaker. Should you encounter any problems while streaming please refer your device's user manual for further information.

Function	Operation	Button
Increase Volume	Playing music	Long press the Next Track / Volume + button will increase the volume
Decrease Volume	Playing music	Long press the Previous Track / Volume - button will decrease the volume
Pause	Playing music	A short press on the Play / Pause button will pause the music
Play	Pausing	A short press on the Play / Pause button will resume the music
Next Track	While playing music	Short press the Next Track / Volume + button and it would move one track forward
Previous Track	While playing music	Short press the Previous Track / Volume - button and it would move one track backward

An indication tone will alert you when the volume is adjusted to the maximum level.

Answering a call with the speaker

Basic operation

Function	Operation	Button
Answer Incoming Call	Incoming Call	Short press the Phone Button to answer an incoming call
Reject Incoming Call	Incoming Call	Long press the Phone Button for 2-3 seconds
End Call	Incoming Call	After your phone conversation, short press the Phone Button.
Increase Volume	During a call	Long press the Next Track / Volume + button will increase the volume
Decrease Volume	During a call	Long press the Previous Track / Volume - button will decrease the volume
Redial last number	Standby mode and connected to a device	Short press the Phone Button twice

5

Please Note

- Not all mobile phones support all the functions listed above. Please refer to your cell phone's user's manual for further information.
- Certain functions and indication tones maybe vary depending on your mobile phone.

Play music using "AUX-IN" Jack

1. Turn ON the device.
2. Insert the Auxiliary cable (included) in the AUX-IN port of the speaker. And, insert the other end of the cable into the audio device (such as mobile phone / computer / tablet / etc.).
3. Select your favorite song at the source device.
4. Long press Next Track / Volume + button to increase the volume or long press Previous Track / Volume - button to decrease the volume.

Note: When you insert Auxiliary cable into the AUX-IN Port of the speaker, its Bluetooth mode will turn off automatically. An indication tone will alert you when the volume is adjusted to the maximum level. All media controls (skip forward / backward etc) can be managed from the source device only.

Specifications

Bluetooth version	2.1 +EDR
Operating distance	26-33 Feet
Speaker power	2W
Working time	Up to 3 hours
Lithium battery	3.7V 1200mAh
Charging input voltage	DC 5V
Charging time	2 - 4 hours
Dimensions	7-7/8" x 5-1/8" x 9-1/8"
Weight	2 lb 4.4 oz

Note: Battery life & charging time may vary based on usage & types of devices used.

Troubleshooting

Problem	Possible Cause	Solution
Low sound level	Source (Tablet, Mobile Phone, Laptop, etc.) volume too low. Battery dead	Adjust source volume. Charge battery.
Sound distorted	Battery nearly dead	Charge battery
No sound at all.	Source (Tablet, Mobile Phone, and Laptop.) turned off. Speaker turned off. Adjust volume source. Media paused on source.	Turn the source on. Turn the speaker on. Adjust volume source. Play media from source.

6

Care and Maintenance

Clean the unit with a soft, damp cloth. Never use chemicals or hard abrasives. Keep this unit away from wet or damp surroundings.

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

LIMITED WARRANTY

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

WARRANTY DURATION: All materials and workmanship are warranted to the original consumer purchaser for a period of ninety (90) days from the original purchase date.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty doesn't cover the following which may be supplied with this product, including but not limited to; LCD Screens, glass parts, lenses, bulbs etc. This warranty is effective only if the product is purchased and operated in USA and Canada, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability,

7

breach of warranty and breach of contract. Under no circumstances will Manufacturer's / Distributor's maximum liability exceed the retail value of the product.

WARRANTY PERFORMANCE: During the above 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

SERVICE AND REPAIR: If service is required for this product, you should first contact Midwest Trading Group Customer Service at info@mtradinggroup.com or by calling 1 (866) 815-4714, Monday to Friday 10am to 6pm EST.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

8