DEERC

8+

S201

RC CAR USER MANUAL

DEERC

Product manual

PREFACE

To make your experience with this remote control car as easy and convenient as possible, please read the instructions provided before using the product. Enjoy and have fun with the product while keeping the manual for future maintenance and reference.

1. In order to protect the legitimate rights and interests of users, please be sure to carefully read the contents of this manual before using this product.
2. When using this product, please be sure to strictly observe and conform the requirements which includes but not limited to operating guidelines, safety guidelines, safety warnings, safeties, precautions, legal disputes, or any other adverse event causing a conflict of interest resulting from the use of this product or any irresistible factors that are in violation of the safety instructions, the user shall bear the related responsibilities and the company [illegible] will not take any responsibility.
3. Once you start using the product, you are deemed to have read, understood, recommended, and accepted all terms and contents of the instructions (including disclaimers, safety instructions, warning instructions, etc.) included with this product.
4. In case you are having challenges on any aspect of the products, may it be operation or maintenance, please contact your local sales agent or contact customer support at DEERC.

PACKAGE CONTENTS

RC Car | Remote Control | Battery | USB Charging Cable | Dropper & Screwdriver | Product Manual

RC CAR'S DETAILS



REMOTE CONTROL FUNCTIONS

① Unscrew and open the battery cover.
② Insert 2 AA batteries in the correct direction.
③ Close the battery cover and lock it.

If the remote will not work for a long time, make sure to turn it off and remove the batteries.

CHARGING



1. Plug the USB charging cable into the USB charging port of the computer, power bank or USB adapter (5V/0.5-2.0A).
2. Connect the battery wire to the USB charging cable.
3. Charging time: about 120 minutes.
4. The red indicator light on the USB charging cable will turn on when it is charging and will turn off once fully charged.

Attention

- Please keep the battery in sight when charging. DO NOT put the battery on a flammable surface.
- If battery pack and USB charging cable are damaged, immediately stop using it and replace the accessories as soon as possible.



Use crossing screwdriver to wrench the screwson the chassis of the remote control car in anticlockwise direction,open the battery cover.

Mount battery pack,close the battery cover and screw it in clockwise direction.

CONTROL METHODS

1. Pairing

Once batteries are inserted to the car and the remote, turn on the car followed by the remote. Both will automatically pair.

The remote's power indicator will flash while waiting for the pairing process and will turn off once pairing has been successful.

2. Forward, Reverse, Turn Left and Turn Right

Pull the throttle trigger backward, the car goes reverse. Push the throttle trigger forward, the car goes reverse.

Turn the steering control wheel counterclockwise, the car will turn to left; turn the steering control wheel clockwise, the car turn to right.

3. Trimmer Function



If while the car is moving forward and veering to left then turn the trimmer knob to the "+" until the car is moving straight.

If while the car is moving forward and veering to right then turn the trimmer knob to the "-" until the car is moving straight.

4. Spray

Open the water tank stopper, fill the car with water&refills, close the stopper.
Press the spray switch once to turn on and turn off the spray.

NOTICE

1. Non-rechargeable batteries are not to be recharged.
2. Rechargeable batteries are only to be charged under adult supervision.
3. Not for children under 8+ years.
4. Always keep parts dry.
5. Always keep all chemical,small parts and anything electrical out of the reach of children.
6. Please do not be a bad battery,battery pack into fire or decomposition in the water to avoidaccidents.
7. Never place any portion of the vehicle in your mouth as it could cause serious injury or evendeath.
8. To charge the battery you must use only the stock included charger or a suitably compatible,FCC battery charger.I eserve to do so may result in a fire causing property damage andpersonal injury.
9. Always disconnect the battery after charging,and let the charger cool between charge sagain.
10. Check the vehicle regularly,make sure the vehicle is in good shape.
11. When the installation or replacement of the battery,Please note polarity.
12. Speed car uses a set of 3.7V rechargeable batteries.Remote control uses 2x1.5V"AA" batteries.
13. Do not resolution on sun and cakefocus for a long times.
14. Turn off the power of the transmitter and the remote control car when not in use.
15. Checking if all screws are loose or not.
16. Apply lubricating oil to all the moving parts.
17. Wipe off the dust and oil.
18. Remove the batteries as the battery seat when you do not use the car.

usa@deerc.com (USA)
eu@deerc.com (EU)
jp@deerc.com (JP)

Made in China

DEERC

www.deerc.com

FCC STATEMENT

This remote control complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.