

单页尺寸：68x98mm
材质：105G铜版纸彩色 小册子

[illegible][illegible][illegible]

Figure 1: Radiator Emission Pattern. The diagram shows a vertical antenna with a horizontal beam and side lobes. The graph shows the radiation pattern with a main beam and side lobes. The text explains that the radiation pattern is determined by the antenna structure and the frequency of the signal. It also notes that the radiation pattern can be adjusted by changing the antenna structure or the frequency of the signal.

FCV Warning
This equipment must be used with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference to other licensed operations in this class. This equipment generates uses and can radiate radio frequency energy and, if not installed and used properly, it may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following suggestions:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radio exposure limits set forth for unlicensed digital devices. Antenna must be installed and used in accordance with the instructions provided with the antenna and operated with minimum distance 20cm between the radiator and your body.