

One (1) Year Limited Warranty

This scale is warranted against defects in materials or workmanship (excluding batteries) for one (1) year for the original purchaser from date of retail purchase. It does not cover damages or wear resulting from accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair. Do not return to retailer. For product support & warranty information: Please contact us with proof of purchase (purchase receipt) at:

TAYLOR
2220 Entrada Del Sol, Suite A
Las Cruces, New Mexico 88001 USA
Phone: 1-866-843-3905
Email: taylorusa@lifetimebrands.com

There are no express warranties except as listed above. This warranty gives you specific legal rights, and you may have other rights which vary from state to state. For additional product information or warranty information outside the USA, please contact us through www.taylorusa.com.

©2025 Taylor, a division of Lifetime Brands, Inc. All rights reserved. Oak Brook, IL, 60523

**Made to our exact specifications in China.
Not legal for trade.**



FCC ID:2AJ5E-76044192

CP7604 12.25 WC

MODEL # 76044192

TAYLOR®

Bluetooth Smart Scale




INSTRUCTIONS FOR USE & WARRANTY INFORMATION



- **1-866-843-3905 (8-5pm MST, M-F)**
- www.taylorusa.com
- taylorusa@lifetimebrands.com

Scale Setup & Calibration




1. Insert 3 AAA (1.5V) batteries (included).
2. Place the scale on a hard, flat surface and toe tap to turn the scale on and to calibrate.
3. Scan QR code and download the free Precision Hub app.
4. Set up your user profile within the Precision Hub app.
5. The scale is ready to weigh.



Proper Foot Placement

Carefully step barefoot on the scale, ensuring your feet are evenly placed in the middle of the scale.



Stand still while your weight is being measured.

The scale will count up to your weight and lock it in. The scale will hold the display with the weight showing.

The scale turns off automatically after use.



DURING MEASUREMENT

- Place your feet in the same position every time you weigh yourself. Stand still during measurement.
- Weigh yourself without clothing whenever possible. Clothes can vary in weight.
- Place the scale where it won't be bumped while being activated or while in use, as an inaccurate reading may occur.
- For the most consistent readings, weigh yourself the same time of day, and for best results early in the morning, as weight can fluctuate due to food or drink in your system.

DETAILED INFORMATION ON HOW TO INSERT THE BATTERIES

1. Insert the 3 'AAA' (1.5V) batteries (included).
2. Remove any plastic wrap from the batteries before installing.
3. Open the battery cover on the back of the scale unit.
4. Place the batteries into the battery compartment according to the "+" and "-" polarity symbols in the battery compartment.
5. Replace the battery compartment cover and screws if applicable.
6. If you do not intend to use the scale for a prolonged period of time, it is advisable to remove the batteries before storing.
7. Do not mix old and new batteries.

Battery Warnings!

- Always purchase the correct size and grade of battery most suitable for the intended use.
- NOTE: Please recycle or dispose of batteries per local regulations.
- WARNING: Batteries may pose a choking hazard. As with all small items, do not let children handle batteries. If swallowed, seek medical attention immediately.
- PRECAUTION: Do not dispose of batteries in a fire. Batteries may explode or leak.
- Remove the batteries if the product will not be used for a long period of time. Remove used batteries promptly.
- Clean the battery contacts and also those of the device prior to battery installation.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 55°C, or incinerate. Doing so may result in injury due to venting, leakage, or explosion, resulting in chemical burns."
- Always replace all batteries at the same time; do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (Ni-Cad, Ni-MH, etc.) batteries.
- When batteries of different brands or types are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference in voltage or capacity. This can result in venting, leakage, and rupture, and may cause personal injury.

Troubleshooting Common Issues

1. If the scale does not turn on or no weight is displayed?

Check if the scale is powered up and started up. If not, please refer to the Section "Scale Setup & Calibration".

2. If the scale is inaccurate or the weight varies?

Place your feet in the center of the platform and stand still. Allow the weight to lock in before looking down at the display. Flooring may be a reason for fluctuation. Use the scale on the hardest floor available for accuracy. Do not move the scale unnecessarily.

3. I have tried all corrective actions, but still can't solve the problem ...

Please contact the Taylor Customer Service Department at 1-866-843-3905 (from 8:00 am to 5:00 pm, Mountain Standard Time, Monday through Friday) or by email to taylorusa@lifetimebrands.com.

4. Why isn't the app syncing my offline measurements?

The app will display a "Synchronize Data" button only if your specific scale requires manual offline measurement transfers. Tap the "Synchronize Data" button and wait for your offline measurements to upload. Some models sync automatically - in those cases, you won't see the button at all.

5. Issues with device connection?

- The scale can only be connected to one cell phone and app at the same time. If the Bluetooth icon is shown on the scale, it may have been connected to another cell phone.
- If the scale is already connected to another cell phone, you can close the app or temporarily turn off the Bluetooth on that cell phone. If the Bluetooth icon disappears, you can try to connect to the scale again.

Error Icons

Lo

This scale has a low battery indicator. It will display "Lo" or readings will grow dim or become irregular if the batteries need replacement.

Err

"Err" indicates an overload warning. The maximum capacity of this scale is 400 lbs / 180 kgs / 28 st 8 lbs. Should "Err" appear on the display during a weighing, this indicates that the maximum weighing capacity of the scale has been exceeded. Remove the weight immediately; otherwise, permanent damage may occur.

Care & Maintenance

1. The platform will be slippery when it is wet. Keep it dry! However, do not expose to direct sunlight, extreme hot/cold temperatures, or humidity.
2. This scale is designed to read weights between 11 and 400 lbs , 5 and 180 kgs. and 11 and 28 st 8 lbs. To prevent damage, do not place more than 400 lbs, 180 kgs or 28 st 8 lbs on it.
3. DO NOT strike, shock, or drop the scale.
4. Treat the scale with care, as it is a precise instrument. Always keep your scale in a horizontal position. Do not store the scale on its side.
5. Clean the scale with a damp cloth and avoid water getting inside the scale.
6. DO NOT use chemical/abrasive cleaning agents.
7. Always keep your scale in a horizontal position.
8. If your scale fails to turn on, check whether batteries are installed or battery power is low. Insert or replace with new batteries.
9. Do not use for commercial purposes and follow all instructions provided in this manual.

User Tips

1. Place your scale on a hard, flat surface, do not use on uneven tile, flooring or carpeting. Try to keep your scale in the same location or position as much as possible.
 2. Step on the scale with one foot applying enough pressure to turn the scale on - then remove your foot.
 3. The digital readout should show dashes or zeros.
 4. The scale will automatically turn off.
 5. Now your scale is ready for you to take a weight reading. Step on the scale evenly with both feet. If you pick up, move or bump your scale, please repeat the steps above for best accuracy.
- Weigh yourself without clothing whenever possible. Clothes can vary in weight.
 - Move the scale to a location where it won't be bumped. If your scale is bumped while being activated or while in use, an inaccurate reading may occur.
 - For the most consistent readings, weigh yourself at the same time of day. Allow for weight fluctuations due to food or drink in your system.

SAFETY WARNING

- The warning signs and icons shown appear in order for you to use this product safely and correctly, as well as to prevent product damage, risk, and injury to you and others.

PRECAUTION NOTICE

- Do not disassemble the scale, as incorrect handling may cause injury.
- Do not step on the scale when your body or feet are wet, especially after bathing or showering, to prevent slipping.

IMPORTANT NOTICE TO USERS

- Make sure to use only the type of battery stated (see Section “Detailed information on how to Insert the Batteries”).

FCC INFORMATION

Party issuing Supplier's Declaration of Conformity & Responsible party – U.S. Contact information:

Taylor division of Lifetime Brands Inc.
2311 W. 22nd Street, Suite 200
Oak Brook, IL 60523

Equipment:

Product Name: Bluetooth Smart Scale

Model No.: 76044192

Trade Name: Taylor

We declare under our sole responsibility that the above referenced product has been tested according to FCC requirements and this device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.