



无线蓝牙耳机  i38s 使用说明	产品规格 蓝牙版本: V5.0 有效距离: ≥ 12m 喇叭直径: Φ 10mm 阻抗: 16 Ω 麦克风: MEMS麦克风 麦克风灵敏度: -42dB 频率响应: 20Hz~20 KHz 播放时长: 约4小时(50%音量) 电池容量: 耳机30mAh, 充电盒400mAh 充电接口: Type-C, 5V-1A充电 物品清单 蓝牙耳机x2 充电线x1 充电盒x1 说明书x1 	功能说明 1.操作说明 1) 耳机充电: 将耳机放入充电仓充电,充电时充电仓绿色指示灯呼吸,充满电后灭灯。 2) 充电仓充电: 充电时、绿色指示灯呼吸;充满后、绿灯长亮。 3) 耳机入仓即关机。 4) 耳机开机: 打开充电仓上盖即耳机开机成功(耳机无指示灯闪烁)。 打开蓝牙设备(手机、平板等)找到蓝牙配对名 “i38s” 点击连接。 2.功能操作 接听电话: 来电时, 点击一下耳机 拒接电话: 来电时, 长按耳机两秒 挂断电话: 通话中, 双击一下耳机 暂停/播放: 单击左耳或右耳 下一曲: 右耳双击 上一曲: 左耳双击 游戏模式: 三击左耳或右耳(耳机呼吸灯亮) 呼叫Sir: 长按三秒唤醒(左右耳一样)	安全指引 (1)除说明书有特别标示的操作方式以外, 请勿尝试拆卸或更换产品内的任何零件; (2)请勿将产品放入水或其他任何液体中, 此产品非防水设计; (3)如果有任何液体不小心进入产品内时, 请立即断开连接并移开此产品, 继续使用有可能会一起起火 或触电。 (4)为避免触电, 请在安装或卸载产品时, 确保手上没有沾水; (5)请勿将此产品放置于热源附件或直接暴露在火源附近; (6)请勿将本产品放置在有强大电磁力的环境中, 否则会导致产品故障。
---	--	--	--

Wireless Earphone  i38s instruction for use	Product specification Bluetooth version: V5.0 Effective distance: ≥ 12m Diameter of trumpet: Φ 10mm Impedance: 16 Ω Horn sensitivity: -42dB Frequency response: 20Hz -20KHz Playing time: about 4 hours (50% volume) Battery capacity: 30mAh for earphone and 400mAh for charging case Charging interface: Type-C, 5V-1A Accessories list Bluetooth earphone x 2 Charging cable x 1 Charging box x 1 Instruction x 1 	Functional specifications 1. Operation instructions 1) Charge for earphones: Put the earphones into the charging case. The green breathing light of charging case will be on during charging and will be off after fully charging. 2) Charge for charging case: When charging, the green breathing light will be on ; then the green light will be constant on after fully charging. 3) Power on : Put the earphones into the charging case , then they will power off automatically. 4) Power off: Open the lid of the charging case, the earphones will power on successfully (There is no indicator light to flash on earphones). Turn on the Bluetooth device (mobile phone, tablet PC) and search for the bluetooth pairing name "i38s",then click to connect. 2. Functional operation Answer the call: touch the earphone for one time Reject the call: long press the earphone for two seconds Hang up the call: double-touch the earphone during calling. Pause/Play: Touch the L or R earphone Next song: Double touch the R earphone Last song: Double touch the L earphone Game mode: three touch the L or R earphone (Breathing light on) Wake up Siri: Long press R or Lfor 3 seconds	Safety Guidelines (1) Do not try to remove or replace any part of the product except the operation mode specified in the instruction; (2) Do not put the product into water or any other liquid. The product is not waterproof; (3) If any liquid enters the product accidentally, please disconnect and remove the product immediately. If you continue to use the product, there may be fire or electric shock together. (4) In order to avoid electric shock, please ensure that there is no water on your hands when installing or uninstalling the product; (5) Do not place the product near the heat source or directly expose it near the fire source; (6) Do not place the product in a strong electromagnetic environment, otherwise it will cause product failure;
--	--	---	---

FCC STATEMENT : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.	제품 사양 블루투스 버전 : V5.0 유효 거리 : ≥ 12m 스피커 직경 : Φ 10mm 임피던스 : 16 Ω 마이크 : MEMS 마이크 마이크 감도 : -42dB 주파수 응답 : 20Hz~20 KHz 제생 시간 : 약 4 시간 (볼륨 50 %) 배터리 용량 : 이어폰 30mAh, 충전 박스 400mAh 충전 인터페이스 : Type-C, 5V-1A 충전 물품명세서 블루투스 헤드셋 x2 충전 케이블 x1 충전 상자 x1 수동 x1 	기능 설명 1. 작동 지침 1) 이어폰 충전 : 이어폰을 충전함에 넣고 충전하면 충전 실의 녹색 표시등이 충전 중에 숨을 쉴 수 있습니다. 완전히 충전 된 후 조명을 끕니다. 2) 충전 실에서 충전 : 충전시 녹색 표시등이 숨을 쉬며 가득 차면 녹색 표시등이 계속 켜져 있습니다. 3) 창고에 보관되면 헤드셋이 꺼집니다. 4) 헤드셋 켜기 : 충전 실의 상단 덮개를 열면 헤드셋이 성공적으로 켜집니다 (헤드셋에 표시등이 깜박이지 않음). Bluetooth 장치 (휴대폰, 태블릿 등)를 켜서 Bluetooth 페어링 이름 "i38s"를 찾은 다음 링크를 클릭합니다. 2. 기능적 작동 전화 받기 : 전화가 오면 헤드셋을 클릭합니다. 전화 거부 : 전화가 올 때 헤드셋을 2 초 동안 길게 누릅니다. 전화 끊기 : 통화 중에 헤드셋을 두 번 클릭합니다. 일시 중지 / 재생 : 왼쪽 또는 오른쪽 귀 클릭 다음 노래 : 오른쪽 귀를 두 번 클릭 이전 : 왼쪽 귀를 두 번 클릭 게임 모드 : 왼쪽 또는 오른쪽 귀 트리플 클릭 (헤드폰 호흡 표시 등 켜짐) Call Sir : 3 초 동안 길게 누르면 깨어납니다 (왼쪽 귀와 오른쪽 귀도 동일).	안전 지침 (1) 매뉴얼에 특별히 표시된 조작 방법을 제외하고는 분해하거나 제품의 모든 부분을 교체하십시오. (2) 제품을 물이나 다른 액체에 넣지 마십시오.이 제품은 방수가 아닙니다. (3) 실수로 제품에 액체가 들어간 경우 즉시 제품을 분리하고 제거하십시오. 제품을 계속 사용하면 화재 나 감전의 원인이됩니다. (4) 감전을 방지하기 위해 제품을 설치하거나 제거 할 때 손에 물이 없는지 확인하십시오. (5)이 제품을 열린 근처에 두거나 직접 화원에 노출시키지 마십시오. (6) 전자기력이 강한 환경에 본 제품을 두지 마십시오. 고장의 원인이됩니다.
---	--	---	---