



## 1. Figure

The EUT-Overall View



## 2. Figure


The EUT-Front View



EUT is placed  
on the host


### 3. Figure

The EUT-Back View



### 4. Figure

The EUT-Front View



Antenna

## 5. Figure

The EUT-Back View

