






T13C 英文版说明书折页

成品尺寸：75*75 mm
材质：80g双胶纸，折页，单黑印刷
料号：11401-01431

正面内页内容

padmate® S18 	How to power on and pair the earphones (step 1)  Power on: Method 1. Take out the earphones from the stand, they will start up automatically and enter the pairing mode (make sure the stand is charged). Method 2. Hold on the touch button of earphone for 3-5 seconds to turn it on (the earphones must not be in the charging case and must be off).	How to power on and pair the earphones (step 2)  Turn on your phone's Bluetooth, search for "Padmate S18" in the available devices list, and click on it to complete the pairing (In order to obtain a more stable and better experience, it is recommended to use mobile phones with Android 6.0, iOS 10.0 or higher OS versions).	How to use (Touch Button) Touch Button Play / Pause Incoming call/hang up Call rejection Previous track Volumn down Call Voice Assistant Touch Button Play / Pause Incoming call/hang up Call rejection Next track Volumn up Call Voice Assistant Left ear Touch area Right ear	How to shut down and charge  About 6 hours Battery life About 3 times Mobile charger Method 1. The earphone will automatically turn off and start charging when is placed in the stand. Method 2. When turns off Bluetooth or exceeds the connection range of the earphone, earphone will automatically switch to standby mode; if it is not connected to any devices within 5 minutes, the earphone will automatically shut down.	How to charge the charger  Type-C charging port indicator light Use the Type-C cable to charge the cradle. When the cradle is charging, the red indicator light flashes; when it is fully charged, the red indicator light is always on.
--	--	---	---	--	--

反面内页内容

AUDIO PRODUCT WARNING! PERMANEN HEARING LOSS MAY RESULT FROM long-term EXPOSURE TO SOUNDS AT HIGH VOLUMES.USE AS LOW A VOLUME AS POSSIBLE. Avoid prolonged use of headsets at excessive sound pressure levels. Please read the Safety Guidelines below prior to using this product. You can reduce the risk of hearing damage by following these safety guidelines: 1.Prior to using this product follow these steps •Before using the product, turn the volume control to its lowest level. •Put the headset on, if applicable. 2.During the use of this product •Keep the volume at the lowest level possible; •If increased volume is necessary,adjust the volume control slowly; •If you experience discomfort or ringing in your ears,immediately discontinue using the product. With continued use at high volume,your ears may become accustomed to the sound level,which may result in permanent damage to your hearing without any noticeable discomfort. GENERAL SAFETY INFORMATION! •If you have a pacemaker or other electrical medical devices,consult your physician beforeusing this product. •This package contains small parts that may be hazardous to children.Always store the product out of reach from children.The bags themselves or the many small parts they contain may cause choking if ingested. •Don't disassemble the product yourself or insert any type of object into it,as this may causea circuit failure that can lead to a fire. •None of the components can be replaced or repaired by users.Only authorized	dealers or service centers may open the product.If any parts of your product require replacement for any reason, including normal wear and tear or breakage,contact your dealer or service centers. •Avoid exposing your product to rain or other liquids. •Keep all products,cords,and cables away from operating machinery. •Observe all signs and instructions that require an electrical device or RF radio product to be switched off in designated areas such as hospitals or aircrafts. •If this product overheats,has been dropped or damaged or has been dropped in a liquid,discontinue use. Remember:Always drive safely,avoid distractions and follow local laws! The use of a speaker while operating a motor cehicle may bo regulated by local laws. Using a headset while operating a motor cehicle motorcycle, watercraft or bicycle may be dangerous,and is illegal in some jurisdictions, just as use of this headset with both ears covered while driv-ing is not permitted in certain jurisdictions.Check with your local authorities. BUILT-IN BATTERY CARE: Please observe the following if the product contains a battery •Your product is powered by a rechargeable battery.The full performance of a new battery is achieved only after two or three complete charge and discharge cycles. •The battery can be charged and discharged hundreds of times, but will eventually wear out. Do not leave a fully charged battery connected to a charger since overcharging may shorten its lifetime. •If left unused, a fully charged battery will lose its charge over time. •The battery life will be shortened if you do not charge the headset for a long time. We recommend you to charge it at least once every three months •Leaving the product in hot or cold places will reduce the capacity and lifetime	of the battery Always try to keep the battery between 15°C and 25°C (59°Fand 77°F) .A product with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery warning •"Caution"—the battery used in this product may present a risk of fire or chemical bum if mistreated. Batteries may explode if damaged. •Only recharge your battery with the provided approved chargers designated for this product. •Dispose of batteries according to local regulations. Please recycle when possible.Do not dispose as household waste or in a fire as they may explode. •Unless otherwise specified in the user manual or quick start guide the battery in your product can not be removed or replaced by the user.Any attempt to do so is risky and may result in damage of the product. Important: Please refer to the user manual for a description of the charging status indicator lights.Some products cannot be used while charging Charger warning •Do not use a wall charger with more than 5V and 2A output. •When you disconnect the power cord or any enhancement,grasap and pull the plug,not the cord. Never use a charger that is damaged. •Do not attempt to disassemble the charger as it may expose you to dangerous electric shock. MAINTENANCE •Unplug the product or charger before cleaning. •Clean the product by wiping with a dry or slightly damp cloth.The cord and charger may only be dry-dusted.	FCC Warning This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --- Reorient or relocate the receiving antenna. --- Increase the separation between the equipment and receiver. --- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction FCC ID: 2AJEO-T13C	padmate® Padmate Warranty Card (Please keep this card as proof) Customer Name: _____ Phone No.: _____ Product Model: _____ Address: _____ Date of Purchase: _____ Product Series No.: _____ Purchase Stamp: _____ E-mail: _____ Notice: 1.Please fill out the form above with purchase stamp for the procedure of warranty. 2.Any change on warranty card and invoice will result in invalidation. 3.Please keep warranty card and invoice as the proof of warranty for the product. No replacement for warranty card or invoice. 4.This warranty is valid within 1 year from the date of purchase.	Tips ●Bluetooth Signal is easily interferred in the following environment. 1. Compact environment with multiple Wi-Fi signals and Bluetooth Signals. 2. Airport, railway, metro where electromagnetic interference is strong. ●Current bluetooth technology cannot guarantee synchronization of gaming and video playing. Model: T13C Input: 5V ---300mA Capacity: 250mAh/0.925Wh Made in China  Padmate S18 TWS Wireless Earbuds Xiamen Padmate Technology Co.,LTD. Add:RM201,Huli Park No.37,Industrial Zone,Tong'an District,Xiamen,China www.padmate-tech.com www.facebook.com/PadmateTech/ Customer service: support@padmate.cn
--	--	--	---	---	---