




遥控器功能说明



- 1 打开遥控器背面的电池盖。
- 2 按照电池箱内的电极指示正确装入2节1.5 "AA" 电池。不可混用新旧或不同类型的电池。
- 3 盖上电池盖。



车身装电池说明

- 1 打开遥控器背面的电池盖。
- 2 按照电池箱内的电极指示正确装入3节1.5 "AAA" 电池。不可混用新旧或不同类型的电池。
- 3 盖上电池盖。




使用3节1.5 "AAA" 电池。


基本操作方法



车身安装方法





将鳄鱼身体突出的连接件一端扣入鳄鱼头卡扣1, 再将另一端推入到卡扣2



将鳄鱼尾巴突出的连接件一端扣入鳄鱼身体卡扣1, 再将另一端推入到卡扣2 (方法与连接头部相同)


REMOTE CONTROL FUNCTION



1. Remove the battery cover from the back of controller.
2. Install 2 "AA" batteries into the controller, make sure to install batteries to their correct polarity. Do not mix old and new batteries or battery types.
3. Replace the battery cover



CAR BATTERY INSTALLATION INSTRUCTIONS

1. Remove the battery cover from the back of controller.
2. Install 3 "AAA" batteries into the controller, make sure to install batteries to their correct polarity. Do not mix old and new batteries or battery types.
3. Replace the battery cover




Use 3X 1.5V "AAA" batteries.


BASIC OPERATION METHOD



BODY ASSEMBLY METHOD



Fasten one end of the protruding connector of the crocodile body into Buckling Slot 1 on the crocodile head, then push the other end into Buckling Slot 2.



Fasten one end of the protruding connector of the crocodile tail into Buckling Slot 1 on the crocodile body, then push the other end into Buckling Slot 2 (assembly method is the same as connecting the head).

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.