



Smart Pet Feeder F1 Wi-Fi

Dear users:

Thank you for purchasing Petwant Automatic smart pet feeder.
This User Guide is intended to provide your pets with a better life.

To have a better user experience,
please read all directions before using the product and
retain this guide for reference.

Using environment: The feeder should be used
indoors(-5°C to 40°C).

Meanwhile, please put the feeder in the shade.



Wireless requirement: Only support 2.4 when configuration.

The best distance between feeder and router is
1-3m (no partition).


Scan the QR code and follow our
Facebook, through which you could get
high-quality after-sales service.



Meet Your Smart Feeder



Power Interface



Power Switch Battery Compartment

Download "Smart Life - Smart Living" APP

To have a better user experience, you need to download "Smart Life - Smart Living" at first through your App Store or Google Play.



Smart Life - Smart Living

Method:

Scan the QR code to enter the download page and install our APP according to the guidance.



Users should authorize permissions to network and location access when installing, or it will affect the normal operation of your feeder.


Create New Account

Click "Register" and follow the guidance in the Application to finish your account registering.





Add Device

Click "Add Device" in Home page,and come to others option,select Pet feeder. Then you need to confirm the indicator is rapidly blinking and choose the correct WiFi option follow the guidance and ensure you have entered the correct password. You need to wait for about 30 seconds to finish your configuration. Thank you for your patience.



Add Device

Please switch on at the bottom of the feeder, ensure the Link indicator on the panel is quick blinking and then you can start your configuration. You need to ensure that you are using 2.4g WiFi during the configuration process. If you can not ensure that, you need to go to the router setting page and open both 2.4g and 5g frequency, and choose 2.4g in WiFi option page.




Normal Situation:

If the link indicator is quick blinking, your device is ready for connecting.
If the link indicator is off, your device is connecting now.
If the link indicator is solid, you device is connected.

Unnormal Situation:


If the link indicator does not blink, please long press SET button for 5 seconds to reset your feeder.

APP Homepage




Automatic Feeding Setting

Click " + " button to add feeding schedules. In order to meet the habit of pets, users can set feeding schedules according to their pets' needs and up to 12 portions per meal. They can choose whether to open the pets call as well. If you want to delete meal setting, please slide this setting to the left and click "Delete".




Manual Feed

Short press the manual feed, it will dispense only one portion. Long press the manual feed, you can select the portions you want to feed and at most 12 portions.



More Settings


You can click " " to check the firmware updates and modify the device name, also remove device as well.



Assemble & Disassemble


Assemble & Disassemble food bucket:

Hold both sides of the Food Bucket and lift upwards for removal; The calibration direction of the food bucket needs to be aligned with the Slotting direction of main body and then press downward.



Assemble & Disassemble food tray:

Hold buckles on both sides of the food tray, push the tray towards the body. Pull the tray outwards for removal.



Cleaning Your Smart Feeder

1. Please cut off and unplug the device before cleaning.
 2. Clean the unit with a damp cloth rather than a soaked cloth.
 3. The food tray and tank can be removed for cleaning in the automatic dishwasher.
 4. The base can't be immersed in water at any time, or it may cause short-circuit of the device.
 5. It needs to be wiped clean and completely dry before refilling the food.
-

Important Safety Information

Explanation of Attention Words and Symbols used in this guide



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



WARNING indicates a hazardous situation which if not avoided could result in death or serious injury.

CAUTION

CAUTION used without the safety alert symbol, indicates a hazardous situation which if not avoided could result in harm to your pets.

NOTICE

NOTICE is used to address safe use practices not related to personal injury.



- ★ Do NOT place any foreign object in the pet feeder.
 - ★ Do NOT use outdoors. FOR INDOOR HOUSEHOLD USE ONLY.
 - ★ Do NOT use an appliance for anything other than its intended use.
 - ★ Do NOT allow children to play or around pet feeder.
 - ★ Do NOT place anything on top of the pet feeder. The unit starts automatically.
 - ★ Do NOT disassemble the pet feeder other than components as instructed in this operating guide.
 - ★ Do NOT install or store pet feeder where it will be exposed to weather or temperatures below -20°C.
 - ★ Do NOT immerse control panel in water. Base should NOT be submerged in water at any time, as this may damage electronic components.
 - ★ Do NOT use this pet feeder with puppies, kittens, dogs or cats not able to reach the food tray or with any physical disability.
 - ★ Do NOT operate any appliance if it has a damaged power cord or plug, or if malfunction or has been damaged. Call the Customer Care Center immediately for further instructions.
 - ★ Do NOT allow pets to chew on or swallow any parts. If you are concerned about the power cord, purchase a cord conduit (a hard plastic protector) in to protect the power cord.
 - ★ Do NOT attempt to repair the pet feeder by yourself.
-

Important Safety Information

- ★ If an extension cord is necessary, an extension cord with a proper rating should be used.
- ★ Do NOT use pet feeder for anything other than intended use. Using attachments not recommended or sold by the manufacturer may cause an unsafe condition.
- ★ Do NOT lift pet feeder by lid, hopper, bowl or bowl holder. Lift and carry feeder using both hands and hopper base, while keeping unit in upright position.
- ★ For dry food only. DO NOT use wet, canned or moist food.
- ★ To avoid tripping, always position power cord out of the way of foot traffic.
- ★ If the plug of this device gets wet, turn off the electricity to that wall outlet. Do not attempt to unplug.
- ★ Examine this appliance after installation. Do not plug in if there is water on the Power Cord or plug.
- ★ To reduce the risk of injury, close supervision is necessary when an appliance is used by or near children.
- ★ If using power cord, do not place power cord or plug in water or other liquids.
- ★ Dispose of all packaging materials properly. Some items may be packed in polybags; these bags could cause suffocation; keep away from children and pets.

CAUTION

- ★ Intended for dogs or cats only.
- ★ Pet feeder should be placed on a level surface.
- ★ Always unplug any appliance when not in use, before putting on or taking off parts and before cleaning. Never pull on the electrical power cord to remove the plug from the wall outlet.

NOTICE

- ★ Alarm indicator will flash in low battery to remind users to replace batteries or plug in adaptor.
- ★ Read and observe all important notices listed on the pet feeder and in the packaging.

SAVE THESE INSTRUCTIONS

Statement



FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Declaration of Conformity

“Hereby, Shenzhen Petwant Pet Products Co., Ltd, declares that this F1 Wi-Fi is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

The manual of Japanese version will be supplied in Japanese as well at the time of use.

