



Dear users:


Thank you for choosing to use our Petwant smart pet feeder.

We hope to help you living a high- quality pet- keeping life.

For your convenience, please read the guide carefully and follow the instructions in the guide.

F2 Wi-Fi

Scan the QR code and follow our Facebook account, which can help you obtaining high- quality after- sales service.



Give it love, It's simple

Intelligence curing Pet senior Housekeeper

SmartFeeder User's Guide

Important Safety Information

Explanation of Attention Words and Symbols used in this guide



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION, used without the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in harm to your pet.

NOTICE

NOTICE is used to address safe use practices not related to personal injury.

WARNING

- Do NOT immerse control panel in water. Base unit should NOT be submerged in water at any time, as this may damage electronic components.
- Do NOT place anything on top of the pet feeder. The unit starts automatically. Keep clear.
- Dispose of all packaging materials properly. Some items may be packed in polybags; these bags could cause suffocation; keep away from children and pets.
- Do NOT allow small children to play with, in or around pet feeder.
- To reduce the risk of injury, close supervision is necessary when an appliance is used by or near children.
- Intended for use with dogs or cats only.
- Do NOT use this pet feeder with puppies, kittens, dogs or cats not able to reach the food tray or with any physical disability.
- Do NOT use outdoors. FOR INDOOR HOUSEHOLD USE ONLY. Check operation frequently to be sure the pet feeder is dispensing properly.
- For dry food use only.
- DO NOT use wet, canned or moist food.
- Pet feeder should be placed on a level surface.
- Before leaving for extended time, always replace batteries with new batteries.
- Do NOT place any foreign object in the pet feeder.
- Do NOT disassemble the pet feeder other than components as instructed in this operating guide.
- To protect against electric shock, if using power cord do not place power cord or plug in water or other liquids.
- Only use attachments recommended or sold by the manufacturer.
- Do not unplug by pulling on power cord. To unplug, grasp the plug, not the power cord.
- Do not operate any appliance if it has a damaged power cord or plug, or if it is malfunctioning or has been damaged. Call the Customer Care Center immediately for further instructions.
- For a portable appliance - To reduce the risk of electrical shock, do not place or store an appliance where it can fall or be pulled into a tub or sink.
- Always unplug any appliance when not in use, before putting on or taking off parts and before cleaning. Never pull on the electrical power cord to remove the plug from the wall outlet.
- Do not use an appliance for anything other than its intended use.
- If the plug of this device gets wet, turn off the electricity to that wall outlet. Do not attempt to unplug.
- Examine this appliance after installation. Do not plug in if there is water on the Power Cord or plug.
- To avoid tripping, always position power cord out of the way of foot traffic.

- Do not allow pets to chew on or swallow any parts. If you are concerned about the power cord, purchase a cord conduit (a hard plastic protector) at any hardware store to protect the power cord.

- Do not attempt repairs on the pet feeder yourself.

- If an extension cord is necessary, an extension cord with a proper rating should be used.

- Do not use pet feeder for anything other than intended use. The use of attachments not recommended or sold by the manufacturer may cause an unsafe condition. Do not modify the pet feeder.

- Do not install or store pet feeder where it will be exposed to weather or temperatures below 40°F.

- Lift and carry feeder using both hands and hopper base, while keeping unit in upright position.

- Read and observe all important notices listed on the pet feeder and in the packaging.

SAVE THESE INSTRUCTIONS

Download Petwant APP



To configure your smart pet feeder,you'll need to download the Petwant- A APP.

Method 1:

Petwant-A APP is available on the Apple APP Store and Google Play. You can search "Petwant- A" in them for APP installation.

Method 2:

Scan the QR code to enter the download page to install APP according to the guidance.



Create your Petwant Account

Method 1:

Click the "Sign up",following the directions on the Petwant- A APP to create your user account.

Method 2:

Users can also sign up through other ways. Such as Twitter and Facebook.



When installed, users need to give the APP access to the location and network ,or it will affect feeder's work.

Create your Petwant Account

Method 1:

Click the "Sign up",following the directions on the Petwant- A APP to create your user account.


Method 2:

Users can also sign up through other ways. Such as Twitter and Facebook.



Preparations for Device Connection

Plug in the power supply and turn on the switch at the bottom of the device,ensure the Link(green) light is blinking,then users can connect feeder to Wi- Fi. Please be sure for cell phone has been connected to Wi-Fi during the first connecting operation.



If LINK(green) light is not blinking,please hold on pressing SET button 5s to re-launch the signal.

Add Device

Users click "+" button to enter the Device page, then choose the right model.



Add Device

Please reconfirm LINK(green) light is blinking, then hint the box and click "Confirm" to enter the Page of "Device Connection". Please enter right Wi-Fi password to ensure pet feeder is working properly. The time required to connect is affected by the network environment, which probably needs 10-20S. Please waiting with patience.



Enter Serial number Password

After you completing the "Add Device" operation, you can find a successfully paired device in the Nearby Devices. Each feeder is equipped with a unique product serial number to ensure your using process is safe and reliable.



APP Homepage



Automatic Feeding Setting

Click "+" icon in the homepage to add feeding information. According to pets' feeding habits, user can set feeding meals and portions independently, up to 4 meal per day. Each meal can be set up to 10 portions (about 10g per portion). After setting completed, user can also choose to open or close the meal independently.



Manual Feeding

Method 1: Hold on pressing countdown until another feeding interface appears to enable instant feeding. You can set portions independently to suit your pet's feeding habits. Each meal can be set up to 10 portions (about 10g per portion).

Method 2: You also can hold on pressing "SET" button on the operation panel to feed your pet manually.




Feeding Records

Click the top right menu to check today's feeding records. You can also choose the history range to view the historic feeding records.



Add Pet's Information

Click "User" icon to enter User Information interface. Click "+" icon, then you can add pet's information.



FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.