

产品认证标准: GB13837, GB17625.1, GB8898, eg in SB1770

販売店印欄 Dealer Chop	お客様へ商品をお渡しする際に販売日を明記した貴店印をご捺印下さい Please put your dealer chop on this space for the customer.
---------------------------------	--

Należy zachować ten dokument do użytku

1. Overview		
A) Front View (1) Volume Control Knob (2) Microphone Control Button (3) EQ / SXFI Button (4) Audio Output Button (5) Microphone-in (Mono) (6) Headphone-out	B) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port	8) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port

Wireless Type: Bluetooth Low Energy (BLE)
Operating RF range: 2402-2480 MHz
Max. RF Output Power: 4dBm
Input: SV ≙ 1A

2. Powering The Device

- (i) PC / Mac
(ii) PS4™
(iii) Nintendo Switch™ Dock
(iv) USB Wall Power Adapter*
*DC 5V, 1A (not included)

3.Connecting Headphones / Headset and Microphone

- (a) Microphone
(b) Headset
(c) Headphones
(i) Mic / Audio splitter cable*

*Cables not included

4. Connecting Speakers and Other Peripherals

- (a) **2.1 Analog Speaker**
(b) **7.1 Analog Speaker System**
(c) **S.1 Analog Speaker System**
(d) **AV Receiver**
(e) **Mobile Device**
(f) **Digital Audio Player**
- (i) Front
(ii) Side
(iii) Rear
(iv) Center / Subwoofer
(v) Line-in
(vi) Optical-out

5. Button Functions and LED Indicators

1. **Volume Control Knob**
Turn the knob left / right to decrease / increase playback's, microphones or Audio Balance's volume.
BLUE - Playback Volume
GREEN - Speaker Output
2. **Microphone Control Button**
Press once to switch to Mic control.
Use Volume Control Knob to control Mic Input Level. Press on the Volume Control Knob once to mute Mic monitoring.
Press and hold to activate / deactivate Audio Balance feature.
LED OFF - Mic Input / Monitoring Level – Off
RED - Mic Input / Monitoring Level – On
GREEN - Audio Balance – On

1. Overview		
A) Front View (1) Volume Control Knob (2) Microphone Control Button (3) EQ / SXFI Button (4) Audio Output Button (5) Microphone-in (Mono) (6) Headphone-out	B) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port	8) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port

Wireless Type: Bluetooth Low Energy (BLE)
Operating RF range: 2402-2480 MHz
Max. RF Output Power: 4dBm
Input: SV ≙ 1A

2. Powering The Device

- (i) PC / Mac
(ii) PS4™
(iii) Nintendo Switch™ Dock
(iv) USB Wall Power Adapter*
*DC 5V, 1A (not included)

3.Connecting Headphones / Headset and Microphone

- (a) Microphone
(b) Headset
(c) Headphones
(i) Mic / Audio splitter cable*

*Cables not included

4. Connecting Speakers and Other Peripherals

- (a) **2.1 Analog Speaker**
(b) **7.1 Analog Speaker System**
(c) **S.1 Analog Speaker System**
(d) **AV Receiver**
(e) **Mobile Device**
(f) **Digital Audio Player**
- (i) Front
(ii) Side
(iii) Rear
(iv) Center / Subwoofer
(v) Line-in
(vi) Optical-out

5. Button Functions and LED Indicators

1. **Volume Control Knob**
Turn the knob left / right to decrease / increase playback's, microphones or Audio Balance's volume.
BLUE - Playback Volume
GREEN - Speaker Output
2. **Microphone Control Button**
Press once to switch to Mic control.
Use Volume Control Knob to control Mic Input Level. Press on the Volume Control Knob once to mute Mic monitoring.
Press and hold to activate / deactivate Audio Balance feature.
LED OFF - Mic Input / Monitoring Level – Off
RED - Mic Input / Monitoring Level – On
GREEN - Audio Balance – On

1. Overview		
A) Front View (1) Volume Control Knob (2) Microphone Control Button (3) EQ / SXFI Button (4) Audio Output Button (5) Microphone-in (Mono) (6) Headphone-out	B) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port	8) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port

Wireless Type: Bluetooth Low Energy (BLE)
Operating RF range: 2402-2480 MHz
Max. RF Output Power: 4dBm
Input: SV ≙ 1A

2. Powering The Device

- (i) PC / Mac
(ii) PS4™
(iii) Nintendo Switch™ Dock
(iv) USB Wall Power Adapter*
*DC 5V, 1A (not included)

3.Connecting Headphones / Headset and Microphone

- (a) Microphone
(b) Headset
(c) Headphones
(i) Mic / Audio splitter cable*

*Cables not included

4. Connecting Speakers and Other Peripherals

- (a) **2.1 Analog Speaker**
(b) **7.1 Analog Speaker System**
(c) **S.1 Analog Speaker System**
(d) **AV Receiver**
(e) **Mobile Device**
(f) **Digital Audio Player**
- (i) Front
(ii) Side
(iii) Rear
(iv) Center / Subwoofer
(v) Line-in
(vi) Optical-out

5. Button Functions and LED Indicators

1. **Volume Control Knob**
Turn the knob left / right to decrease / increase playback's, microphones or Audio Balance's volume.
BLUE - Playback Volume
GREEN - Speaker Output
2. **Microphone Control Button**
Press once to switch to Mic control.
Use Volume Control Knob to control Mic Input Level. Press on the Volume Control Knob once to mute Mic monitoring.
Press and hold to activate / deactivate Audio Balance feature.
LED OFF - Mic Input / Monitoring Level – Off
RED - Mic Input / Monitoring Level – On
GREEN - Audio Balance – On

1. Overview		
A) Front View (1) Volume Control Knob (2) Microphone Control Button (3) EQ / SXFI Button (4) Audio Output Button (5) Microphone-in (Mono) (6) Headphone-out	B) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port	8) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port

Wireless Type: Bluetooth Low Energy (BLE)
Operating RF range: 2402-2480 MHz
Max. RF Output Power: 4dBm
Input: SV ≙ 1A

2. Powering The Device

- (i) PC / Mac
(ii) PS4™
(iii) Nintendo Switch™ Dock
(iv) USB Wall Power Adapter*
*DC 5V, 1A (not included)

3.Connecting Headphones / Headset and Microphone

- (a) Microphone
(b) Headset
(c) Headphones
(i) Mic / Audio splitter cable*

*Cables not included

4. Connecting Speakers and Other Peripherals

- (a) **2.1 Analog Speaker**
(b) **7.1 Analog Speaker System**
(c) **S.1 Analog Speaker System**
(d) **AV Receiver**
(e) **Mobile Device**
(f) **Digital Audio Player**
- (i) Front
(ii) Side
(iii) Rear
(iv) Center / Subwoofer
(v) Line-in
(vi) Optical-out

5. Button Functions and LED Indicators

1. **Volume Control Knob**
Turn the knob left / right to decrease / increase playback's, microphones or Audio Balance's volume.
BLUE - Playback Volume
GREEN - Speaker Output
2. **Microphone Control Button**
Press once to switch to Mic control.
Use Volume Control Knob to control Mic Input Level. Press on the Volume Control Knob once to mute Mic monitoring.
Press and hold to activate / deactivate Audio Balance feature.
LED OFF - Mic Input / Monitoring Level – Off
RED - Mic Input / Monitoring Level – On
GREEN - Audio Balance – On

1. Overview		
A) Front View (1) Volume Control Knob (2) Microphone Control Button (3) EQ / SXFI Button (4) Audio Output Button (5) Microphone-in (Mono) (6) Headphone-out	B) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port	8) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port

Wireless Type: Bluetooth Low Energy (BLE)
Operating RF range: 2402-2480 MHz
Max. RF Output Power: 4dBm
Input: SV ≙ 1A

2. Powering The Device

- (i) PC / Mac
(ii) PS4™
(iii) Nintendo Switch™ Dock
(iv) USB Wall Power Adapter*
*DC 5V, 1A (not included)

3.Connecting Headphones / Headset and Microphone

- (a) Microphone
(b) Headset
(c) Headphones
(i) Mic / Audio splitter cable*

*Cables not included

4. Connecting Speakers and Other Peripherals

- (a) **2.1 Analog Speaker**
(b) **7.1 Analog Speaker System**
(c) **S.1 Analog Speaker System**
(d) **AV Receiver**
(e) **Mobile Device**
(f) **Digital Audio Player**
- (i) Front
(ii) Side
(iii) Rear
(iv) Center / Subwoofer
(v) Line-in
(vi) Optical-out

5. Button Functions and LED Indicators

1. **Volume Control Knob**
Turn the knob left / right to decrease / increase playback's, microphones or Audio Balance's volume.
BLUE - Playback Volume
GREEN - Speaker Output
2. **Microphone Control Button**
Press once to switch to Mic control.
Use Volume Control Knob to control Mic Input Level. Press on the Volume Control Knob once to mute Mic monitoring.
Press and hold to activate / deactivate Audio Balance feature.
LED OFF - Mic Input / Monitoring Level – Off
RED - Mic Input / Monitoring Level – On
GREEN - Audio Balance – On

1. Overview		
A) Front View (1) Volume Control Knob (2) Microphone Control Button (3) EQ / SXFI Button (4) Audio Output Button (5) Microphone-in (Mono) (6) Headphone-out	B) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port	8) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port

Wireless Type: Bluetooth Low Energy (BLE)
Operating RF range: 2402-2480 MHz
Max. RF Output Power: 4dBm
Input: SV ≙ 1A

2. Powering The Device

- (i) PC / Mac
(ii) PS4™
(iii) Nintendo Switch™ Dock
(iv) USB Wall Power Adapter*
*DC 5V, 1A (not included)

3.Connecting Headphones / Headset and Microphone

- (a) Microphone
(b) Headset
(c) Headphones
(i) Mic / Audio splitter cable*

*Cables not included

4. Connecting Speakers and Other Peripherals

- (a) **2.1 Analog Speaker**
(b) **7.1 Analog Speaker System**
(c) **S.1 Analog Speaker System**
(d) **AV Receiver**
(e) **Mobile Device**
(f) **Digital Audio Player**
- (i) Front
(ii) Side
(iii) Rear
(iv) Center / Subwoofer
(v) Line-in
(vi) Optical-out

5. Button Functions and LED Indicators

1. **Volume Control Knob**
Turn the knob left / right to decrease / increase playback's, microphones or Audio Balance's volume.
BLUE - Playback Volume
GREEN - Speaker Output
2. **Microphone Control Button**
Press once to switch to Mic control.
Use Volume Control Knob to control Mic Input Level. Press on the Volume Control Knob once to mute Mic monitoring.
Press and hold to activate / deactivate Audio Balance feature.
LED OFF - Mic Input / Monitoring Level – Off
RED - Mic Input / Monitoring Level – On
GREEN - Audio Balance – On

1. Overview		
A) Front View (1) Volume Control Knob (2) Microphone Control Button (3) EQ / SXFI Button (4) Audio Output Button (5) Microphone-in (Mono) (6) Headphone-out	B) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port	8) Back View (7) Front-out (L / R) (8) Side-out (L / R) (9) Rear-out (L / R) (10) Center / Subwoofer (11) Line-in (12) Optical-out (13) USB Type-C Port

Wireless Type: Bluetooth Low Energy (BLE)
Operating RF range: 2402-2480 MHz
Max. RF Output Power: 4dBm
Input: SV ≙ 1A

2. Powering The Device

- (i) PC / Mac
(ii) PS4™
(iii) Nintendo Switch™ Dock
(iv) USB Wall Power Adapter*
*DC 5V, 1A (not included)

3.Connecting Headphones / Headset and Microphone

- (a) Microphone
(b) Headset
(c) Headphones
(i) Mic / Audio splitter cable*

*Cables not included

4. Connecting Speakers and Other Peripherals

- (a) **2.1 Analog Speaker**
(b) **7.1 Analog Speaker System**
(c) **S.1 Analog Speaker System**
(d) **AV Receiver**
(e) **Mobile Device**
(f) **Digital Audio Player**
- (i) Front
(ii) Side
(iii) Rear
(iv) Center / Subwoofer
(v) Line-in
(vi) Optical-out

5. Button Functions and LED Indicators

1. **Volume Control Knob**
Turn the knob left / right to decrease / increase playback's, microphones or Audio Balance's volume.
BLUE - Playback Volume
GREEN - Speaker Output
2. **Microphone Control Button**
Press once to switch to Mic control.
Use Volume Control Knob to control Mic Input Level. Press on the Volume Control Knob once to mute Mic monitoring.
Press and hold to activate / deactivate Audio Balance feature.
LED OFF - Mic Input / Monitoring Level – Off
RED - Mic Input / Monitoring Level – On
GREEN - Audio Balance – On

Ознакомьтесь с информацией, содержащейся в данном разделе, чтобы обеспечить условия безопасного использования изделия и снизить риск поражения электрическим током, возникновения короткого замыкания, нанесения травм, возгорания, удушья или слуха и прочих опасностей. **Неправильная эксплуатация изделия может привести к аннулированию гарантии. Дополнительную информацию см. в гарантийном документе, входящем в комплект поставки.**

- Не разбирайте и не пытайтесь самостоятельно ремонтировать изделие. Все работы по техническому обслуживанию и ремонту должны проводить квалифицированные специалисты.
- Запрещено эксплуатировать устройство при температурах ниже 0°C (32°F) и выше 45°C (113°F).
- Запрещено пробывать или повредить корпус устройства и бросать его в огонь.
- Держите устройство вдали от источников мощных магнитных полей.
- Запрещено подвергать изделие сильным механическим воздействиям и ударам.
- Запрещено подвергать изделие воздействию воды или влаги. Если продукт устойчив в высокой влажности, не погружайте его в воду и не выносите под дождь.

Техническая поддержка пользователей
На сайте creative.com/support/SBAE-7 круглосуточно доступна база знаний Creative, предназначенная для самостоятельного решения технических вопросов и устранения неполадок. На этом сайте Вы также можете воспользоваться услугами службы технической поддержки и найти другую полезную информацию.

Дополнительная информация
Дополнительная документация для этого продукта включает DoC и информацию по безопасности и нормативную информацию можно скачать с сайта поддержки creative.com/support/SBAE-7.

Гарантия
Информация о гарантии прилагается к изделию в отдельном документе. Сохраняйте документ, подтверждающий факт покупки, в течение всего гарантийного периода.

Сохраните данный документ для использованного в будущем.

ТИП ОБРАЗОВАНИЯ: Звуковая карта
Номер модели, торговая марка: SB1810 Creative
Издание: SV ≙ 1A
Производитель: Creative Labs Pte. Ltd.
Страна происхождения: Китай

Имя и адрес представителя Т.СОО "Прокси",
142281, Московская область, город Протвино,
Областное шоссе, д.2, К.216.

Номер телефона: +7 (495) 369-00-84
Электронный адрес: proxy.russia@gmail.com



EN The use of the WEEE Symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help protect the environment. For more detailed information about the recycling of this product, please contact your local authority, your household waste disposal service provider or the shop where you purchased the product.

FR L'utilisation du symbole DEEE indique que ce produit ne peut être traité comme déchet ménager. En garantissant la mise au rebut appropriée de ce produit, vous contribuez à préserver l'environnement. Pour plus d'informations sur le recyclage de ce produit, contactez les autorités locales, le fournisseur de service d'élimination des déchets ménagers ou le magasin où vous avez acheté le produit.

DE Die Verwendung des WEEE-Symbols gibt an, dass dieses Produkt nicht als Haushaltsmüll betrachtet werden kann. Durch die korrekte Entsorgung dieses Produktes tragen Sie zum Schutz der Umwelt bei. Weitere Informationen zum Recycling des Produkts erhalten Sie bei der örtlichen Behörde, für Sie zuständige Müllabfuhr oder das Geschäft, in dem Sie das Produkt erworben haben.

ES El uso del símbolo RAEE (WEEE) indica que el producto no se puede tratar como un desecho doméstico. Si se desecha de este producto debedamente, contribuirá a proteger el medio ambiente. Para obtener información sobre el reciclaje de este producto, póngase en contacto con las autoridades locales, el servicio de recogida de basura o la tienda donde ha adquirido el producto.

IT L'uso del simbolo RAEE indica che questo prodotto non deve trattato come un rifiuto domestico. Assicurandosi che questo prodotto sia smaltito correttamente, si contribuisce a proteggere l'ambiente. Per informazioni più dettagliate sul riciclaggio di questo prodotto, rivolgersi agli enti locali, al fornitore del servizio di smaltimento dei rifiuti domestici o al negozi in cui è stato acquistato il prodotto.

PL Symbol WEEE wskazuje, że ten produkt nie może być traktowany jako odpad gospodarczy. Zapewniając prawidłową utylizację produktu pomagasz w ochronie środowiska. Aby uzyskać szczegółowe informacje na temat utylizacji produktu, należy skontaktować się z lokalnymi władzami, przedsiębiorstwem świadczącym usługi usuwania odpadów z gospodarstwa domowego lub sklepem, w którym zakupiono produkt.

NL Gebruik van het WEEE-symbool betekent dat het product niet als normaal huishoudelijk afval mag worden verwerkt. U helpt met de bescherming van het milieu door dit product op correcte wijze te verwijderen. Voor meer informatie over het recyclen van dit product, neemt u contact op met het gemeentehuis, uw afvalafsterverlener of de winkel waar u het product hebt gekocht.

PT O uso do símbolo REEE indica que este produto não pode ser tratado como residuo doméstico. Ao garantir que este produto é eliminado correctamente, estará a proteger o ambiente. Para obter informações mais detalhadas sobre a reciclagem deste produto, contacte as autoridades locais, o fornecedor de serviços de eliminação de lixo doméstico ou a loja onde adquiriu este produto.

SV Användningen av WEEE-symbolen anger att produkten inte får hanteras som hushållsavfall. Genom att säkerställa att produkten hanteras på rätt sätt bidrar du till att skydda miljön. Mer detaljerad information om återvinningen av denna produkt får du hos den lokala återvinningssamfundningen, bolaget som hanterar dina hushållsoppor eller den återförsäljare där du köpte produkten.

NO Bruken av WEEE symbolet indikerer at dette produktet ikke kan behandles som husholdningsaffald. Du vil bidra til å beskytte miljøet ved å sørge for at dette produktet blir avhendet på en forsvarlig måte. Ta kontakt med kommunalt myndighet, renovasjonsselskaper der du bor eller forretningen hvor du kjøpte produktet for å få mer informasjon om resiklering av dette produktet.

DK Brugen af WEEE symbolet angiver, at dette produkt ikke må behandles som husholdningsaffald. Ved at sikre at produktet bortskaffes korrekt, vil du hjælpe med til at beskytte miljøet. For mere detaljerede oplysninger om genbrug af dette produkt, bedes du kontakte din kommune, dit renovationselskabs tjenesteudbyder eller den butik, hvor du købte produktet.

FI WEEE-symbolin käyttö ilmaisee, että tätä tuotetta ei saa hävittää kotitalousjätteen seassa. Huolehtimalla siitä, että tämä väline hävitetään asianmukaisesti, autat suojamaan ympäristöä. Tarkeimmat tiedot tämän tuotteen kierrätyksestä saat ottamalla yhteyttä paikallisviranomaisiin, jätteenhoitoyhtiöön tai liikkeeseen, josta ostit tämän tuotteen.

HU A WEEE szimbólum használatát jelzi, hogy termék nem kezelhető háztartási hulladékként. A termék megfelelő ártalmatlanításával segít védeni a környeztet. A termék újrahazsznosításával kapcsolatos további információkért keresse meg a helyi hatóságot, a háztartási hulladék elszállításáért felelős szolgáltatót vagy a boltot, ahol a terméket vásárolta.

EL Η χρήση του συμβόλου WEEE δηλώνει ότι δεν μπορείτε να αντιμετωπίσετε αυτό το προϊόν ως οικιακό απόρθητο. Βεβαιώνοντας της κατάλληλη απόρριξη του προϊόντος, αυτόν, βοηθάτε στην προστασία του περιβάλλοντος. Για περισσότερες πληροφορίες σχετικά με τη σωστή απόρριξη του προϊόντος, επικοινωνήστε με τις τοπικές αρχές, την υπηρεσία αποκοπής οικιακών απορριμμάτων ή το κατάστημα από όπου αγοράσατε το προϊόν.

LT EEEA simbolis rodo, kad produktas negalima išmesti kartu su buitineis atliekomis. Tinkamai išmesdami šį produktą padėsite saugoti aplinką. Jei išsamesnės informacijos, kaip perdirbti šį husholdinį atliekų, galite gauti iš vietinės atliekų surinkimo institucijos, butinių atliekų perdirbimo paslaugų teikėjų arba pardavtojų, kuriuos įsigijote šį produktą.

SK Použitie symbolu WEEE označuje, že tento výrobok sa nesmie likvidovať s komunálnym odpadom. Ak výrobok správne zlikvidujete, prispievate k ochrane životného prostredia. Podrobnejšie informácie o recyklácii výrobku získate na miestnom zastupiteľstve, u poskytovateľa služieb likvidácie domového odpadu alebo v predajni, v ktorej ste výrobok zakúpili.

CZ Použití symbolu WEEE označuje, že tento výrobek nesmí být považován za domovní odpad. Zajištěním správné likvidace tohoto výrobku pomůžete chránit životní prostředí. Podrobnější informace o recyklaci tohoto výrobku získáte od místních úřadů, od firmy, která u vás zajišťuje svoz odpadu, nebo v obchodě, kde jste výrobek zakoupili.

RU Использование символа WEEE означает, что данный продукт не может рассматриваться в качестве бытовых отходов. Соблюдая правильную утилизацию этого изделия, вы можете защитить окружающую среду. Для получения более подробной информации о переработке изделия, пожалуйста, обратитесь в местные органы власти, в службу сбора бытовых отходов или в магазин, где был приобретен продукт.

保修 随产品附带的保修信息为一个单独的文檔。请在保修期内保留购买凭证。

請保留此文件，以备今后參考。

保修 随产品附带的保修信息为一个单独的文檔。请在保修期内保留购买凭证。

請保留此文件，以备今后參考。

保修 随产品附带的保修信息为一个单独的文檔。请在保修期内保留购买凭证。

請保留此文件，以备今后參考。

保修 随产品附带的保修信息为一个单独的文檔。请在保修期内保留购买凭证。

請保留此文件，以备今后參考。

保修 随产品附带的保修信息为一个单独的文檔。请在保修期内保留购买凭证。

請保留此文件，以备今后參考。

保修 随产品附带的保修信息为一个单独的文檔。请在保修期内保留购买凭证。

請保留此文件，以备今后參考。

保修 随产品附带的保修信息为一个单独的文檔。请在保修期内保留购买凭证。

請保留此文件，以备今后參考。

保修 随产品附带的保修信息为一个单独的文檔。请在保修期内保留购买凭证。

請保留此文件，以备今后參考。

保修 随产品附带的保修信息为一个单独的文檔。请在保修期内保留购买凭证。

請保留此文件，以备今后參考。

保修 随产品附带的保修信息为一个单独的文檔。请在保修期内保留购买凭证。

請保留此文件，以备今后參考。

保修 随产品附带的保修信息为一个单独的文檔。请在保修期内保留购买凭证。

請保留此文件，以备今后參考。

Additional Safety and Regulatory information for Sound Blaster X3

Regulatory Information

The following sections contain notices for various countries:

CAUTION: This product is intended for use with FCC/CE certified computer equipment. Please check the equipment operating/installation manual and/or with the equipment manufacturer to verify/confirm if your equipment is suitable prior to the installation or use of the product.

Notice for USA

Federal Communication Commission (FCC) Interference Statement

FCC Part 15: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

CAUTION: To comply with the limits of the Class B digital device, pursuant to Part 15 of the FCC Rules, this device must be installed with computer equipment certified to comply with Class B limits.

All cables used to connect to the computer and peripherals must be shielded and grounded. Operation with non-certified computers or non-shielded cables may result in interference to radio or television reception. may result in interference to radio or television reception.

MODIFICATION: Any changes or modification not expressly approved by the grantee of this device could void the user's authority to operate the device the user's authority to operate the device.

Federal Communication Commission (FCC) Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Notice for Canada

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

L' émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes:

1. L' appareil ne doit pas produire de brouillage;
2. L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

Canada Radiation Exposure Statement

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d' exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet émetteur ne doit pas être situé ou fonctionner conjointement avec une autre antenne ou un autre émetteur.

MODIFICATION: Any changes or modification not expressly approved by the grantee of this device could void the user's authority to operate the device.

Toute modification non approuvée explicitement par le fournisseur de licence de l' appareil peut entraîner l' annulation du droit de l' utilisateur à utiliser l' appareil.

Ukraine RoHS Statement

Обладнання відповідає вимогам Технічного регламенту щодо обмеження використання деяких небезпечних речовин в електричному та електронному обладнанні, затвердженого постановою Кабінету Міністрів України від 3 грудня 2008 № 1057

充電式電池リサイクルについてのご注意

クリエイティブの一部製品にはリチウムイオン充電電池が使用されています。



Li-ion

リチウムイオン充電電池はリサイクル可能な資源です。

- クリエイティブ製品に内蔵されている充電電池をリサイクルするには、充電電池の取り外しはお客様ご自身で行わないで下さい。リサイクルの方法などのお問い合わせは、クリエイティブメディア株式会社のカスタマーサービスセンター (<http://jp.creative.com/support/contact/> (日本語のみ)) にご相談下さい。
- 取り外しが可能なクリエイティブ製品の充電電池をリサイクルするには -



注意事項

- 安全の為、電力を完全に使い切ってから充電電池を取り外して下さい。
- 安全の為、充電電池の金属端子部分にはセロハンテープなどの絶縁テープを貼って下さい。
- 安全策を講じた使用済み充電電池は、充電式電池のリサイクル協力店へお持ち下さい。充電式電池の回収/リサイクルおよびリサイクル協力店については、中間責任法人JBRCのホームページ <http://www.jbrc.com/> を参照して下さい。

Vietnam RoHS Statement

This product is in compliance with Circular 30/2011/TT-BCT of the Ministry of Trade of the Socialist Republic of Vietnam ("Circular"), it does not contain the following substances in concentration greater than the Maximum Limit value as specified in the Circular.

Substance	Maximum Limit (ppm) 1, 2
• lead	1000
• mercury	1000
• cadmium	100
• hexavalent chromium	1000
• polybrominated biphenyls (PBB)	1000
• polybrominated diphenyl ethers (PBDE)	1000

¹ Maximum Limit does not apply to applications exempted from the Circular.

² Maximum Limit refers to concentration by weight in homogeneous materials.

Notice for Taiwan

敬告使用者:

- 本產品使用時，不致造成違反低功率電波輻射性電機管理辦法之控制、調整及開關之使用方法。
- 本產品不得任意調整更改各項零件或對於發射之功率影響之作為，若有操作問題請與本公司人員聯繫；並由本公司負起監督及維修之責任。
- 根據交通部低功率電波輻射性電機管理辦法規定：

第十二條

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信法規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

SUPPLIER'S DECLARATION OF CONFORMITY

According to CFR Title 47 § 2.1077

Importer's Name: Creative Labs, Inc.
Importer's Address: 1901 McCarthy Boulevard
Milpitas, CA. 95035
Tel: (408)428-6600

declares under its sole responsibility that the product

Trade Name: Creative
Model Numbers: SB1810
Product Name: Sound Blaster X3

has been tested according to the FCC / CISPR22 requirement for Class B devices and found compliant with the following standards:

EMI/EMC: ANSI C63.4 & C63.10, FCC Part 15 Subpart B & C
Complies with Canadian ICES-003 Class B & RSS-247 standards

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including Interference that may cause undesirable operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Supplementary Information:

Thinh Bui
Compliance Manager
Creative Labs, Inc.
1st August 2019

内蔵バッテリー

- 内蔵バッテリーを取り外さないでください。

本製品は、各地の環境規制に準じて処分する必要があります。バッテリーを交換する場合は、お住まいの地域のサポート営業所に製品をお送りください。製品サービス情報については、www.creative.comをご覧ください。

- 直射日光や火等の過度の熱にさらさないでください。

注意: バッテリーが不適切な種類と交換されると、爆発する危険があります。交換は種類が同じまたは同等の電池のみを使用してください。

(Bluetoothデバイス用の追加ガイドライン)

- Bluetoothデバイスの短波無線周波数信号は、他の電子機器や医療機器の動作に悪影響を及ぼすことがあります。
- 使用を禁止されている場所ではデバイスの電源をお切りください。医療施設、飛行機、燃料補給地点、自動ドア付近、自動火災報知機付近、その他の自動制御機器の近くでこのデバイスを使用しないでください。
- このデバイスはペースメーカーや他の医療機器から20cm以上離してください。電波により、ペースメーカーやその他の医療機器の動作に悪影響を及ぼすことがあります。

내장된 배터리

- 내장된 배터리를 제거하지 마십시오.

제품은 해당 지역 환경 법규에 따라 폐기해야 합니다. 배터리를 교체하려면 지역에 제품을 반환사무실을 지원합니다. 제품서비스 정보에 대해 알아보려면 www.creative.com을 방문하십시오.

- 이러한 햇빛 화재 나 좋아하는 같은 과도한 열에 노출시키지 마십시오.

주의: 배터리가 잘못으로 대체하는 경우 폭발의 위험유형입니다. 동일하거나 같은 형식의 배터리 만 교체.

(Bluetooth 장치에 대한 추가 지침)

- Bluetooth 장치의 단파 무선 주파수 신호는 다른 전자 및 의료 장비의 작동에 영향을 미칠 수 있습니다.
- 사용이 금지된 곳에서는 장치를 끄십시오. 의료 기관, 항공기, 급유 지점, 자동차, 자동 화재 경보기 또는 기타 자동으로 제어되는 장치 근처에서는 사용하지 마십시오.
- 이 장치를 심장 박동 조절 장치 및 기타 의료 장비에서 최소 20cm 멀리 두십시오. 라디오파가 심장 박동 조절 장치 및 기타 의료 장비의 작동에 손상을 끼칠 수 있습니다.

Baterai Tersemat

- Jangan coba-coba melepas baterai yang tersemat.

Produk ini harus dibuat sesuai dengan peraturan lingkungan setempat. Untuk mengganti baterai, kembalikan produk Anda ke kantor dukungan di wilayah Anda. Untuk informasi layanan produk, kunjungi www.creative.com.

- Jangan sampai produk terkena panas yang berlebih seperti sinar matahari atau sejenisnya.

PERHATIAN: Berisiko meledak jika baterai diganti dengan tipe yang salah. Gantikan hanya dengan jenis yang sama atau yang setaraf.

(Panduan tambahan untuk perangkat Bluetooth)

- Sinyal frekuensi radio gelombang pendek dari perangkat Bluetooth dapat mengganggu fungsi perangkat elektronik dan medis lain.
- Matikan perangkat jika dilarang menggunakannya. Jangan gunakan perangkat di fasilitas medis, pesawat, pom bensin, dekat dengan pintu otomatis, alarm kebakaran otomatis, atau perangkat lainnya yang dikendalikan secara otomatis.
- Jauhkan perangkat ini setidaknya 20 cm dari alat pacu jantung dan perangkat medis lain. Gelombang radio dapat mengganggu fungsi alat pacu jantung dan perangkat medis lainnya.

AR إرشادات السلامة

البطارية المدمجة

- لا تحاول فك البطارية المدمجة.

يجب التخلص من المنتج وفقاً للوائح البيئية المحلية.

لاستبدال البطارية، أرجع المنتج الخاص بك إلى مكتب الدعم الإقليمي لديك.

للحصول على معلومات حول خدمة المنتج، انتقل إلى

www.creative.com

- لا تعرض الجهاز للحرارة الزائدة، مثل أشعة الشمس، أو النيران، أو ما شابه.

تنبيه: تجنب خطر الانفجار إذا تم استبدال البطارية بأنواع غير صحيحة.

استبدال فقط مع نفس النوع أو ما يعادلها.

خطوط إرشادية إضافية للأجهزة التي تدعم وظيفة Bluetooth

قد تُفسد إشارات التردد اللاسلكي ذات الموجات القصيرة لجهاز يدعم وظيفة

Bluetooth عملية تشغيل الأجهزة الإلكترونية والطبية الأخرى.

قم بإيقاف تشغيل الجهاز في الأماكن المحظور تشغيله فيها. لا تستخدم الجهاز في

المرافق الطبية أو الطائرات أو أماكن التزود بالوقود أو الأماكن القريبة من

الأبواب الأوتوماتيكية أو إنذارات الحريق التلقائية أو أي أجهزة أخرى يتم التحكم

بها بشكل تلقائي.

ضع هذا الجهاز على بعد 20 سم على الأقل عن أجهزة ضبط نبضات القلب أو

الأجهزة الطبية الأخرى. قد تُفسد الموجات اللاسلكية عملية تشغيل أجهزة ضبط

نبضات القلب والأجهزة الطبية الأخرى.