包装信息	型号：AMC2 Neo 成品尺寸：140*185MM 材质：120g书写纸，折页 工艺：四色印刷 版本号：V1.1-20230811	备注信息	英文版 较版本V1.0-20230620修改了文案和认证信息

尺寸：560*370mm

正面

背面

1 2 3

4



maono | GLOBAL BEST SELLING INTERNET MICROPHONE

User Manual

Portable Live Streaming and Podcast Console
For Computer & Smartphone

maono

GLOBAL BEST SELLING INTERNET MICROPHONE

Maono(「maono」, meaning "vision" in Kiswahili, is the Global Best Selling Internet Microphone Brand that products are sold well in 15.3 countries worldwide. With the beautiful vision of becoming a global leading brand of internet audio products that deliver a pleasant sound experience, Maono is always working with audio professionals, influencers, and users, to make the world's best microphones and audio products.

maonocaster™

Thanks for choosing Maonocaster C2 Neo podcast console.
Please read the User manual carefully to
have a better using experience.

Accessory List

Maonocaster C2 Neo Podcast Console — 3.5mm TRRS Audio Cable
USB-A to USB-C Cable — User Manual

Product Features

The Maonocaster C2 Neo audio console is the latest addition to the Maonocaster series. It features a simplified and compact design that reduces the learning curve and improves portability without compromising on the audio quality. We have also redesigned the I/O to make it work better with both PC and mobile devices.

The C2 Neo has an XLR microphone input with built-in premium preamps and phantom power that delivers studio-quality sound. It also supports wireless audio input via your other Bluetooth or 3.5mm AUX input for accompaniment. Additionally, you can utilize pitch presets, reverb presets, and three custom sound pads to elevate your content creating experiences.

Product Feature Highlights

- Multi-platform live streaming and podcast recording
- Independent microphone and accompaniment volume control
- Side-chain and music only feature
- Direct monitoring and loopback switch
- 3 Custom Sound Effect Buttons for different moods
- USB-C for easy connection with computer and mobile device.
- USB-C pass-thru charging for select mobile devices
- Compatible with Windows and macOS
- Built-in Battery, up to 6 hours of off-grid operation.

Applications

Podcasting, recording, and streaming on computers, tablets, and smartphones.
Compatible with mainstream recording and streaming software.

Specifications

Input Connectivity	USB-C	Battery Type	18650
Frequency Response	20Hz-20kHz	Battery Capacity	3000mAh
SNR	100dB(A-Weighted)	Power Input	5V/1A Max
Headphone Output	32Ω(M), 300Ω(L) Max. 150mW@1kHz	Charging Time	Approx. 2.5hrs
Low Cut Filter	100Hz/48dB	Battery Life	Approx. 6 hrs
Wireless Connectivity	Bluetooth 4.0	Thickness	38mm (1.50mm ± 0.2mm including buttons)

Model No.: AMC2 Neo

To get started, just
support_@maono.com
then QR code.

Technical Support
support@maono.com
www.maono.com

Made in China

Layout

1. Microphone gain knob_① fader_② and level meter_③

First enable XR and light to control the gain of the microphone. Keeping the gain too will reduce the amount of environmental noise being recorded.

Then slide up and down the fader to control the volume of the microphone.

The color distribution of the level meter: 1-6 green, 7-9 orange, 9 red.

To achieve the best audio quality, please keep the level meter in green and orange section.

2. Accompaniment volume knob

Rotate left and right to control the volume of audio input from USB-C input port, 3.5mm accompaniment input and Bluetooth input.

3. Battery level display

When all 3 LED lights are on, it means 100% battery level; when 2 LED lights are on, it means 75%; when 2 LED lights are on, it mean 50%; when 1 LED light is on, it means 25%. When charging, the battery level indicator LED lights will blink in sequence and a red light remains on.

4.Bluetooth LED indicator_① and switch button_②

① : After turning on the Bluetooth by long press the switch button, the LED indicator flashes and the device actively searches for and connects to paired devices. It stays on after a successful connection.

② : Press and hold the Bluetooth button for more than 3 seconds to turn the Bluetooth off.

5. USB&Stream Output level knob_① and output level meter_②

Rotate left and right to control the volume of audio output from 3.5mm stream output and USB-C output. The level meter on the right shows the output level.

6. Headphone volume fader

Slide up and down to control the headphone volume.

7. 48V phantom power supply switch

This button controls the phantom power of XLR microphone input. When the button is turned on, the 48V LED indicator lights up.

Whether to turn on phantom power depends on the type of XLR microphone you are using. In most cases, only XLR condenser microphones require phantom power to function. If your microphone does not require phantom power, turning it on may damage it.

Tip: Phantom power cannot be turned on when there is no XLR microphone connected.

If you don't know what type of microphone you have, please contact your microphone manufacturer for confirmation.

Select Maono XLR condenser microphone models: PD200, PD300, PD400X, PD400X Pro, MD200

Select Maono XLR dynamic microphone models: PD200, PD300, PD400X, PD400X Pro, MD200

8. There are five function keys in this area, namely Reverb Preset, Side Chain(Music Only), Direct Monitoring, Loopback, Pitch Presets, and Noise Reducer.

8.1 Reverb Presets

This function has 4 preset reverb effects. Short presets are switch back and forth between the original sound, KTV, church, hall, valley, and room among these 6 sound effects. When switching, the light color will change and some with voice prompts. The effect of reverb and echo changes after switching.

8.2 Side Chain and Music Only

The Side Chain function automatically lowers the volume of background music when you start to speak, highlighting your voice. It is suitable for chatting scenes in live broadcasts and podcasts. The Music Only mode can eliminate the vocal part in the accompaniment input and retain the in-sync part. It is suitable for karaoke users in singalong. The Side Chain function and Music Only function are turned off as default.

Button Operation	Function	Status	LED Indicator
Short Press	Switching On/Off Side Chain	Side Chain ON, Music Only OFF	
Long Press or Double Click	Switching On/Off Music Only	Side Chain ON, Music Only ON	
		Side Chain OFF, Music Only ON	
		Side Chain OFF, Music Only OFF	

Tips: Voice prompts and LED indicator shows the current status.

8.3 Direct Monitor and Loopback

Direct Monitor is turned on and the loopback is turned off by default.

If you want to hear your own voice recorded via microphone, you can turn off the Direct Monitor function.

If the Loopback feature is enabled, the audio sent to the device via USB will be sent back to the USB connected device. If it is disabled, the audio sent to the device can be heard through the headphones, but will not be recorded. Turning off this feature can avoid unwanted echos.

Button Operation	Function	Status	LED Indicator
Short Press	Switching On/Off Direct Monitor	Direct Monitor ON, Loopback ON	
Long Press or Double Click	Switching On/Off Loopback	Direct Monitor ON, Loopback OFF	
		Direct Monitor OFF, Loopback ON	
		Direct Monitor OFF, Loopback OFF	

Tips: Voice prompts and LED indicator shows the current status.

8.4 Pitch Presets

This feature adds pitch changing effects to the microphone input.

Short press to loop through the five pitch presets available and turn off the pitch changing feature. The LED indicator shows the current status.

9. Custom Sound Effect Buttons

Maonocaster C2 Neo provides users with 3 custom sound effect buttons. You can record their favorite song, music, beat and other sound clips into the device through microphone, external audio accompaniment, Bluetooth input to use it for broadcasting and recording.

MIC1 buttons can record sound effects within 20 seconds.

The product does not have custom sound preloaded and need to be recorded by the user first.

9.1 Erase existing sound effects: Press and hold any of the previously recorded custom keys for more than 3 seconds. The light goes out when the existing sound is successfully erased, entering the state of recording. The light goes out when the erasing is completed.

9.2 Sound effect recording: Regardless of whether there are special effects in the custom keys or not, the action of erasing the original special effects must be performed first. Short press the corresponding erased custom key, and the light flashes slowly. At this time, it is in recording state. The light goes out when recording is completed. during recording, if you short press the corresponding custom key, you can stop recording.

Tips: The storage space of each custom special effect key is limited. When the memory of this custom key is full, it will automatically stop recording. At this time, the light will automatically go out.

9.3 Play custom sound effects: Short press any of the previously recorded custom keys to start playing special effects. The LED indicator remains on until the playback is completed, during playback, short press to stop.

10. Power switch

Turn on and off the device.

Press and hold for 3 seconds to turn on.

When the power is on, press and hold for 3 seconds to turn off.

11. DC-5V interface

This interface is only used to power the device.

12. USB-C Data Interface

Data interface, can be used for audio data communications with computer and mobile devices.

Note:

(1) When using an external power supply to power the Maonocaster C2 Neo through the DC-5V interface, the USB-C interface can pass thru charge the smartphone connected via USB-C.

(2) When using a computer USB port to connect the sound card DC-5V interface for charging, the sound card's USB-C interface can charge USB-C mobile phones, while the USB-C port of the sound card charges the phone, it can also exchange digital audio signals with the phone.

(3) When not connected to an external power supply, the phone will not be charged, but audio data can be transmitted normally.

*** The phone needs to support OTG function and it is need to be turned on.**

(4) iPhone with Lightning connector requires an Lightning to USB Camera Adapter from Apple to connect to the Maonocaster C2 Neo.

13. STREAM OUT interface

3.5mm streaming interface, output audio signal to mobile phone (US standard interface), controlled by "USB & Stream Out" knob.

When connected to a streaming phone, the audio is transmitted through the connected 3.5mm TRRS (4 Pin) cable.

14. Headphone jack

Supports mobile phone earphones (TRRS plug), studio headphones (TRS plug).

*** When you connect mobile phone earphones to the headphone jack, the microphone input is not supported.**

15. 3.5mm AUX interface

Connect external audio sources or playback devices through an audio cable for easy playback of background music during live broadcasting and recording through an AUX audio cable.

16. Microphone Interface

Gooseneck XLR PRO microphone interface supports XLR or 6.35-3mm/¼in microphone input and can provide 48V phantom power for condenser microphone through the 48V button switch on the front panel. It supports both dynamic and condenser microphones.

Setup Guide

1.Smartphone Connection



1. Connect the streaming phone, accompaniment device, headphones and microphone as shown in the figure.
2. Turn on the power and adjust the various required sound effects.
3. Use an App to start streaming or recording.

Tips: If your phone do not have a 3.5mm jack, it is necessary to use the original USB-C to headphone adapter from your phone brand.

* You can record to two phones if your utilize both USB-C output and Line Out.

Maonocaster C2 Neo only supports one microphone input and is suitable for single-person recording live streaming.

2.PC Streaming



1. Connect the accompaniment source (mobile phones), headphones, and microphone to the Maonocaster C2 Neo as shown in the figure.
2. Use the included USB-C data cable to connect the computer and the Maonocaster C2 Neo. The computer will automatically recognize the device and install the drivers.
3. Enter the sound control panel of Windows, and set the "Maonocaster C2 Neo" as the system default playback and recording device in "playback" and "recording".

4. Open the streaming or recording software on your computer, and confirm "Maonocaster C2 Neo" is set as default audio recording and playback device.

Tips: Connecting your Stunning PC's audio output to AUX port with a 3.5mm cable then connecting your Streaming PC with USB-C will allow a Dual PC streaming setup.

3. Charging



1. You can use a USB-C cable to connect to a computer, power bank, or power adapter for charging.
2. The battery level display will turn red when charging, and flashes to show the charging progress.
3. The DC-5V port only supports device charging and does not have data transfer function.

Note:

- Please charge the device before first use.
- If not used for a long time, please charge the device every 3 months.
- Charging is supported even when the device is turned off.
- For safety, please stop charging after the battery is fully charged to avoid overcharging.

4.Bluetooth Connectivity

Maonocaster C2 Neo supports Bluetooth audio input for background music and accompaniment. You can also refer to Neo No.2 in function guide)



Pairing and connection:

1. Turn on the device and the Bluetooth indicator starts flashing.
2. Search for the device in your smartphone's Bluetooth menu and find the "Maonocaster C2 Neo" Bluetooth device and click the name to connect.
3. Bluetooth indicator remains solid when successful connection.
4. Play your desired music or audio on your smartphone.
5. Use a streaming or recording App on your phone to start content creation.

Notes:

- Bluetooth connection is limited by distance. Do not place the phone too far away.
- The Bluetooth connectivity is only for audio input.

5. Troubleshooting

5.1 Unable to power on

① Please check if the device has enough battery level and charge it before powering on.
② Press and hold the ⏻ logo button for more than 3 seconds to turn on the device.

5.2 No sound from the external audio source

① Check if the external audio source is connected to the AUX input or Bluetooth.
② Check if the AUX volume control knob is turned on.
③ Check if the volume of the audio input device is turned up.

5.3 No sound from the headphones

① Check if the headphone cable is plugged into the "headphone" jack.
② Check the "headphone" fader and gradually increase the volume by sliding it upwards.

5.4 No sound from the microphone

① Check if the microphone is correctly connected to the microphone input, unplug and reconnect if necessary.
② Check the "USB&Stream Out" knob in the middle. Turn it clockwise to gradually increase the output volume.
③ Check the "microphone volume" fader and gradually increase the volume by sliding it upwards.
④ Confirm with the microphone dealer if your microphone is compatible with Maonocaster C2 Neo, or consult us for recommended microphone models.

5.5 No sound during live streaming

① Check the "USB&Stream Out" knob and turn it clockwise to gradually increase the output to a suitable volume.
② Check if the "Maonocaster C2 Neo" is set as the default playback and recording device in the streaming software. If not, follow the instructions in the "PC Streaming Setup" section of this manual to set it up.

6. Safety Precautions

- To avoid personal injury or property damage caused by factors such as high temperature, noise, radiation, fire, and electricity, please use this product in a safe environment and carefully read and follow the following precautions.
- If the product overheats, emits smoke, or damage occurs during use, please turn off the power and unplug the power cord immediately, and send the product to the dealer for repair.
- Do not modify, disassemble or repair this equipment by yourself, so as not to invalidate the product warranty or cause personal injury. If necessary, please contact the dealer for assistance.
- This product should be used and stored in a dry, ventilated, and safe environment. Do not use this product in a damp or dusty environment.
- Avoid prolonged, over-watching, and overuse, and ensuring a short circuit, being close to a heat source, or exposure to direct sunlight may cause irreversible damage to the product.
- Do not use this product in situations where it is explicitly prohibited by law. Comply with relevant safety regulations and use this product safely to avoid accidents.
- This product is not a toy for children. Keep it out of the reach of children.

FCC Requirement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC Caution:

- English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) This device may not cause interference; and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- French:

Le présent appareil est conforme aux CNR d' Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage; et

(2) l' utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

Cet appareil est conforme aux limites d'exposition aux radiofréquences. Le matériel peut être utilisé dans des conditions d' exposition portables illimitées.