



名称: 小美规遥控器说明书 V1.0
尺寸 :48*65mm
材料 :128g 双铜
印刷方式: 风琴一折, 双面印刷
语言排列: 英




正面右



背面右

正面左



Remote Control Socket Instruction Manual

* Please read the Instructions carefully
before using the product.

Specification:

Rated voltage: AC 100-240V 50Hz /60Hz
Rated current: 15A
Transmission frequen: 2.4GHz
Power for Remote: 2xAAA battery

Installation:

Install 2xAAA battery in the compartment,
make sure the installation of battery is
correct.

Detailed Self- Learning Operation:

All remote controlled socket units had
been pre-paired no need to pair again.

If you want to pair the remote control
and plug socket again , do as below
please:

- ⦿ Plug the remote controlled socket to a
power point and turn the power on.
- ⦿ Press and hold the Learning button on the
socket for about 5 seconds until the LED is
flashing.
- ⦿ Release the learning button and long press
the ' ON ' or ' OFF ' button of the remote.
- ⦿ Paired successful when the LED
indicator on the socket stops flashing.

Change the battery:

Regularly change the battery in the remote
control for best use however if you find the
socket is not responding or the LED
indicator of remote control becomes dim,
then you have to change the battery at
the first time.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC ID: 2AJK8-IR40