

ShenZhen JinJiaYang Electronics Co.,Ltd

Bluetooth Headphone

Test Model: 530

IMPORTANT SAFETY INSTRUCTIONS

When using electronic equipment, basic safety precautions should be followed, including the following:

WARNING: To reduce the risk of electric shock, fire or injury to persons:

1. Read all instructions before using the unit.
2. Use this unit only for its intended use as described in this manual.
3. Do not operate this unit if it has a damaged cord or plug, is not working properly or has been damaged or dropped. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
4. **WARNING:** Do not allow Children to use the unit without supervision.
5. **WARNING:** Liquids and foodstuffs must not be spilled or dropped into the unit.
6. **WARNING:** it is hazardous for anyone other than a trained person to carry out any service or repair operation.
7. This unit is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.
8. Children should be supervised to ensure that they do not play with the unit.
9. The unit must be free-standing. It must not be placed in a cabinet.
10. The temperature of accessible surfaces may increase when the unit is operating.
11. This unit is not intended to be operated by means of an external timer or separate remote control.
12. If smoke is emitted, switch off and unplug the unit immediately.
13. **Cleaning:** Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a slightly damp cloth for cleaning and immediately wipe dry.
14. **Attachments:** Use only attachment recommended by the manufacturer. Use of other attachments may be hazardous.
15. **Water and Moisture:** Do not use this product near water (e.g., near a bath tub, washbowl, kitchen sink, laundry tub, in wet basements, or near a swimming pool and the like).

16. Ventilation: Slots and openings in the cabinet are provided for ventilation to ensure reliable operation of the product and to protect it from overheating. These openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided.
17. This unit must not be exposed to dripping or splashing and objects filled with liquids, such as vases, must not be placed on the apparatus.
18. Replacement Parts: When replacement parts are required, be sure that your service technician has used replacement parts specified by the manufacturer of that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electronic shock, or other hazards.
19. Safety Check: Upon completion of any service or repairs to this product ask the service technician to perform safety checks to ensure that the product is in proper operating condition.
20. Overloading: Do not overload wall outlets, extension cords, or integral convenience receptacles as this may result in a fire or electric shock.
21. When the AC/DC adapter is used as the disconnect device, the disconnect device must remain readily operable. To completely disconnect the power input, the AC/DC adapter must be completely disconnected from the mains.

PAIRING AND CONNECTION

Ensure that earphones and the cellphone are within 1 metre of each other.

Long press the button  for 3 seconds until the red/blue pairing lights illuminate.

Search for the item in the cellphone and press to connect.

NOTE:

If the earphones and the cellphone have been previously paired, the earphones will automatically connect to the cellphone when turned on.

The earphones will automatically turn off if not used for more than 5 minutes.

KEY FUNCTIONS

 button

Press for about 3 seconds to turn the earphones on. Long press for 3 seconds to pair or to turn off.

Press to answer an incoming call and press again to end the call.

Press for 3 seconds to reject an incoming call.

 /M button

Press to pause and resume when playing music.

Long press to change the mode.

+ - buttons

Press the + button for previous song and press the - button for the next song.

Long press the + button to increase the volume and long press the - button to decrease the volume.

BATTERY CHARGING

Use the micro USB charging cable to connect to a standard USB port(DC 5V) to recharge.

The indicator light turns red when charging and the light will turn off when fully charged.

SPECIFICATIONS

Speaker.....	Advanced 40mm driver unit
Impedance.....	32 Ω
Sensitivity.....	110dB
Bluetooth version.....	V2.1+EDR
Frequency response.....	20Hz-20KHz
Distance.....	10M
Battery capacity.....	3.7V/300mAh
Standby time.....	300hours
Talk time.....	8~10hours
Charging time.....	2-2.5hours

WARRANTY EXCLUSIONS

The warranty will not be valid if:

- 1.The product has not been installed, operated or maintained in accordance with the manufacturer operating instructions provided with the product.
- 2.The product has been used for purposes other than its intended function.
- 3.The product has been used for purposes other than household use.
- 4.The damage or malfunction of the product is caused by any of following conditions:

- Incorrect voltage
- Accidents (including liquid or moisture damage)
- Misuse or abuse of the product
- Faulty or improper installation

- Mains supply problems including power spikes or lightning damage
- Infestation by insects
- Tampering or modification of the product by persons other than authorised service personnel
- Exposure to abnormally corrosive materials
- Insertion of foreign objects into the unit

Warning:

1. In order to extend the life of the speakers and your physical and mental health, please do not play music in large volume mode for a long time.
2. Please select headphone output mode to listen music in public place, so as not to disturb others.

Adapter shall be installed near the equipment and shall be easily accessible. The plug considered as disconnect device of adapter.

This equipment had been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio Frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 5 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be located or operating in conjunction with any other antenna or transmitter.

The device has been evaluated to meet general RF exposure requirement. The Device can be used in portable exposure condition without restriction.