

MUG+

MG0 1 Wireless Speaker USER MANUAL



Warning

- Use a 5V 1A adaptor for charging.
- Removal of the built-in battery invalidates the warranty and may destroy the product.
- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important Safety Instructions

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus(including amplifiers) that produce heat.
- Only use attachment/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally or has been dropped.

Note: The product label is located on the bottom of the product.

Part Name



Specification

- Battery life : 8 hours
- Li-ion rechargeable battery
- Driver : 45mm/3W
- Frequency Response Range : 20Hz- 20kHz
- Connectivity: Bluetooth 4.1
- weight : 120g
- Wireless range: Up to 10m (50 feet). Obstacles may effect range
- Input: 5V 1A
- Amplifier DSP Technology

Get Started

1. Press pair button and hold 3 seconds until hearing “beep” tone. The LED indicator is flashing for pairing.
2. Go to Bluetooth ® settings on your device, search for “MUG+”and click to pair.
3. Put MUG+on any mug or container, play any music from your device.
4. To connect another device, short press pair button once again.

In The Box

- MUG+ x 1
- USB charging cable x 1