

NOKIA


E1200

Essential Wireless Headphones

User guide / 用戶指南 / 用戶指南 / ユーザーガイド


CONTENTS

内容 / 内容 / コンテンツ




POWER ON

开机 / 開機 / 電源オン




PAIRING

配對 / 配對 / ペアリング



CHARGING

充电 / 充電 / 充電する




LED

	Red
	Red


CONTROL

操控 / 操控 / コントロール

MUSIC



CALL



VOICE ASSISTANT



TROUBLE SHOOTING

疑难排除 / 疑難排除 / コントロール

Problem	Reason	Solution
Cannot turn on/ Do not react	Battery Low	Charge headphones for 2-3 hours and restart the headphones
No sound after paired	Wrong pairing	Pair again or reset headphones
Turn off automatically	Battery Low	Charge headphones for 2-3 hours
Red light flashes on headphones	Battery Low	Charge headphones
Headphones cannot be charged	Power supply problem	Perform a restart of the headphones
No light when charging	Power supply problem	Check if the charging cable is plugged in. Ensure the switch button is turned on.
Hearing echo	Volume is too loud or environment is noisy	Adjust the volume or change place
Noise in call	Environment interference caused or distance between headphones and mobile is too far	Change a place or move closer the headphones and devices
The sound occasionally drops out	Environment interference caused or distance between headphones and mobile is too far	Make sure the headphones are transmission range of the bluetooth device
The sound is too low	Volume is too low	Increase the volume

TROUBLE SHOOTING

疑难排除 / 疑難排除 / コントロール

故障	原因	解決方法
启动失败	低电量	为耳机充电
配对后没有声音	配对程序出错	先重置耳机再重新配对
耳机自动关机	低电量	为耳机充电
耳机在通话中亮红灯	低电量警告	请立即为耳机充电
耳机不能充电	电源问题	先重启耳机及为耳机充电
充电期间没有指示灯	电源问题	检查充电线是否插好及电源是否开启
迴声	音量太高或环境过于嘈杂	调整音量或改变使用环境
电话中的噪音	环境干扰或耳机跟设备距离超出范围	改变使用环境或缩短耳机和设备之间的距离
信号不好及有断续	环境干扰或耳机跟设备距离超出范围	远离干扰信号或缩短耳机与设备之间的距离
声音太少	音量太低	调高音量

TROUBLE SHOOTING

疑难排除 / 疑難排除 / コントロール

故障	原因	解決方法
啟動失敗	低電量	為耳機充電
配對後沒有聲音	配對程序出錯	先重置耳機再重新配對
耳機自動關機	低電量	為耳機充電
耳機在通話中亮紅燈	低電量警告	請立即為耳機充電
耳機不能充電	電源問題	先重啟耳機及為耳機充電
充電期間沒有指示燈	電源問題	檢查充電線是否插好及電源是否開啟
迴聲	音量太高或環境過於嘈雜	調整音量或改變使用環境
電話中的噪音	環境干擾或耳機跟設備距離超出範圍	改變使用環境或縮短耳機和設備之間的距離
信號不良及有斷續	環境干擾或耳機跟設備距離超出範圍	遠離干擾信號或縮短耳機與設備之間的距離
聲音太少	音量太低	調高音量

TROUBLE SHOOTING

疑难排除 / 疑難排除 / コントロール

Problem	Reason	Solution
Cannot turn on/ Do not react	Battery Low	Charge headphones for 2-3 hours and restart the headphones
No sound after paired	Wrong pairing	Pair again or reset headphones
Turn off automatically	Battery Low	Charge headphones for 2-3 hours
Red light flashes on headphones	Battery Low	Charge headphones
Headphones cannot be charged	Power supply problem	Perform a restart of the headphones
No light when charging	Power supply problem	Check if the charging cable is plugged in. Ensure the switch button is turned on.
Hearing echo	Volume is too loud or environment is noisy	Adjust the volume or change place
Noise in call	Environment interference caused or distance between headphones and mobile is too far	Change a place or move closer the headphones and devices
The sound occasionally drops out	Environment interference caused or distance between headphones and mobile is too far	Make sure the headphones are transmission range of the bluetooth device
The sound is too low	Volume is too low	Increase the volume

NOKIA

RichGO Technology (Shenzhen) Co.Ltd is a licensee of the Nokia brand for earphones and mobile accessories. Nokia is a registered trademark of Nokia Corporation.

The BLUETOOTH® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by RichGO is under license.

For product support, please visit <http://www.Nokia.com/shop/support> or call 4009993019 (CN)

SPECIFICATIONS

产品规格 / 產品規格 / 仕様

E1200 Essential Wireless Headphones

Wearing style	: Wireless Headphones
Ear coupling	: Circumaural
Frequency response	: 20 Hz to 20KHz
Transducer principle	: Dynamic, Closed
Transducer size	: 40mm
Sound pressure level(SPL)	: dB(1KHz/ 1mW)
Impedance	: Ω
Microphone principle	:
Power supply	: Built-in Lithium rechargeable batteries, 3.7V, 500mAh USB charging: 5V, mAh
Operating time	: 36 hrs (music playback via A2DP)*
Charging time	: approx. hours
Weight	: approx. 197g
Volume Control	: Yes

Bluetooth

Version	: Bluetooth Specification Version5.0
Profiles	: HSP,HFP,AVRCP,A2DP
Effective Range	: Line of sight approx. 30ft (10m)
Transmission frequency	: 2.402 MHz to 2.480 MHz
Output power	: 10mW (max)
Supported Audio Format(s)	: SBC

* Charging case that holds multiple charges for having the total listening time.Battery life depends on device settings, environment, usage and many other factors.

SAFETY GUIDE

安全須知 / 安全須知 / 安全ガイド

Important safety instructions

- Read the user guide (as supplied) carefully and completely before using the product.
- Always include this safety guide when passing the product on to third parties.
- Do not use an obviously defective product.
- Use only the product in environments where wireless Bluetooth®transmission is permitted.



Preventing damage to health and accidents

- Do not listen at high volume levels for long periods of time to prevent hearing damage.
- The product generates stronger permanent magnetic fields that could cause interference to cardiac pacemakers, implanted defibrillators (ICDs) and other implants. Always maintain a distance of at least 3.94" (10cm) between the product component containing the magnet and the cardiac pacemaker, implanted defibrillator or other implant.
- Keep the product, accessories and packaging parts out of reach of children and pets to prevent accidents. Swallowing and choking hazard.
- Do not use the product in an environment that requires your special-attention (e.g. in traffic).



Preventing damage to the product and malfunctions

- Always keep the product dry and do not expose it to extreme temperatures (hairdryer, heater, extended exposure to sunlight, etc.) to avoid corrosion or deformation. The normal operating temperature is from 0 °C to 40 °C/32 °F to 104 °F.
- Use only attachments/accessories/spare parts supplied or recommended by NOKIA.
- Only clean the product with a soft, dry cloth.



Safety instructions for lithium rechargeable batteries

WARNING
In extreme cases, rechargeable batteries may leak and may cause the following hazards if abused or misused:
• explosion • fire development • heat generation • smoke or gas development



Dispose of defective products with built-in rechargeable batteries at special collection points or return them to your specialist dealer.



Only use rechargeable batteries recommended by NOKIA and the appropriate chargers.



Only charge the product / rechargeable batteries at ambient temperatures between 10°C/50°F and 40°C/104°F.



Switch battery pack-powered products off after use.



When not using for extended periods of time, recharge the product / rechargeable batteries regularly (about every 3 months).



Do not heat the product / rechargeable batteries above 70 °C/158°F. Avoid exposure to sunlight and do not throw the product / rechargeable batteries into fire.

SAFETY GUIDE

安全須知 / 安全須知 / 安全ガイド

重要安全提示

- 在使用产品前请认真完整阅读用户指南 (按照供货 情况)。
- 请始终将产品和本安全指南一起交给第三方。
- 如果设备有明显的损伤, 请不要继续使用。
- 只能在允许无线蓝牙® 传输的地方使用本产品。



防止可能危害健康和引发事故的情况

- 为了保护您的听力, 请不要长时间使用高音量收听音乐。
- 本产品会产生较强的持久磁场, 可能会对心脏起搏器和植入式除颤器 (ICD) 和其他植入物造成干扰。含有磁铁的产品元件与心脏起搏器、植入式除颤器或其他植入物之间保持至少 10 厘米 (3.94 英寸) 的距离。
- 请将产品零件、包装零件和附件零件放置在儿童和宠物无法触及之处, 以防发生意外、窒息和窒息危险。
- 请勿在需要集中注意力的环境 (例如道路上) 使用本机。



防止产品损坏和故障

- 保持产品干燥, 不要将其暴露于低温或较高的环境温度下 (吹风机、加热器、长时间日照等) 以防腐蚀或变形。正常使用温度在 0 °C 至 40 °C 之间。
- 仅使用使用说明书提供或推荐的附件/配件/备件。
- 只用于干燥的软布清洁产品。



电池、充电电池的安全说明

警告
在极端情况下, 如果发生滥用或误用, 标准/充电电池可能会泄漏, 并可能造成以下危害:
• 过热 • 着火 • 爆炸 • 产生烟雾或有害气体



将报废的产品包括电池交到正规废旧回收中心或专业经销处。



请仅使用诺基亚推荐的电池和匹配的充电器。



只能在 10 °C 至 40 °C 的环境温度下给电池充电。



使用完毕后, 关闭电池供电的产品。



即使长时间不使用也要定期给电池充电 (约每 3 个月充电一次)。



不得将充电电池加热超过 70 °C。请避免日晒, 切勿将充电电池扔入火中。

SAFETY GUIDE

安全須知 / 安全須知 / 安全ガイド

安全注意事項

- 使用产品前, 请先阅读完整地了解用户指南 (随附提供)。
- 交给他人本产品时, 请务必附上本安全指示。
- 本产品明显受损伤时, 请勿使用。
- 使用本产品之前, 请先确认所在环境是否允许使用蓝牙®/蓝牙® 无线技术。



避免導致損害健康及意外事件。

- 請勿長期聽高分貝的聲音, 以避免聽力受損。
- 產品會產生較強的永久磁場, 可能會對心律調節器、植入式心臟起搏器 (ICD) 和其他植入裝置造成干擾。在包含磁鐵的產 品元件與心律調節器、植入式心臟起搏器或其他植入裝置之間, 務必保持至少 10 公分 (3.94 英寸) 的距離。
- 請將產品零件、包裝零件和附件零件放置在兒童和寵物無法觸及之處, 以防發 生意外、誤食和窒息危險。
- 請勿在需要集中注意力的環境 (例如道路上) 使用本機。



避免造成產品損壞和干擾

- 請永遠保持產品乾燥, 並不可將其暴露於極高溫或極低溫環境 (吹風機、暖氣、長時間光照等), 以免腐蝕或變形。正常使用溫度在 0 °C 至 40 °C 之間。
- 請務必使用 NOKIA 提供或建議的附件、配件和備用零件。
- 清潔本機時, 只可使用乾燥軟布。



電池/充電電池使用安全注意事項

警告
在極端情況下, 充電電池可能會洩漏, 如果濫用或誤用可能會導致以下危害:
• 產生過熱現象 • 產生火災 • 產生爆炸 • 產生煙霧



將將廢的產品包括充電電池交回收集點或在您附近的經銷商。



請僅使用 NOKIA 推薦的充電電池及為其適配的充電器。



僅在環境溫度為 10 °C 到 40 °C 時對電池充電。



由電池提供電源的產品, 不使用時務必關機。



長期不使用時, 應定時 (約每三個月) 為電池充電。



請勿讓電池承受 70 °C 以上的溫度, 應避免陽光直射, 且不可將電池丟入火中。

正當使用本機/法律責任

此款耳機作為藍牙相容型配件設備, 專門設計用於無線音訊通訊, 如播放音樂或透過藍牙技術通話等。使用本產品時, 若不符合相關的產品指南中列出的用途, 屬不當使用。對產品以及附加設備/配件的錯誤使用或不規範使用造成的損壞, NOKIA 不承擔任何責任。NOKIA 不擔保與 USB 規範不符合的 USB 設備損害。NOKIA 公司對因電池電量耗盡、過度老化或輸出藍牙信號範圍而導致的通訊中斷及其損失不承擔任何負責。在操作設備前, 請遵守各自國家的具體法規!

廠商聲明

有關合規性標記的更多信息, 請參閱文件末尾。

保固

NOKIA 為此產品提供一年 (12 個月) 保固。
請前往本公司網站 www.nokia.com/shop/support 瞭解目前有效的保固條件, 或諮詢銷售 此產品的 NOKIA 經銷商。

回收

請將您使用過的電子產品、電池以及包裝材料都交到指定的收集點。這樣, 您便有助於防止不受控制的 廢物處理, 以及促進物料的循環再造。電氣和電子產品含有貴重材料, 包括金屬 (例如銅、鋁、鎳和鎳) 和貴重金屬 (例如金、銀和鉑)。本裝置所有材料都可以回收做為物料和能源。
若產品、電池、文獻或包裝上有輪軸形標上交叉交叉的標誌, 這表示當所有電器和電子產品與電池的 使用期限屆滿時, 必須另行收集及處理。請將這些產品送至分類的都市廢物 表棄, 讓它們收集以 供循環再造。如要獲取最近收集地點的資料, 請諮詢本地廢物處理有 關部門。

低功率電波輻射性電機管理辦法

經型式認證合格之低功率射頻電機, 非經許可, 公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
低功率射頻電機之使用不得影響航航安全及干擾合法通信; 經發現有干擾現象時, 應立即停用, 並改善至無干擾時方得繼續使用。
前項合法通信, 指依電信法規定作業之無線電通信。
低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

規定に沿った使用/賠償責任

このヘッドホンは、Bluetooth無線通信技術を通じての音楽再生および電話な どの無線オーディオコミュニケーション用のBluetooth対応機器用のアクセサリとして考案されて います。製品は、関連製品のガイドに記載された以外の使用の仕方をしてください。製 品や付属品/アクセサリの間違った使用や不適切な使用に起因する損 傷に対して NOKIA は何らの責任を負いません。NOKIA は、USB -規格に一致しないUSB -機器の損傷に は責任を負いません。
NOKIA は、空のバッテリーや劣化したバッテリー、またはBluetooth -送信エリアの 急劇による接続断絶に基づく損傷には責任を負いません。本機器の操作を開始する前 に、各国の規制についてはご確認ください。

製造者宣言

法規定遵守の表示に関する詳細情報は本文書の最後でご確認いただけます。保証NOKIAは 本製品1を年間保証いたします。実際の保証条件については、弊社ウェブサイト www.nokia.com/shop/supportをご覧ください。または、最寄りの NOKIA 取扱店までお問い合わせください。

SAFETY GUIDE

安全須知 / 安全須知 / 安全ガイド

安全に関する注意事項

- 製品をお使いになる前に、(同梱の)取扱説明書クイックガイドをすべて良くお読みください。
- 製品を第三者に渡す場合は、必ず安全に関する注意事項も一緒に渡します。
- 明らかに故障がある場合は、製品を使用しないでください。
- 本製品はワイヤレスBluetooth®を伝送が許可される環境でのみ使用します。



健康被害と事故を防止するために

- 聴覚被害を防止するために、大音量で長時間使用しないでください。
- 本製品は、より強力な永久磁界を生成し、心臓ペースメーカー、植込み型除颤器 (ICD) 等、および他のインプラント製品の手を引き起こす危険性があります。磁界を含む製品構成要素と心臓ペースメーカー、植込み型除颤器、または他のインプラントと当地の間に、少なくとも 10cm (3.94 インチ) 以上の距離を確保してください。
- 事故を防ぐため、製品、梱包、アクセサリの部品は子供やペットの手が届かないところに保管してください。飲み込みと窒息する危険性があります。
- 道路を歩く場合など、特に注意が必要な状況では、本製品を使用しないでください。



製品の破損と故障を防止するために

- 錆や変形を防止するために、製品は常に乾燥した状態に保ち、著しく低温または 高温場所には置かないでください。ドライヤーや暖房などで熱くならないよう に注意してください。また、長時間直射日光に当てないでください。
- NOKIA が提供または推奨する付属品、アクセサリ、スぺア部品のみを使用してください。
- 製品は柔らかい乾いた布を使って清掃してください。



バッテリーの安全上の注意事項

警告
乾電池/充電電池を正しく使用しないと、ひどい場合には液漏れすることがあり、次の危険を引き起こすおそれがあります:
• 熱の発生 • 火災の発生 • 爆発 • 煙やガスの発生



故障した製品は、バッテリーを含めて、収集所に廃棄するか、または専 門業者までお持ちください。



NOKIA が推奨するバッテリーと、それに適した充電器だけをお使 ください。



バッテリーは、10 °C ~ 40 °C の周囲温度でのみ充電してください。



用後は、バッテリーで電力供給される製品のスイッチを切ります。



長期間使用しない場合は、バッテリーを定期的に充電してください (約3ヶ月ごと)



バッテリー温度が70°Cを超えないようにしましょう。バッテリーを日のあたる場所に置いたり、火中に加ったりしないでください。

本機を廃棄するときのご注意



機器に内蔵されている充電式電池はリサイクルできます。この 充電式電池の取りはずしはお客様自身で行わず、「ソニーの相談窓口」にご相談ください。(「ソニーの相談窓口」の連絡先は裏表紙に記載されています。)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

RESET

重置 / 重置 / リセット

